



trend-line™

STYLE/MODÈLE: 1445

1445-01 Sofa
1445-02 Loveseat
1445-03 Chair
1445-05 Corner
1445-06 RHF Loveseat
1445-07 LHF Loveseat
1445-30 RHF Corner Sofa Sectional
1445-31 LHF Corner Sofa Sectional
1445-20 LHF Sofa with Chaise (with floating base)
1445-22 RHF Sofa with Chaise (with floating base)
1445-41 LHF Corner Chaise
1445-42 RHF Corner Chaise

L	D/P	H
85	37	38
62	37	38
39	37	38
37	37	38
54	37	38
54	37	38
91	37	38
91	37	38
85	59	38
85	59	38
36	80	38
36	80	38

L: length D: depth H: height
 AH: arm height SD: seat depth SH: seat height
 L: longueur P: profondeur H: hauteur
 HB: hauteur/bras PS: profondeur/siège HS: hauteur/siège