



Immersive Sound

Congratulations on the purchase of your new MotoMotion Immersive Sound Sofa, Loveseat or Chair!

It is important to note that the Amplifier is located in different locations on various products:

- Sofa Mounted behind the back flat on the middle seat
- Loveseat Mounted inside the console (access from the bottom via a zipper)
- Recliner Mounted inside either arm (access from the bottom via a zipper)

There are 3 ways in which to connect the immersive sound system to your desired audio source:

- 1. Wireless (Make sure your TV has Bluetooth capability prior to delivery) Prior to Delivery Not all TV Bluetooth will connect to the Motomotion Immersive Sound. An Optical Bluetooth Wireless Transmitter is required.
- 2. 3.5mm Auxiliary Cable
- 3. Digital optical cable

1. Immersive Sound - Wireless (Multiple Units) Recommended



Digital Optical Splitter & Dual USB Type A Charge



Multiple Moto Moion product(s) can be connected wirelessly with a wireless transmitter (sold separately) like the one pictured in the upper left corner.

Most newer TVs can cast a single Bluetooth signal. It is very important to verify that your tv has this function prior to your delivery. Refer to your TV owner's manual for set up instructions.

The wireless transmitter pictured in the upper left corner, allows up to 2 devices to be paired to a single audio source (i.e. TV, gaming system, tablet, etc). Additional transmitters can be used simultaneously using a digital optical splitter. The transmitter pictured above comes with (1) digital optical cable, (1) 3.5mm auxiliary cord and (1) USB type A charging cord.

"If you are using two transmitters simultaneously to Bluetooth up to 4 devices, a digital optical splitter an dual USB type A charger will need to be purchased separately. (see bottom left pictures) This set up is based on the Monster transmitter pictured above. Please follow the directions supplied with your wireless transmitter for proper hookup.

Immersive Sound Components

- A. Immersive sound starts with tactile transducers. Located in the seat and lower back of the reclining seats, these vibrating discs elevate your entertainment experience.
- B. A 100-watt amplifier provides all the power you will need, regardless of your entertainment selection.
- C. Two Full range speakers, one in each arm, bring your movies, music or video games to life.
- D. Our patented subwoofer provides just the right amount of boom without disrupting the neighbors.



Wireless Audio Set Up-1 Pc Only



Audio Control Panel Locations: Sofa - Drop Down Table Loveseat - Inside the Console Recliner - Inside the Arm

- 1. Make sure that Bluetooth is enabled on the device in which you are wanting to connect to.
- 2. Press and hold the black button on the audio control panel for 5 seconds until the blue light starts to flash.
- 3. On your audio source (i.e. cell phone, tablet, tv etc). look for "Moto Media System". Once located, select to pair your device to the immersive sound equipment.

NOTE: If system is hardwired via an auxiliary cord or digital optical cable wireless function will connect but will not play any audio.

2. 3.5 mm Hardwire

The most economical audio performance will be achieved by hooking up your system via 3.5 mm auxiliary cable. Each MotoMotion amplifier is equipped with an AUX Input. The input selection switch should be placed in the AUX position.

The cord(s) necessary for this installation is NOT included with you MotoMotion product(s) and would need to be purchased prior to your delivery.

In the event you have multiple MotoMotion Immersive Sound products,, you can simploy daisy chain off the first MotoMotion product by plugging a second 3.5 mm auxiliary cord into the AUX Output and then into the AUX input on the next product.



Hardwire



It is important to note that each audio source (i.e. TV, gaming system, tablet, etc) has different outputs for running audio to external sources such as an immersive sound sofa, loveseat or chair. It is important that you verify your audio output options on your audio source prior to delivery.

On this TV there are 2 audio output options. Digital Optical Cable or RCA jacks. Either of these options can be used to carry audio to your MotoMotion amplifier.

*If the desired option is to use the RCA (red and white) Outputs, an RCA to 3.5mm adapter cord like the one pictured would need to be purchased prior to delivery.

3. Digital Optical Cable Hardwire

The best audio performance will be achieved by hooking up your system via a digital optical cable. Each MotoMotion amplifier is equipped with a single SPDIF (Optical Input). The input selection switch should be placed in the SPDIF position.

The cord(s) necessary for this installation is NOT included with your MotoMotion product and would need to be purchased prior to your delivery.

In the event you have multiple MotoMotion Immersive Sound units, you would need to buy a digital optical splitter to hook to your TV so that cords could be run to each unit. **See example pictured to the right.**

