

IMPORTANT NOTICE:
Storing and opening the leaf
requires 2 people.

WINNERS ONLY®

ASSEMBLY INSTRUCTIONS

PROD. NO : **DAT23684RT & DAT23684RB**

Thank you for purchasing this quality product. Please read the instructions thoroughly before unpacking the assembly parts.

Caution: sharp exposed staple tips can cause injury, therefore for your protection, please remove any exposed staples used in packing.

Please keep all hardware parts out of the reach of children.

1. We recommend that you should assemble this product with the assistance of another person; this will make the assembly easier, and will help to prevent personal injury and to insure parts are not damaged during the assembly process.






2. Before beginning, please check the packing materials carefully for small parts which may have come loose inside the carton during shipping. Please do not discard any packing material until all parts have been located. If any parts are missing, please contact your dealer for prompt replacement.



3. To prevent damage to your floor or carpet, please check the bottom of each piece of furniture for stain residues and rough surfaces and also check for staples or nails left after removing the packing materials. The manufacturer will not be held responsible if preventive steps are not taken prior to installation.









4. Please do not over tighten screws or bolts. During normal use everyday, screws, bolts, nuts and wooden plugs may loosen up. They should be periodically inspected and re-tightened to prevent damage to the furniture and (or) personal property or cause injury. Always check to be sure all hardware on this list and the below mentioned components are attached to the furniture properly and kept tightened.

5. Please lay all parts and hardware on a non abrasive surface such as a carpet, and follow the assembly

Hardware List :

DAT23684RT COMPONENTS LIST			QTY
A	Table Top		1pc
B	Table Leaf		1pc
C	Trestle Bar		2pcs
D	Bottom Rail		1pc
E	Clamp Lock		4pcs

DAT23684RB COMPONENTS LIST			QTY
F	Leg Frame		2pcs
G	Adjustable Leveler		4pcs

NO	DESCRIPTION	SIZE	FIGURE	QTY
1	Long Bolt	Ø5/16"x 105mm		8pcs
2	Flat Washer	Ø5/16"x 19mm		12pcs
3	Spring Washer	Ø5/16"x 12mm		20pcs
4	Small Flat Washer	Ø5/16"x 14mm		8pcs
5	Short Bolt	Ø5/16"x 50mm		4pcs
6	Short Bolt	Ø1/4"x 75mm		8pcs
7	Allen Key	58x 23x 4mm		1pc
8	Wood Cap	Ø15.5x 10mm		8pcs

IMPORTANT NOTE:

- Please keep all hardware parts out of the reach of children.
- Two or more people are needed for assembly.

TIP: store the Allen key and or Wrench used in assembly in this product's drawer or use masking or painter's tape to affix it to the underside of the product. This will make it easier to find if you want to periodically tighten bolts or disassemble the product.

WINNERS ONLY®

ASSEMBLY INSTRUCTIONS

STEP 1:

- Attached Leg Frame (F) Trestle Bar (C): Long Bolt (1), spring washers (3), small flat washers (4), tighten by using allen key (7), Wood Cap (8) (Fig.2).
- Attached Leg Frame (F) Bottom Rail (D): Insert short bolts (5), spring washers (3), flat washers (2) tighten by using allen key (7) (Fig.1).

Fig.1






Fig.2



STEP 2: Open Clamp Lock (E), move Table leaf (B) go out and push Table Top (A) from both ends to close. Lock the Clamp Lock (E) underneath the Table Top (A) to prevent injury from sliding table top (A).



WINNERS ONLY®

ASSEMBLY INSTRUCTIONS

STEP 3: Attach the assembly base to the Table Top (A), insert Short Bolt (6), spring washers (3), flat washers (2) and tighten by using allen key (7) (Fig.3).





Fig.3



STEP 4:

- Turn the table to upright position. Unlock the Clamp Locks (E) underneath the Table Top (A). pull from both ends of Table Top (A).
- Place the Table Leaf (B) in position and push Table Top (A) from both ends to close. Lock the Clamp Lock (E) underneath the Table Top (A) to prevent injury from sliding table top (A).

