


MOE'S

home collection

ASSEMBLY INSTRUCTIONS.


GIGI FLOOR LAMP DARK BROWN

OD-1033-20



THANK YOU FOR YOUR PURCHASE!

PARTS AND HARDWARE.



NOTES.

All wires are connected. When unpacking be careful not to pull wires as a bad connection may result. Do not connect electricity until your lamp is fully assembled.

To reduce the risk of fire, electrical shock, or personal injury, always turn off lamp and allow it to cool prior to replacing light bulb.


Do not touch bulb when fixture is turned on or look directly at lit bulb.

Keep flammable materials away from lit bulb.

CAUTION: To prevent the risk of fire, do not use light bulbs with wattage greater than 7W LED.



STEP 1. TO ASSEMBLE

1. Carefully remove all parts from the box and remove all plastic covering.
2. Turn OFF power to the junction box where the lamp will be installed.
3. Insert the 7 Watt LED bulbs (Not Included) into threaded sockets.
4. Installation is complete.



STEP 2.

Tighten the holder ring clockwise



Do not use polishes or cleaners on your lamp.

USE DRY CLOTH TO CLEAN.