


Dimensions (in inches)



Height to top of door (in.) A	70-1/2
Height to top of hinge (in.) B	69-7/8
Height to top of case (in.) C	69
Case depth without door (in.) D	29-3/4
Case depth less door handle (in.) E	34-3/4
Case depth with door handle (in.) F	36-1/4
Depth with fresh food door open 90° (in.) G	48-3/4
Width (in.) H	35-3/4
Width with door open 90° with door handle (in.) I	44-5/8
Width with doors open fully (in.) J	68-1/4
Min distance between side of case and wall, in either direction, to allow doors to open fully (in.) K	16-3/8
Depth with FZ door completely open (w/o handle) (in.) X	51-7/8
Depth with FZ door completely open (w/ handle) (in.) Y	53-3/8