# **CINQ** Alarm Accessories



#### **Contact Sensor**

Secure each door and window, and get alerts as soon as they open.

Power: 2 CR2032 Batteries (included)

Connectivity: Z-Wave (250-ft range to Base Station open air, line of sight)

**Operating Conditions:** Indoor Use Only

**Setup Requirements** Ring Alarm or Ring Alarm Pro

### **Motion Detector**

Place in each room to get mobile alerts whenever motion is detected indoors.

Power: 2 AA Batteries (included)

**Connectivity:** Z-Wave (250-ft range to Base Station, open air, line of sight)

**Operating Conditions:** Indoor Use Only

**Setup Requirements** Ring Alarm or Ring Alarm Pro

	۲	۲	۲	
		2	3	
٢	4	5	6	
۲		8	9	
	×		0	
-	-	-	_	

#### **Keypad**

Add keypads to other areas to easily arm and disarm your Alarm system while indoors.

Power: AC Adapter, Internal rechargeable Lithium Ion Battery

Connectivity: Z-Wave (250-ft range to Base Station, open air, line of sight)

**Operating Conditions:** Indoor Use Only

**Setup Requirements** Ring Alarm or Ring Alarm Pro

#### **Range Extender** Extend the signal from the Alarm

Base Station to all components so entire system stays online.

Power: 100-120V 60Hz

**Connectivity:** Z-Wave (250-ft range to Base Station, open air, line of sight)

**Operating Conditions:** Indoor Use Only

**Setup Requirements** Ring Alarm or Ring Alarm Pro



#### **Glass Break Sensor**

Monitors glass windows and doors. Detects the sound of glass breaking up to 25 feet.

Power: 3 AA Batteries (included)

**Connectivity:** Z-Wave (250-ft range to Base Station open air, line of sight)

**Operating Conditions:** Indoor Use Only

**Setup Requirements** Ring Alarm or Ring Alarm Pro



#### **Outdoor Contact Sensor**

Secure outdoor gates, sheds and windows. Get mobile alerts or set sensor to automatically trigger siren Power:

2 AA Batteries (included)

Connectivity: Z-Wave (250-ft range to Base Station open air, line of sight)

**Operating Conditions:** Weather Resistant IP66

**Setup Requirements** Ring Alarm or Ring Alarm Pro

#### Flood & Freeze Sensor

Place near any water source and get alerts when water or low temperatures are detected.

Power: 3V Lithium Battery (included)

**Connectivity:** Z-Wave (250-ft range to Base Station open air, line of sight)

**Operating Conditions:** Indoor Use Only

Setup Requirements Ring Alarm or Ring Alarm Pro

#### Smoke & CO Listener

Place near existing smoke and carbon monoxide detectors to get alerts when their sirens sound.

Power: 3V Lithium Battery (included)

Connectivity: Z-Wave (250-ft range to Base Station open air, line of sight)

#### Setup Requirements

Ring Alarm or Ring Alarm Pro Mount next to existing smoke/CO alarm

## **Panic Button**

010

Press and hold the button for three seconds to sound the siren on your Alarm.

Power: 3V Lithium Battery (included)

Connectivity: Z-Wave (250-ft range to Base Station open air, line of sight)

**Operating Conditions:** Indoor Use Only

Setup Requirements Ring Alarm or Ring Alarm Pro



#### **Dome Siren**

Complement the siren in your Ring Alarm Base Station. Automatically sounds when Ring Alarm is triggered

Power: 2 CR123A Batteries (included)

**Connectivity:** Z-Wave (250-ft range to Base Station open air, line of sight)

**Operating Conditions:** Indoor Use Only

**Setup Requirements** Ring Alarm or Ring Alarm Pro

#### **Retrofit Alarm Kit**

Connect your existing wired contact security system to Ring Alarm.

2 x 3V Lithium Batteries (included)

Z-Wave (250-ft range to Base Station open air, line of sight)

**Operating Conditions:** Indoor Use Only

**Setup Requirements** Ring Alarm or Ring Alarm Pro

#### **Power Pack**

External backup battery for Alarm Pro and eero 6 Extenders. Delivers up to 8 hours of backup battery.

Power:

100 - 240V 50/60Hz AC Adapter (not included)

Connectivity: USB-C (included)

**Operating Conditions:** Indoor Use Only

**Setup Requirements** Ring Alarm Pro or eero 6 Extender

sensor zones from an existing

Power:

**Connectivity:**