

UTTERMOST

ASSEMBLY INSTRUCTIONS

21417

WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF WHILE POWER BEFORE INSTALLING OR SERVICING THIS FIXTURE.

We suggest a licensed professional electrician for installation

Installation Steps

1. Turn power off at fuse or circuit box before starting installation process.
2. Carefully unpack your new fixture and lay out all the parts on a clear surface.
3. First, carefully place the Cluster socket inside the Fixture body.
4. Thread the Bottom rod onto the Cluster socket as shown. Hand-tighten until snug.
5. As you thread the Cluster socket and the Bottom rod together, continuously pull the wires through the swivel of the Fixture body. Thread the Bottom rod onto the swivel of the Fixture body.
6. Screw swivel onto the Canopy if needed. If you don't need swivel, you can screw the stem to canopy directly. Adjust the length of the wire for your installation, remove excess. Determine the number of Stems to be assembled to the Fixture body as needed for your hanging height.
7. Thread the Ground screw into the hole of the Crossbar. Secure the Crossbar assembly to the outlet box with the Outlet box screws.
8. Make Wire connections with Wire Connector:
 - The Black Wire from fixture to Black Wire from power source.
 - The White Wire from Fixture to White Wire from power source.
 - Attach the Ground Wire and house ground wire to the Crossbar with the green Ground screw.
9. Carefully tuck wires back into the Outlet Box.
10. Attached the Canopy of the fixture body to the Crossbar assembly. Secure with the Mounting balls.
11. Install only LED light bulbs (Not Supplied) in accordance with the fixture's specifications. **DO NOT EXCEED THE MAXIMUM WATTAGE RATING!**

