


## UTTERMOST

Socket ring

Type A 40W (NOT INCLUDED)



Assembly Instruction

STYLE NO.: 29982-1

- 1. Take the parts carefully out of the carton, and place them on a flat surface, make sure that the parts will not be damaged.
- 2. Place the Metal Tube 1 on the Base and secure by turning in a clockwise direction.
- 3. Place the Metal shade on the socket and secure by socket ring.
- 4.Install 40 Watt, TYPE A bulb (NOT INCLUDED) into the socket of the fixture.

To clean, wipe with soft dry cloth.

NOTE: THE DRAWING OF THE LAMP BODY IS FOR REFERENCE ONLY.