DENON

AVR-1913 INTEGRATED NETWORK AV RECEIVER

Getting Started

Mise en route / Antes de empezar

ENGLISH

Welcome

Thank you for choosing a DENON receiver. This guide provides step-by-step instructions for setting up your receiver.

If you have setup problems:


If you need additional help in solving problems, contact DENON customer service in your area. See the address sheet included in the box.

1-855-MY.DENON

1-855-693-3666 Call for Assistance: 9:00AM to 8:00PM M-F E.S.T.

For frequency asked questions please visit www.usa.denon.com/FAQ.


Before You Begin




ENGLISH


Setup Steps

There are three steps to the setup process.











2 Connecting the receiver to your TV


□ Place the receiver near your TV.






Receiver

□ Connect the receiver to your TV with an HDMI cable.





Receiver (Rear panel)

❑ Turn on the TV.




□ Select the appropriate HDMI input on your TV.






TV remote control unit




TV remote control unit

❑ Turn on receiver.




• Turn on receiver as shown below.



ENGLISH


3 Follow the On-Screen Setup Assistant

The Setup Assistant will walk you through connecting and configuring your speakers and components to your DENON receiver. Please use the remote control and follow the on-screen instructions.



Owner's Manual

The included CD-ROM contains an Adobe PDF version of the full owner's manual for the AV receiver. Please reference this manual for more details about the setup and operation of the receiver and it's features.





FC Product Name : Integrated Network AV Receiver Model Number : AVR-1913



V00