

Pedestal Assembly Instructions

for SUMMIT® Refrigerator-Freezers CP35, FF71, FF73 and FFBF49A

Following the instructions below to mount the refrigerator correctly on the pedestal will keep your appliance from tipping forward.

NOTE: Do not move pedestal into its final location until the last step.

1. Mount Bracket 1 to the position on the floor where the refrigerator will eventually be placed.
2. Reverse Bracket 2 which has been pre-mounted to the pedestal.
3. Mount refrigerator over the lip at front of pedestal and under bracket 2 as shown below.
4. Adjust lip of pedestal and tighten 4 screws to hold it in place.
5. Slide pedestal into final location so that it fits under the prongs of Bracket 1.


This completes the assembly.



Rear of pedestal showing pre-mounted Bracket 2



Bracket 1 mounted to the floor



Bracket 2 reversed



Refrigerator mounted on pedestal and positioned under Bracket 1



Front legs of refrigerator are positioned behind lip of pedestal