

ITEM #81262

Chocolate Oak Mantel Height  
3-Shelf Bookcase with Drawer

**Leick**  
Home  
SINCE 1910


2219 S. 19th St.

Sheboygan, WI 53081






Ph: 920-451-4060

Fax: 920-451-4063

[info@leickhome.com](mailto:info@leickhome.com)









## Hardware List

	Item	Description	Qty
a		Bolt 1/4"x1-1/8"	8PCS
b		Flat Washer 1/4"x16mm	8PCS
c		Allen Wrench	1PC
d		Shelf Metal Clip	8PCS
e		Black Screw	2PCS

# Parts List

---


Item		Description	Qty
A		Top	1PC
B		Left Side Frame	1PC
C		Right Side Frame	1PC
D		Back Panel	1PC
E		Shelf Panel	2PCS
F		Bottom Panel	1PC

# Assembly Instructions

Two person assembly recommended.


## step 1

Open the drawer for fastening left side frame (B) and top with bolts. Tighten two bolts when the side frame front rail is flush with drawer front rails.




## step 2

Insert back panel (D) into left side frame groove. Align the left side frame (C) groove with back panel and fasten with bolts when the front rails are flush.




## step 3

Insert the bottom shelf and align the back panel into bottom shelf groove. Fasten the bolts when the bottom shelf front rail is flush with two side frames.




## step 4

Place the bookcase right side up and fasten the back panel with two screws (e).




## step 5

Insert shelf supports and place two adjustable shelves on shelf supports. Fasten the anti-tipping hardware onto pre-drilled holes at back of bookcase and wall.



### Furniture Tipping Restraint



Furniture Tipping Restraint must always be used to prevent serious harm or death to children.