



## GENERAL PRODUCT CARE

### Wood Products

#### CLEANING

- Use a damp cloth. Use a mild soap if necessary. Dry thoroughly after cleaning.
- Use caution when using commercial furniture polishes. Follow precautions listed by the manufacturer and test on a small inconspicuous area first.
- DO NOT use chemical cleaners or glass cleaners on finish. They may breakdown the finish.

#### MAINTENANCE/PRECAUTIONS:

- KD furniture should be tightened periodically to avoid breakage/damage. Avoid over tightening.
- To prevent fading, do not place product in direct sunlight.
- To prevent marking, do not write directly on surface.
- To prevent discoloring, do not use rubber-based place mats.
- To prevent damage to finish, do not place hot items directly on surface.
- To prevent splitting and checking, maintain even humidity conditions in your home or store (30 -40 % RH. @ 70 F). Also keep product away from direct sources of heat or forced air heating vents.
- To prevent swelling or de-lamination, do not allow liquids to remain on the finish, in or around decorative route lines.
- Furniture coasters under legs are recommended to protect floors and carpet.

Note: When product contains multiple materials (i.e. wood, metal, stone, etc.), please refer to the general care guidelines for each specific material.



MAGNUSSEN™  
H O M E

## GENERAL PRODUCT CARE

### Fossil Stone Product

#### CLEANING:

- On Polished Stone, use a damp cloth. Use mild soap if necessary. Dry thoroughly after cleaning.
- On rough stone, dust or vacuum with soft brush.
- DO NOT use chemical cleaners or glass cleaners on finish. They may stain the stone or finish.

#### MAINTENANCE / PRECAUTIONS:

- KD furniture should be tightened periodically to avoid breakage / damage. Avoid over tightening.
- To restore luster to polished stone, use very fine car polish or wax and buff. This will also protect the stone from stains.
- To remove stains or marks from rough stone, simply use fine wire brush.

#### CAUTION

- Make sure product is fossil stone and not cast plaster or fiberglass before using wire brush.
- To prevent fading, do not place product in direct sunlight.
- To prevent chipping or cracking, do not bang or drop the product or objects on product.
- To prevent damage to the stones, do not place hot items directly on the surface.
- Keep product away from direct sources of heat or forced air heating vents.
- To prevent swelling or de-lamination, do not allow liquids to remain on the finish or in or around decorative route lines. Maintain even humidity conditions in your home or store (30 - 40% RH @ 70 F).
- Our stone products ARE NOT intended for outside use.
- Furniture coasters under legs are recommended to protect floors and carpet.

Note: When product contains multiple materials (i.e. wood, metal, stone, etc.), please refer to the general care guidelines for each specific material.



MAGNUSSEN™  
H O M E

## GENERAL PRODUCT CARE

### Glass Product

#### CLEANING:

- Use a damp cloth. Use a mild soap if necessary. Dry after cleaning.
- Take precaution when using glass cleaners. Avoid cleaner contact with other finishes.

#### MAINTENANCE / PRECAUTIONS:

- KD furniture should be tightened periodically to avoid breakage /damage. Avoid over tightening.
- To prevent damage, do not place hot items directly on surface.
- To avoid scratches, do not use abrasive cleaners. Also use coasters under items placed on glass.
- Our glass products ARE NOT intended for outside use.
- To prevent chipping or cracking, do not bang or drop the product or objects on the product.

Note: When product contains multiple materials (i.e. wood, metal, stone, etc...), please refer to the general care guidelines for each specific material.



MAGNUSSEN™  
H O M E

## GENERAL PRODUCT CARE

### Brass Product

#### Cleaning

- Clean with warm soapy water such as a mild dish detergent that does not have a strong chemical base, along with a soft cloth or paper towel.
- Do not use brass polish or abrasives as this will harm/ remove the antiqued surface of the brass sinks.

#### Maintenance/Precautions:

- To prevent fading, do not place product in direct sunlight.
- To prevent chipping or cracking, do not bang or drop the product or objects on product.
- To prevent damage to the finish, do not place hot items directly on the surface.
- Keep product away from direct sources of heat or forced air heating vents.
- Furniture coasters under legs are recommended to protect floors and carpets.

Note: When product contains multiple materials (i.e. wood, metal, stone, etc.), please refer to the general guidelines for each specific material.



MAGNUSSEN™  
H O M E

## GENERAL PRODUCT CARE

### Marble Product

#### Cleaning

- On polished stone, use a damp cloth. Use mild soap if necessary. Dry thoroughly after cleaning.
- DO NOT use chemical cleaners or glass cleaners on finish. They may stain the stone or finish.

#### Maintenance/Precautions:

- KD furniture should be tightened periodically to avoid breakage/damage. Avoid over tightening.
- To restore luster to polished stone, use a very fine car polish or wax and buff. This will also protect the stone from stains.
  - To prevent fading, do not place product in direct sunlight.
  - To prevent chipping or cracking, do not bang or drop the product or objects on product.
  - To prevent damage to the stones, do not place hot items directly on the surface.
  - Keep product away from direct sources of heat or forced air heating vents.
  - To prevent swelling or de-lamination, do not allow liquids to remain on the finish or in or around decorative route lines. Maintain even humidity conditions in your home or store (30-40% RH @ 70F).
- Our stone products ARE NOT intended for outside use.
- Furniture coasters under legs are recommended to protect floors and carpets.



## GENERAL PRODUCT CARE

### Easy Leather Care

Because leather is a natural product, it needs little or no care during normal use. However, in the event that you have a spot or spill, the following cleaning hints should help.

#### Stain Removal Tips

**Spots and Spills:** Blot excess liquid immediately with a clean absorbent cloth or sponge. If necessary, use clear, lukewarm water and gently wipe the spill. Dry with a clean towel and allow to air dry.

**Stubborn Spots and Stains:** Use a mild solution of Ivory soap and clear, lukewarm water. Apply the soap to a clean, wet sponge, then rinse well and let air dry naturally. Always try the cleaning method in a hidden area first to be sure it's colorfast.

**Butter, Oil, or Grease:** Wipe excess butter, oil, or grease off the leather with a clean, dry cloth, and then leave it alone as the spot should dissipate into the leather in a short period of time. Do not apply water to try to wash a butter, oil, or grease stain.

Do not use saddle soap, abrasive cleanser, soap, furniture polish oil, varnish, or ammonia water. The leather has already been permanently preserved in the tanning process and needs no maintenance other than the simple cleaning recommended.

The leather will initially repel most liquids, but if left to stand over an extended period of time, they will be absorbed. This is why it's a good idea to wipe up spills immediately. If the spill is absorbed, it will dissipate over time, just as human skin will absorb and eventually diffuse stains.

To avoid fading, keep furniture away from direct sunlight

NOTE: These are suggestions in accordance with general cleaning industry procedures. We cannot guarantee favorable results, and we assume no liability in connection with their use. If necessary, seek professional cleaning assistance.