
INSTALLATION INSTRUCTIONS



Thinstall™ Steel Stud Adapter



TASMS/TAMMS

DISCLAIMER

Milestone AV Technologies and its affiliated corporations and subsidiaries (collectively "Milestone"), intend to make this manual accurate and complete. However, Milestone makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Milestone makes no representation of warranty, expressed or implied, regarding the information contained herein. Milestone assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.

Chief® and Thinstall™ are registered trademarks of Milestone AV Technologies. All rights reserved.

DEFINITIONS

MOUNTING SYSTEM: A MOUNTING SYSTEM is the primary Chief product to which an accessory and/or component is attached.

ACCESSORY: AN ACCESSORY is the secondary Chief product which is attached to a primary Chief product, and may have a component attached or setting on it.

COMPONENT: A COMPONENT is an audiovisual item designed to be attached or resting on an accessory or mounting system such as a video camera, CPU, screen, display, projector, etc.

WARNING: A WARNING alerts you to the possibility of serious injury or death if you do not follow the instructions.



CAUTION: A CAUTION alerts you to the possibility of damage or destruction of equipment if you do not follow the corresponding instructions.



IMPORTANT SAFETY INSTRUCTIONS

WARNING: Failure to read, thoroughly understand, and follow all instructions can result in serious personal injury, damage to equipment, or voiding of factory warranty! It is the installer's responsibility to make sure all accessories are properly assembled and installed using the instructions provided.

WARNING: Failure to provide adequate structural strength for this accessory can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the structure to which this accessory is attached can support five times the combined weight of all equipment. Reinforce the structure as required before installing the accessory. The wall to which the mounting system / accessory is being attached may have a maximum drywall thickness of 5/8" (1.6cm). Do not install drywall anchors into the seam between drywall pieces.

WARNING: Exceeding the weight capacity can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the combined weight of all components attached to this accessory does not exceed 50 lbs (22.67 kg) OR the weight capacity of the mounting system being used.



WARNING: Use this accessory only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.



WARNING: Never operate this accessory if it is damaged. Return the accessory to a service center for examination and repair.





WARNING: Do not use this accessory outdoors.

IMPORTANT!: The TASMS/TAMMS accessory is designed to be mounted to a 2" x 4"-25ga minimum steel studs wall. **IMPORTANT!**: The TASMS/TAMMS accessory is designed to mount Chief's Thinstall™ single stud wall mounting systems to a steel studs wall. Do not attempt to install any other mounting system to this accessory.

-- SAVE THESE INSTRUCTIONS--

DIMENSIONS







LEGEND

	Tighten Fastener	Pencil Mark
G	Apretar elemento de fijación	Marcar con lápiz
	Befestigungsteil festziehen	Stiftmarkierung
	Apertar fixador	Marcar com lápis
	Serrare il fissaggio	Segno a matita
	Bevestiging vastdraaien	Potloodmerkteken
	Serrez les fixations	Marquage au crayon
	Loosen Fastener	Drill Hole
	Aflojar elemento de fijación	Perforar
	Befestigungsteil lösen	Bohrloch
	Desapertar fixador	Fazer furo
	Allentare il fissaggio	Praticare un foro
	Bevestiging losdraaien	Gat boren
	Desserrez les fixations	Percez un trou
•	Phillips Screwdriver	Adjust
	Destornillador Phillips	Ajustar
	Kreuzschlitzschraubendreher	Einstellen
	Chave de fendas Phillips	Ajustar
	Cacciavite a stella	Regolare
	Kruiskopschroevendraaier	Afstellen
	Tournevis à pointe cruciforme	Ajuster
0	Open-Ended Wrench	Remove
	Llave de boca	Quitar
	Gabelschlüssel	Entfernen
	Chave de bocas	Remover
	Chiave a punte aperte	Rimuovere
	Steeksleutel	Verwijderen
	Clé à fourche	Retirez
	By Hand	Optional
	A mano	Opcional
	Von Hand	Optional
	Com a mão	Opcional
	A mano	Opzionale
	Met de hand	Optie
	À la main	En option
	Hex-Head Wrench	Security Wrench
	Llave de cabeza hexagonal	Llave de seguridad
	Sechskantschlüssel	Sicherheitsschlüssel
	Chave de cabeça sextavada	Chave de segurança
	Chiave esagonale	Chiave di sicurezza
	Zeskantsleutel	Veiligheidssleutel
	Clé à tête hexagonale	Clé de sécurité


TOOLS REQUIRED FOR INSTALLATION



PARTS



Site Requirements



Assembly And Installation

IMPORTANT!: The TASMS/TAMMS accessory is designed to mount Chief's Thinstall[™] wall mounting systems to a steel studs wall. Do not attempt to install any other mounting system to this accessory.

- Hold adapter plate (A) up to the wall on top of steel stud at desired mounting location. (See Figure 1) or (See Figure 2)
- Mark three hole locations. The middle hole to use will vary based on which mounting system is being used on the TASMS. (See Figure 1) or (See Figure 2)
- 3. Drill a 1/2" (12.7mm) hole at the desired mounting locations. (See Figure 1) or (See Figure 2)




Figure 1




Figure 2

 Hold metal channel on anchor (D) flat alongside plastic straps and slide channel through hole. (See Figure 3)




Figure 3

- Holding plastic straps on anchor (D), pull anchor away from wall until channel rests flush behind wall making sure anchor channel is positioned vertically on stud. (See Figure 4)
- Slide plastic cap on anchor (D) towards wall until flange of cap is flush with wall. (See Figure 4)




Figure 4

- Snap off plastic straps on anchor at wall by pushing side to side, snapping off straps level with flange of plastic cap. (See Figure 5)
- 8. Repeat Steps 3 through 7 for the other mounting hole.




Figure 5

- Place adapter plate (A) over anchors and align mounting holes on mount with holes in anchors. (See Figure 6) or (See Figure 7)
- Use two 1/4-20 x 1 3/4" Phillips pan machine screws (B), two screw caps (F) and two 1/4" washers (C) to secure adapter plate (A) to anchors (D) using top and bottom mounting holes. (See Figure 6) or (See Figure 7)




Figure 6




Figure 7

- 11. Use 1/4-20 hex nut (E) to secure Thinstall mounting system to adapter plate (A). (See Figure 8) or (See Figure 9)
- Use 1/4-20 x 1 3/4" Phillips pan machine screw (B) and 1/4" washer (C) to secure Thinstall™ mounting system to adapter plate (A). (See Figure 8) or (See Figure 9)




Figure 8




Figure 9

Install Thinstall™ mount to wall plate following Thinstall™ installation instructions.



Chief, a products division of Milestone AV Technologies

8800-002956 Rev01 ©2017 Milestone AV Technologies www.milestone.com 05/17 USA/International A 6436 City West Parkway, Eden Prairie, MN 55344

P 800.582.6480 / 952.225.6000

F 877.894.6918 / 952.894.6918

A Franklinstraat 14, 6003 DK Weert, Netherlands

P +31 (0) 495 580 852

F +31 (0) 495 580 845

Asia Pacific A Office No. 918 on 9/F, Shatin Galleria

Europe

18-24 Shan Mei Street

Fotan, Shatin, Hong Kong

P 852 2145 4099

F 852 2145 4477

