

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

552102

LOVESEAT

ITEM:552102

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

- 1.Remove wood legs from sofa bottom and sort by size.
- 2.Please check to see that parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME

6 MINUTES

PARTS IDENTIFICATION

A BASE



1PC

B WOOD LEG



4PCS

C L BACK CUSHION



1PC

D R BACK CUSHION




1PC

ITEM:552102




STEP 1





ITEM:552102




STEP 2



STEP 3 COMPLETE



ITEM: 552102



Note: Dimension tolerance $\pm 5\%$