



3979-SECT (37, 34) in leather 775-74



3979-SECT in Leather 654-01

FLEXSTEEL®

© Flexsteel Industries, Inc. | Last Updated 01/24

- Standard
- Optional



Connecting Clips


A connecting clip is attached to one sectional piece to allow the frame of a second piece to slide neatly down into the clip to secure the two pieces together.

3979 Westside Sectional | Components & Configurations


Leather Furniture

Components


LAF = Left-Arm-Facing
RAF = Right-Arm-Facing




-33
LAF Corner Sofa




-34
RAF Corner Sofa




-37
LAF Sofa




-38
RAF Sofa




-27
LAF Loveseat




-28
RAF Loveseat




-29
Armless Loveseat




-23
Full Wedge




-231
Corner Chair




-19
Armless Chair




-255
LAF Angled Chaise




-265
RAF Angled Chaise




-25
LAF Chaise



-26
RAF Chaise



-17
LAF Chair



-18
RAF Chair

Scale 1/4"=1'








Dimensions are in inches and are subject to variance.
© Flexsteel Industries, Inc. • Rev. 6/22
FLX-FR3979-CC-PP

FLEXSTEEL®

3979 Westside Sectional | Components & Configurations

Leather Furniture

Sample Configurations



Scale 1/4"=1'

Dimensions are in inches and are subject to variance.
© Flexsteel Industries, Inc. • Rev. 6/22
FLX-FR3979-CC-PP

FLEXSTEEL®