Assembly Instruction for DINING BENCH O-16230-3-BN

Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.

- 1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage the product or injury to persons during assembly.
- 2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
- 3. Please do not over tighten screws or bolts.
- 4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.


PART LIST							
No.	PART [PART DESC.		Q'Ty			
Α		Seat frame		1 pc			
В		Legs Frame	PO-16230-3-BNLEG	2 pcs			
С		Cushion	PO-16230-3-BNCOV PO-16230-3-BNCOR	1PC			


HARDWARE LIST							
No.	HARI	DWARE DESC.	CODE.	Q'Ty			
1		Bolt (ؽ" x 3¼ ")		16pcs			
2		Flat Washer (Ø ^{5/} ₁₆ " x ^{3 /} ₄ ")	PO-16230-DTHW	16pcs			
3		Allen Key (^{5/} 32 " x 2 ^{3/} 8 ")		1 pc			
4		Leveler($\frac{1}{4}$ " x_4^3 ")	PO-16230-LVL2	8 PCS			



STEP 1

Only tighten all bolts when all bolts aligned with bolt inserts.





* Note: Do not fully tighten Bolts until Step 2

COMPLETE