


PRODUCTION DIMENSION ---New A2 model for Decorative Panel




	Midea Standard	Midea A2 Panel Rdy	K Brand Panel Rdy	G Brand Panel Rdy	B Brand Panel Rdy
Depth	24-1/2"	24"	24"	23-1/2"	23-1/16"
Width	23-7/8"	23-7/8"	22-5/8"	23-3/4"	23-9/16"
Height	33-3/4"	33-3/4"	33-5/8"	32-1/4"	33-7/8"

**GOOD MODEL
(MDT24H3AST)**



VS

New A2 model





In many kitchens, you may have noticed appliances sticking out of cabinets for no reason. In these circumstances, the culprit is either:

- (a) *Poor product selection that is not suitable for the area or*
- (b) *Substandard installation*

Panel ready appliances need to be flush with cabinets.

Tip 1 - Product Selection - Know the depth of the dishwasher you are buying

In the US, the standard counter depth is 24 inches. Considering a standard panel is 3/4" thick, you would want your dishwasher to be shallower than 23 1/4". Taking into account an imperfect drywall, and considering hoses and wires that may end up lurking behind, it is best to have a dishwasher depth of 21 5/8" to a maximum depth of 23 1/6".

Almost all European-made dishwashers - Bosch, Miele, or [Asko dishwashers](#) - come with these dimensions, however, we cannot say the same for the US made dishwashers since they are generally deeper than their European counterparts. So, if your heart is set on a GE or [Whirlpool dishwasher](#) model, make sure to double check the product specs for depth.

<https://www.designerappliances.com/blog/panel-ready-dishwashers/>