

ASSEMBLY INSTRUCTIONS *COASTER FINE FURNITURE*



Fine Furniture for every stage of life

602501P
Power Sofa

ITEM :602501P



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.





WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective.Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 3 MINUTES


PARTS IDENTIFICATION

A	BASE		1PC
B	SUPPORT LEG		6 PCS
C	BACK		2 PCS
D	POWER CABLE		1 PC
E	LEG		4PCS


Z HARDWARE IDENTIFICATION

1	WRENCH		φ 0.6cm	1 PC
2	WASHER		φ 0.6cm	8PCS
3	BOLT		0.6cm	8 PCS


STEP 1




STEP 2




STEP 3




STEP 4



CONTROLLER INSTRUCTIONS





Note: Dimension tolerance $\pm$ 5%