




ASSEMBLY INSTRUCTION

Model : ASHLEY-BROWN-KB-HB LAMP & SPEAKER






Description : KING BED HEADBOARD
LAMP & SPEAKER


Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment.

PART LIST :

No.	Description	Diagram	Quantity
A	HEADBOARD		1
B	LEFT HEADBOARD LEG		1
C	RIGHT HEADBOARD LEG		1

HARDWARE LIST :

No.	Description	Diagram	Size	Quantity
D	JCBB SCREW		M8 x 40mm	6
E	SPRING WASHER		M8 x 15mm	6
F	FLAT WASHER		M8 x 22mm	6
G	ALLEN KEY		M5	1
H	ADAPTOR			1



ASSEMBLY INSTRUCTION

Description : KING BED-HEADBOARD LAMP & SPEAKER
-FOOTBOARD & SLATS
-SIDERAILS

Model : ASHLEY-BROWN-KB-HB LAMP SPEAKER-FB-KB-SR

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment.

PART LIST :

No.	Description	Diagram	Quantity
A	HEADBOARD LAMP & SPEAKER		1
B	FOOTBOARD		1
C	SIDE RAIL		2
D	WOODEN SLAT		3
E	WOODEN SUPPORT		6

HARDWARE LIST :

No.	Description	Diagram	Size	Quantity
F	JCBB SCREW		M8 x 25mm	8
G	SPRING WASHER		M8 x 15mm	8
H	FLAT WASHER		M8 x 22mm	8
I	ALLEN KEY		M5	1
J	CB SCREW		M4 x 32mm	6
K	SCREW DRIVER (*)			1

Lamp Touch Sensor :
i) Switch on
ii) Lighter
iii) More lighter
iv) Switch off

(*) The manufacturer does not provide item K.

