

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items and compare with the parts list and/or hardware list shown below.

STEP 1


PARTS LIST		
ITEM	DRAWING	DESCRIPTION QTY
1		HEAD BOARD 1 PC
2		FOOT BOARD 1 PC
3		HB LEG POST (L) 1 PC
4		HB LEG POST (R) 1 PC
5		SIDE RAILS 2 PCS
6		SLATS SUPPORT 4 PCS
7		WOODEN SLAT 4 PCS

HARDWARE LIST		
ITEM	DRAWING	DESCRIPTION QTY
A		JCBB (M8) 8 x 35MM (NYLOK) 4 PCS
B		Spring Washer M8 x22mm 4 PCS
C		Flat Washer M8 x 16 x 1.6mm 4 PCS
D		ALLEN KEY M5 5 x 35 x 120MM 1 PC
E		C.S.K. SCREW (M4) 4 x32mm 8 PCS

Screw Driver is not included



NOTE: MUST TIGHTEN SCREW PERIODICALLY WITH USE. SCREWS WILL BECOME LOOSE CHECK THIGHT OF ALL SREWS EVERY 6-8 WEEKS.




Step 1: Attach and tighten the leg posts (3 & 4) to the head board (1) by inserting JCBB bolt (A) with washers (B & C).

ASSEMBLY INSTRUCTIONS



B677W-315 ANDOVER 5/0 Q HEADBOARD, FOOTBOARD & SLATS-WHITE
 B677W-335 ANDOVER 5/0-6 /6 Q/EK SIDE RAILS-WHITE
 B677W-415 ANDOVER 4/6 F HEADBOARD, FOOTBOARD & SLATS-WHITE
 B677W-535 ANDOVER 3/ 3-4 /6 T/F SIDE RAILS-WHITE

B677B-315 ANDOVER 5/0 Q HEADBOARD, FOOTBOARD & SLATS-NUTMEG
 B677B-335 ANDOVER 5/0-6 /6 Q/EK SIDE RAILS-NUTMEG
 B677B-415 ANDOVER 4/6 F HEADBOARD, FOOTBOARD & SLATS-NUTMEG
 B677B-535 ANDOVER 3/ 3-4 /6 T/F SIDE RAILS-NUTMEG


STEP 2



STEP 3



COMPLETED ASSEMBLY



NOTE: MUST TIGHTEN SCREW PERIODICALLY WITH USE. SCREWS WILL BECOME LOOSE. CHECK TIGHT OF ALL SCREWS EVERY 6-8 WEEKS.