


ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

723267
END TABLE

REVISION 0 : 01/12/2021
REVISION 1 : 03/10/2021

ITEM:723267



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 30 MINUTES


PARTS IDENTIFICATION

A TOP GLASS
* thickness 8mm *




1PC

B FRAME




2PCS

C LEG



4PCS

D SHELF GLASS
* thickness 5mm *



1PC

HARDWARE IDENTIFICATION

1 SHORT BOLT
(3/16" x 12mm BLK)



16PCS

2 TOP CAP
(Ø15mm BLK)



4PCS

3 SUCTION CUP



8PCS

4 BOTTOM CAP
(Ø15mm BLK)



4PCS

5 ALLEN WRENCH
(4mm)



1PC


ITEM: 723267




ASSEMBLY INSTRUCTIONS

STEP 1

Do not tighten until each step is completed or instructed.




STEP 2




ITEM: 723267

ASSEMBLY INSTRUCTIONS

STEP 3



STEP 4




ITEM:723267

ASSEMBLY INSTRUCTIONS



Product Size : 648 DIA X 597 H (MM)

Product Size : 25.5" DIA X 23.5"



Note : Dimension tolerance $\pm 5\%$