C092-020-201 DINING TABLE LILLIAN

ASSEMBLY INSTRUCTIONS TWO (2) PEOPLE AND PHILIP WRENCH REQUIRED


UNPACK ALL PARTS AND CHECK AGAINST PARTS LIST ON THIS INSTRUCTION SHEET BEFORE DISCARDING PACKING AND CARTONING!!

- 1) Turn the Top / Apron Assembly (1) face down on a smooth, clean surface.
- 2) Attach the leg (3) to the Top / Apron Assembly (1) using flat washers (C), lock washers (B) and bolts (A) tighten with wrench provided (D) as shown in (Drawing A).
- 3) Using two people carefully return the table to the upright position. Then place the numbered leaves in the table as shown in (Drawing B).
- 4) Connect the center leg (4) with the mounting plate using Flat washer (C), Lock washer (B), and the nut (F), tighten with the wrench provided (D) as shown in (Drawing C).
- 5) Turn the Center leaf on a smooth, clean surface then attached the center leg & mounting plate assembled to leaf using Lock washer (B), Flat washer (C) and bolt (A), tighten with wrench provided (D) as shown in (Drawing D)
- 6) Put the center leaf in the table and line up the side panel and leaves properly then tighten the entire locks. (note: please adjust the floor glide on the center leg if necessary)

*** NOTE KEEP THIS SHEET!!! ***

In the unlikely event that you would need a replacement part for your furniture, please contact your local authorized Caracole International dealer. If you need replacement hardware quickly, it could be purchased from your local hardware store.

C092-020-201 DINING TABLE	QTY
	QTY
20.004.40400	QTY
20.004.40400	
20-201-40123	1
20-201-4060	3
20-201-40150	8sets
20-201-4018	4
20-201-40349	1
20-201-40151	1
20-201-4006	5
20-201-4001	1
20-201-4075	1
	20-201-40123 20-201-4060 20-201-40150 20-201-4018 20-201-40349 20-201-40151 20-201-4006 20-201-4001 20-201-4075



Created on:2021-9-28

