

# ASSEMBLY INSTRUCTION INSTRUCCIONES

# 2430SET-LG / 2430SET-P TABLE 2430SET-LG / 2430SET-P MESA


## PARTS LIST LISTA DE PARTES

A		1 PC/PIEZA
B		4 PCS/PIEZAS


①		OPEN WRENCH Ø12	1 PC/PIEZA
②		NUT Ø5/16"	8 PCS/PIEZAS
③		LOCK WASHER 5/16"*13mm	8 PCS/PIEZAS
④		FLAT WASHER 5/16"*19mm	8 PCS/PIEZAS

## ASSEMBLY INSTRUCTION INSTRUCCIONES

### Step 1



### Step 2




DO NOT TIGHTEN ALL BOLTS UNTIL COMPLETELY ASSEMBLED.  
NO APRETER LOS TORNILLOS HASTA ARMAR COMPLETAMENTE.

# ASSEMBLY INSTRUCTION INSTRUCCIONES

# 2430SET-LG / 2430SET-P- CHAIR 2430SET-LG / 2430SET-P- SILLA


## PARTS LIST LISTA DE PARTES

C		1 PC/PIEZA
D		1 PC/PIEZA
E		2 PCS/PIEZAS


⑤		BOLT 1/4''*20*3-1/8'' (chair back leg corner)	4 PCS/PIEZAS
⑥		BOLT 1/4''*20*2-5/8'' (front leg)	4 PCS/PIEZAS
⑦		BOLT 1/4''*20*1-1/2'' (chair back center)	1 PC/PIEZA
⑧		ALLEN KEY Ø1/4*2-1/4''	1 PC/PIEZA

## ASSEMBLY INSTRUCTION INSTRUCCIONES


Step 1




Step 2



Step 3



Step 4



DO NOT TIGHTEN ALL BOLTS UNTIL COMPLETELY ASSEMBLED.  
NO APRETER LOS TORNILLOS HASTA ARMAR COMPLETAMENTE.