

Furniture of America[®]

ASSEMBLY INSTRUCTIONS







VERSION #24-04-30

MODEL

FM-BK629

Questions?

GIVE US CALL: 1-888-980-5122 MON-FRI 8:30AM - 5:30PM (PST)

TOOLS REQUIRED



Screwdriver (Not included)



Allen Wrench



2 - People





The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.





Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



PRE ASSEMBLY

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



















Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.

Suitable Location

Assembling near the area of the intended location is highly recommended.

Sufficient Space

Make sure you have enough space to move around during the assembly.

Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.

Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.





Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Save the instructions and store any supplied tools for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE. TO SUPPORT ITS INTENDED WEIGHT CAPACITY, THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.



 Please keep instructions for future reference.

 Check the quantity and irregularity of parts and hardware before you start.



PARTS





$\textcircled{\ }$	B	©	D
			<***************
Bolt Ø1/4" x 3-1/8" 16 PCS.	Bolt Ø1/4" x 1-1/2" 22 PCS.	Bolt Ø5/16" x 2-3/8 8 PCS.	Screw #4 x 35mm 58 PCS.
E	F	G	H
Bolt	Nut	Matal David	
Ø1/4" x 1" 9 PCS.	Ø1/4" x 1" 11 PCS.	Metal Dowel 9 x 3-1/2" 4 PCS.	Allen Wrench 4mm 2 PCS.
CIIIIII)			
Wood Dowel 40 x 10 x 10 2 PCS.			

Exploded View



CM-BK629 is packed in 4 cases

Carton	Disignation		Part	Hardware
CM-BK629-1	Left Headboard Frame	#1		
	Right Headboard Frame	#2		
CM-BK629-2	Left Footboard Frame	#3		() ()
	Right Footboard Frame	#4	[]	F : 22PCS G : 4PCS H : 2PCS H : 2PCS H : 2PCS
	Upper Front Side Rail	#5	()	
	Upper Back Side Rail	#6	l a ; ; /	
	Lower Front Side Rail	#7	/	
	Lower Back Side Rail	#8	(4 <u></u>	
CM-BK629-3	Back Guardrail	#9		
	Front Guardrail	#10		
	Guardrail Support	#11	()	
	Guardrail Attachment	#12	<u>(11 ca ce</u>)	
	Ladder Rail (Right)	#13		
	Ladder Rail (Left)	#14	· · · · · · · · · · · · · · · · · · ·	
	Ladder Rung	#15		

CM-BK629 is packed in 4 cases

Carton	Disignation	Part		Hardware
	Bottom Ladder Rung	#16		
	Corner Ladder	#17		
	Corner	#18		
CM-BK629-4	Twin Slat Kit	#19		
	Full Slat Kit	#20		
	Support Leg	#21	↔	











This product is intended for RESIDENTIAL USE ONLY and not for commercial use.

Safety Warnings for Bunk Beds

- Read and follow the information on the WARNING labels shown on the end structure of the upper bunk and on the carton.
- 2. Do not remove warning labels from the bed.
- 3. Keep these instructions for future use.
- 4. IMPORTANT: Must use Bunkie mattress or Bunkie board. The proper sizes for the UPPER/LOWER TWIN-SIZE Bunkie mattress or Bunkie board should be 74"- 75" long and 37 ½"- 38 ½" wide with no more than 6" thickness and for the UPPER/LOWER FULL –SIZE should be 74"-75" long and 53" – 54" wide with no more than 6" thickness.
- 5. Surface of mattress must be at least 5 inches (127 mm) BELOW the upper edge of the guardrails.
- 6. The MAXIMUM weight capacity for the upper bunk is not to exceed 150 lbs.
- 7. Do not allow children under 6 years of age to use the upper bunk.
- Periodically check and ensure that the guardrails, ladder, handle and other components are in their proper position, free from damage, and that all connectors are tightened and secured.
- DO NOT allow horseplay, rough playing, or jumping on the beds and do not allow playing or hiding under the beds.
- 10. Always use the ladder for entering or leaving the upper bunk.
- 11. Do not use substitute parts. Contact the manufacturer or dealer for replacement parts.
- 12. Use of a nightlight may provide added safety precaution for a person using the upper bunk.
- 13. Always use the guardrails on both sides of the upper bunk.
- 14. If the bunk bed will be placed next to a wall, the guardrail that runs the full length of the bed should be placed against the wall to prevent entrapment between the bed and the wall.
- 15. The use of water or sleep flotation mattresses is prohibited.
- 16. No more than one person is allowed on the upper bunk at all times.



Objects such as, but not limited to, hanger, hooks, belts, bag, rope strings, etc. should not be hanged or used on or around the bunk bed.

Replacement Parts:

Replacement parts may be obtained from your Furniture of America dealer.

Distributed by: Furniture of America 680 S. Lemon Avenue City of Industry, CA 91789