









43UP7100ZUF
43UP7670PUC





43UP71*




43UP76*





A, B, C, D, E : mm (inches / pulgadas / po)
F, G : kg (lbs / libras / lb)



MODELS MODELOS MODÈLES	A		B		C		D		E		F		F - G		Power consumption
															Consumo de potencia
															Consommation électrique
43UP7100ZUF	973	973	611	611	187	187	572	572	85.0	85,0	8.1	8,1	8.0	8,0	110 W
	(38.3)	(38,3)	(24.0)	(24,0)	(7.3)	(7,3)	(22.5)	(22,5)	(3.3)	(3,3)	(17.8)	(17,8)	(17.6)	(17,6)	
43UP7670PUC	967	967	609	609	187	187	564	564	57.1	57,1	8.9	8,9	8.8	8,8	110 W
	(38.0)	(38,0)	(23.9)	(23,9)	(7.3)	(7,3)	(22.2)	(22,2)	(2.2)	(2,2)	(19.6)	(19,6)	(19.4)	(19,4)	
Power requirement / Alimentación requerida / Alimentation										AC 120 V- 50/60 Hz					



ENGLISH Read **Safety and Reference**.
ESPAÑOL Leer **Seguridad y Consultas**.
FRANÇAIS Lisez **Sécurité et références**.

ENGLISH
Easy Setup Guide
Please read this manual carefully before operating your set and retain it for future reference.

ESPAÑOL
Guía Rápida de Configuración
Lea atentamente este manual antes de poner en marcha el equipo y consérvelo para futuras consultas.

FRANÇAIS
Guide de configuration rapide
Avant d'utiliser l'appareil, veuillez lire attentivement ce manuel et le conserver pour pouvoir vous y reporter ultérieurement.

⊕ : Depending upon model / Según el modelo / Selon le modèle