













ITEM NAME/NOM D'ITEM: TRIPICANA DINING CHAIR/SERENE DINING CHAIR
ITEM #/NO. ITEM: 704032/704033


PARTS LIST/LISTE DES PIÈCES

(1)	(2)	(3)	(4)
 x1	 x1	 x1	 x1
(5)	(6)	(7)	
 x1	 x1	A. M6 x 50MM  x8 B. Ø20MM  x8 C. M6 x 25MM  x1 D. M5 x 60MM  x4 E. PLASTIC PLUGS  x9 F. 4MM  x1	
NOTE: You will need to supply your own Phillips-head screwdriver. 			


ASSEMBLY INSTRUCTIONS / INSTRUCTIONS D'ASSEMBLAGE

I	Tools required	II	Tools required
 		  	


III



Tools required



IV



For missing parts or damaged parts, please call /
Pour pièce manquante ou endommagée, veuillez appeler:

USA, Canada and Mexico: (866)-798-6663

AI-V1-231201