




# *ASSEMBLY INSTRUCTIONS*

## *COASTER FINE FURNITURE*



*Fine Furniture for every stage of life*

# 753447

## End Table

ITEM: **753447**



## ASSEMBLY INSTRUCTIONS

### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

## PARTS IDENTIFICATION

A	TOP		1PC
B	PEDESTAL COLUMN		1PC
C	BASE		1PC

## HARDWARE IDENTIFICATION


1	<b>SHORT BOLT</b> (5/16" x 1 1/4" - RBW)		4PCS
2	<b>LONG BOLT</b> (5/16" x 2 1/2" - RBW)		2PCS
3	<b>SMALL LOCK WASHER</b> (1/4" - RBW)		4PCS
4	<b>SMALL FLAT WASHER</b> (1/4" - RBW)		4PCS
5	<b>BIG LOCK WASHER</b> (5/16" - RBW)		2PCS
6	<b>BIG FLAT WASHER</b> (5/16" - RBW)		2PCS
7	<b>ALLEN WRENCH</b> (4MM - RBW)		1PC

ITEM: **753447**


## ASSEMBLY INSTRUCTIONS




### STEP 1




### STEP 2



### STEP 3 COMPLETE



ITEM: **753447**



**NOTE:** Dimension tolerance + 5%