








ZUO®


ITEM NAME/NOM D'ITEM: BULLY LOUNGE CHAIR

ITEM # /NO.ITEM: 100534A/100535A/100536A

PARTS LIST / LISTE DES PIÈCES


1	2	3	8
 x 1	 x 1	 x 1	A.  M8X60MM x 4 B.  M8X17MM x 8 C.  M5 x 1 D.  M10X40MM x 6 E.  M8X18MM x 4 F.  x 6 G.  M8X80MM x 2 H.  M4X45MM x 3 I.  x 4 J.  M6X45MM x 2 K.  M6 x 2 L.  M4 x 1
4	5	6	7
 x 1 (finger)	 x 1 (finger)	 x 1 (flat)	 x 2

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS D'ASSEMBLAGE




zuo®

III



IV



For missing parts or damaged parts, please call

USA

1-866-798-6663



Canada

514-382-6661

AI-4-171115


ITEM NAME/NOM D'ITEM: BULLY OTTOMAN
ITEM #/NO. ITEM: 100534B/100535B/100536B

PARTS LIST/LISTE DES PIÈCES


(1)	(2)	(3)	(4)
 x1	 x2	 x2	A.  M6 x L45mm x4
			B.  M6 x4
			C.  M4 x L32mm x4
			D.  M6 x4
			E.  10 x L40mm x8
			F.  PASTE PAD x4
			G.  6mm x1

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS D'ASSEMBLAGE

I



II



III

