



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

509173

CHAIR

REVISION 0: 03/11/2022
REVISION 1: 07/18/2022

PAGE 1 OF 4

COASTERFURNITURE.COM

ITEM : 509173



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A

CHAIR



1PC

B


LEG



4PCS


C

PATTERNED PILLOW




1PC


ITEM : 509173
ASSEMBLY INSTRUCTIONS
STEP 1




STEP 2



STEP 3



ITEM : 509173



NOTE: Dimension tolerance $\pm 5\%$

