



3902-51H in Leather 577-70



Power Rocking Recliner with Power Headrest
3902-51H in 824-90



Power Rocking Recliner with Power Headrest
3902-51H in 824-90

FLEXSTEEL®

© Flexsteel Industries, Inc. | Last Updated 11/15/2023

- 53

51M

51H

51

50M

50H

50
- FEATURES
- Flexsteel Spring Unit

● DualFlex

Back Construction

● Attached

Seat Construction

● Attached

Seat Cushion(s)

● High-Density (HC)

- Standard
- Optional

PRODUCT DIMENSIONS	OVERALL			SEAT			Arm Height	Open Depth	Wall Clearance
	Height	Width	Depth	Height	Width	Depth			
Swivel Gliding Recliner -53	41"	37"	40"	20"	22"	22"	25"	67"	15"
Power Rocking Recliner -51M	41"	37"	40"	20"	22"	22"	25"	67"	15"
Power Rocking Recliner with Power Headrest -51H	41"	37"	40"	20"	22"	22"	25"	67"	15"
Rocking Recliner -51	41"	37"	40"	20"	22"	22"	25"	67"	15"
Power Recliner -50M	41"	37"	40"	20"	22"	22"	25"	67"	5"
Power Recliner with Power Headrest -50H	41"	37"	40"	20"	22"	22"	25"	67"	5"
Recliner -50	41"	37"	40"	20"	22"	22"	25"	67"	5"

NOTES

Available in more than 99 leather options
Also available in Kashmira fabric
Removable backs allow for easy lifting and maneuvering through doorways.
Swivels a full 360 degrees.
Glides or reclines from any swivel position.
Swivels in all directions while reclined.
Safety locks prevent the recliner from gliding while reclining.
Power mechanism allows you to smoothly recline to any position.
Power headrest mechanism allows you to adjust the headrest.
Two power buttons allow you to operate the reclining and headrest mechanisms independently.
Single USB port is included on the power button control.
Safety locks prevent the recliner from rocking while reclining.
Safety locks prevent the furniture from rocking while reclining
Removable backs allow for easy lifting and maneuvering through doorways
The power control allows you to independently adjust the recline and headrest.
A separate home button returns the headrest and footrest to their original positions with one touch.
A USB port is included on the power control for powering electronics.
Zero draw technology only uses power when the USB port is in use.
Lower the footrest by applying pressure to it in a downward motion. Lowering the footrest with the handle can damage the recliner.
Power allows you to smoothly recline to any position.
A single USB port is included on each power button control on styles with arms.



Power Recline
& Headrest