

















Metal Chair
CO1025







PART LIST

A 	B 	C 	D 	E 
Chair Back 1 PC	Chair Seat 1 PC	Left Support Leg 1 PC	Right Support Leg 1 PC	Leg Connector 1 PC

HARDWARE LIST

#1  M6X13mm	#2  M6X42mm	#3 	#4 	#5 
Bolt 4 PCS	Long Bolt 4 PCS	Hex Nut 8 PCS	Flat Washer 12 PCS	Plastic Washer 4 PCS
#6 	#7 	#8 		
Wrench 1 PC	Allen Wrench 1 PC	Round Plastic Washer 4 PCS		


EXTRA HARDWARE LIST

#1  M6X13mm	#2  M6X42mm	#3 	#4 
Bolt 1 PC	Long Bolt 1 PC	Nut 2 PCS	Flat Washer 4 PCS


IMPORTANT NOTE: WE RECOMMEND TWO PEOPLE WORK TOGETHER TO ASSEMBLE THE CHAIR

Step 1. Lay chair back (part A) down on a soft flat surface, such as carpet, as shown below. Attach chair seat (part B) to chair back (part A) using bolts (part #1), flat washers (part #4), nuts (part #3), wrench (part #6) and allen wrench (part #7).

NOTE: Please do not fully tighten bolts until unit is fully assembled.



Step 2. Attach left support leg (part C) and right support leg (part D) to leg connector (part E).



Step 3. Attach support legs (parts C & D) to chair back (part A) and chair seat (part B) using long bolts (part #2), Round Plastic Washer (part #8), and flat washers (part #4), plastic washers (part #5), nuts (part #3), wrench (part #6) and allen wrench (part #7) .

NOTE: Please fully tighten all bolts at this time.

