



Furniture of America®


ASSEMBLY INSTRUCTIONS

MODEL #

CM5510-PC-RIGHT

Questions?

GIVE US A CALL: 1-888-980-5122
MON – FRI 8:30AM – 5:30PM (PT)



TOOLS REQUIRED



Allen Wrench
(Included)



Phillips
Screwdriver
(Not Included)



2 - People
Recommended

ASSEMBLY RATING



EASY → DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



FOA Intro

Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific Time and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



Consumer Hotline
Toll-Free 1-888-980-5122



WEBSITE
www.foagroup.com



Monday to Friday
8:30AM- 5:30PM (PT)



E-MAIL
cs.ec@foagroup.com



foagroup



FurnitureOfAmerica



CHECK BEFORE STARTING



Are you missing anything?

Double-check all parts, hardware and accessories listed are all accounted for.



Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!



Should we send any replacements?

Are there any irregularities or flaws in the parts? We can send replacements!




Prep Time!

Please review the assembly instructions and all diagrams prior to assembling.



PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.




Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.




Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly
and insert screws or bolts into
their respective holes.



Turn clockwise to tighten and
only tighten when step is
completed or when instructed
to do so.



Use the appropriate hand tools
or power tools for assembly.
Select steps, such as tightening
screws and/or bolts, may require
hand tools to avoid causing
damage during assembly.



Save the instructions and store
any supplied tools for later
maintenance.





After two weeks, check and
tighten any loose hardware and
repeat again every six months
thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN
OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS
INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

PIER

CM5510-PC-RIGHT




PARTS

#14 1pc




Right Post A

#15 1pc



Right Post B

#16 1pc



Right Post C

#17 6pcs




Right Arc
Tube

#18 2pcs



Right Connection
Tube 1

#19 2pcs



#20 1pc



Right Top
Glass

#21 3pcs




Right Middle
Glass

#22 2pcs




Right
Bottom Glass

#23 1pc



Right Upper
Panel

#24 1pc



Right
Lower Panel

#25 2pcs



Right
Clamp A


#26 2pcs



Right
Clamp B


HARDWARE

#A 12pcs




Bolt $\phi 1/4" \times 2-1/2"$
Black

#B 6pcs



Bolt $\phi 1/4" \times 7/8"$
Black

#C 2pcs




Bolt $\phi 1/4" \times 5/8"$
Black

#D 3pcs



#E 10pcs



Mandrel screw
 $1/4" \times 1-3/16"$

#F 10pcs




Suction cup

#G 2pcs



Bracket

#H 1pc




Anchors

#J 1pc

#K 1pc

#L 1pc

#M 5pcs



Restraint strap
(280mm)

Screw
(M4x37mm - White)

Allen Key
(4x22x60mm - White)

Phillips Bolt
(3/16"x1/2 - Black)

#N 5pcs




Glass Clip

ASSEMBLY INSTRUCTIONS

1

Part #16 x1pc
Part #19 x2pcs
Hardware #B x2pcs
Hardware #L x1pc




Align the right connection tube 2 (#19) to right post C (#16), then secure by using bolts (#B).

Note:
Do not fully tighten all bolts until assembly is complete. This will help all parts to assemble properly.

2

Part #14 x1pc
Part #15 x1pc
Part #17 x3pcs
Part #23 x1pc
Part #24 x1pc
Hardware #A x12pcs
Hardware #L x1pc




Align the right arc tubes (#17) to the outside of the right posts (#14,15), align the right panels (#23,24) to the inside of the right posts (#14,15) as shown in the diagram, then secure by using bolts (#A).

ASSEMBLY INSTRUCTIONS

3

Part #18 x2pcs


Align the right connection tube 1 (#18) to the inside of the right post A (#14) through the middle hole on the right side of the right panels (#23,24) as shown in the diagram.



4

Hardware #B x4pcs
Hardware #G x1pc
Hardware #L x1pc

Align the right post C (#16) to right connection tube 1 (#19) as shown in the diagram, then secure by using bolts (#B) with bracket (#G).




Align the right connection tube 2 (#19) to the inside of the right post B (#15), shown in the diagram, then secure by using bolts (#B).

Keep pier vertical and then tighten screws

ASSEMBLY INSTRUCTIONS

5


Hardware #D x3pcs
 Hardware #E x10pcs
 Hardware #F x10pcs
 Hardware #M x5pcs
 Hardware #N x5pcs



6

Part #21 x1pc
 Part #22 x3pcs
 Part #23 x2pcs
 Hardware #L x1pc

Align the suction cups (#F) to mandrel screws (#E), then secure into right posts (#14,15) as shown in the diagram.



ASSEMBLY INSTRUCTIONS


6

Part #25 x2pcs

Part #26 x2pcs

Hardware #C x2pcs


Hardware #L x1pc



Note:

Please follow this step when you want to assemble with CM5510-TV together.

Align the right PIER to TV STAND (CM5510-TV) as shown in the diagram, then secure by using clamp (#25,26) with bolts (#C).




7

Hardware #G x1pc

Hardware #H x1pc

Hardware #K x1pc




Locate the anchors (H), bracket (#G) on the wall over a wall stud and 2 inches below the bracket (#G) secured to the back of tv stand. Attach the wall stud using the screw (#K) provided, through the smaller hole.

ASSEMBLY INSTRUCTIONS

8

Hardware #J x1pc

Place the furniture into position so both brackets (#E) are vertically in line. Lace the end of the restraint strap (#G) through the larger hole in each bracket (#E). Bring both ends together and slide the flat end through the locking end and draw it through until all slack is removed. Confirm that the strap is securely laced and locked.



ASSEMBLY COMPLETED

Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

TO PREVENT TIP OVER
PRODUCT MUST BE
ATTACHED TO WALL

✓ **Keep this handy!**

Please retain this instruction manual and any order-related information for future reference.

✓ **Lift, don't drag!**

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.


ASSEMBLY INSTRUCTIONS

Wall Mounting and Fixing



EXPANSION WALL ANCHOR

Our provided expansion wall anchors are only suitable for masonry walls, such as drywall, plaster or concrete, and are best for holding lightweight items or for anti-tip prevention. If you are unsure of the correct wall anchor to use with the product, please request professional guidance. Liability for product damage or failure due to using the incorrect anchors will fall on the installer.




CHECK BEFORE PROCEEDING


Prior to drilling or hammering, please check for wires or pipes. We recommend using a stud finder to locate a stud, which will offer more appropriate resistance and hold more weight.

QUICK TIPS


1. If unsure of the proper size, always choose a larger screw and wall anchor.




2. Match the drill bit to the wall anchor and hole size.



3. Only drill horizontally. Do not force the drill or enlarge the hole for the wall anchor.



4. Take extra care when drilling into high walls or ceramic tiles. Wall anchors should be a tight fit for the hole. Never use wall anchors in ceilings.



MAINTENANCE



We recommend a yearly check to see if the wall anchor or screw has loosened. If so, please remove the existing wall anchor and screw, and use a new anchor.