


**Furniture of America**<sup>®</sup>

# Assembly Instructions

For more information contact our team: [service.ec@foagroup.com](mailto:service.ec@foagroup.com)

## CM7552Q



### ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.

### Tools Required For Assembly:

Allen Wrench



(Included)

Phillips Screwdriver



(Not Included)

EASY



DIFFICULT




**2 PERSONS RECOMMENDED**

# ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


## BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.



Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor. No dragging of products/parts.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.



Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.




**FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.**






Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.


**Parts List (Box 1) Headboard Box**

-  #1 x 1pc  
Headboard
-  #2 x 1pc  
Footboard
-  #3 x 2pcs  
Headboard Leg L/R


**Parts List (Box 2) Side Rail Box**

-  #4 x 2pcs  
Side Rail
-  #5 x 1pc  
Center Slat Drawer
-  #6 x 3pcs  
Bed Slat w/o marking  
1545 x 45 x 18mm
-  #7 x 2pcs  
Bed Slat with marking  
1545 x 45 x 18mm
-  #8 x 5pcs  
Bed Slat Support  
320 x 30 x 30mm
-  #9 x 1pc  
Drawer Slat Support  
95 x 30 x 30mm
-  #10 x 2pcs  
Drawer Support Rail  
633 x 40 x 20mm
-  #11 x 5pcs  
Concealed Panel  
2040 x 295 x 9mm




**Parts List (Box 3) Drawer Box**

-  #12 x 2pcs  
Footboard Drawer

**Hardware List (Box 1) Headboard Box**

-  #A x 6pcs  
Bolt 1/4" x 1-2/8"
-  #B x 6pcs  
Lock Washer
-  #C x 6pcs  
Flat Washer
-  #D x 1pc  
Allen Key m4

**Hardware List (Box 2) Side Rail Box**



-  #E x 2pcs  
Bolt 1/4" x 1-3/8"
-  #F x 6pcs  
Bolt 1/4" x 2"
-  #G x 2pcs  
Lock Washer
-  #H x 2pcs  
Flat Washer
-  #I x 1pc  
Allen Key m4
-  #J x 1pc  
Allen Key m5
-  #K x 14pcs  
CSK m4 x 32mm
-  #L x 25pcs  
P.H Screw m3.5x20mm



#1



Prepare 6 bolts assembly by inserting lock washer (#B), then flat washer (#C) onto bolts (#A).  
Align HB legs (#3R/L) to the holes of the headboard (#1). Secure by using bolts (#A).

#A x 6pcs  
#B x 6pcs  
#C x 6pcs



#2

1) Loosen the bolts attached to headboard (#1) and footboard (#2), then hook the side rails (#4) to the loosened bolts on the headboard (#1) and footboard (#2).  
2) Tighten the bolts on the headboard (#1) and footboard (#2) to the side rail hooks (#4).






#3

Align center slat drawer (#5) to the side rails (#4), then secure by using screws (#K).

#K x 2pcs




x 2

#4

#K


#5



#4

Align support leg (#9) to the hole of the center slat drawer (#5), then adjust leveler of the support leg (#9) according to ground level.

#F x 1pc




x 1

#1

#F

#5


#9






- #E x 2pcs
- #G x 2pcs
- #H x 2pcs
- #K x 2pcs

Prepare 2 bolts assembly by inserting lock washer (#G), then flat washer (#H) onto bolts (#E). Align drawer support rail (#10) to the holes of the footboard (#2) and center slat (#5). Secure drawer rail (#10) to center slat (#5) by using bolts (#E), then secure drawer rail (#10) to footboard (#2) by using screws (#K).




Unscrew knobs on the inside, then secure knobs to the outside of the drawers (#12).







#7

#F x 5pcs



Align slat support (#8) to the hole of the bed slat without marking (#6). Secure by using bolts (#F).

Align slat support (#8) to the holes of the bed slat with marking (#7). Secure by using bolts (#F).





Align slats (#6,7) to the side rails (#4).



#8

Secure slats (#6,7) by using screws (#K).

#K x 10pcs



#4




MARKING LINE





#9

Align concealed panel (#11) to the slats (#6,7). Secure by using screws (#L).


#L x 25pcs




Please see diagram in steps 10.



ASSEMBLY COMPLETED






**Furniture of America**<sup>®</sup>

# Assembly Instructions

For more information contact our team: [service.ec@foagroup.com](mailto:service.ec@foagroup.com)

## CM7552EK



### ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.

### Tools Required For Assembly:

Allen Wrench



(Included)

Phillips Screwdriver



(Not Included)

EASY



DIFFICULT




**2 PERSONS RECOMMENDED**

# ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


## BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.



Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor. No dragging of products/parts.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.



Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.




**FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.**




Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.


**Parts List (Box 1) Headboard Box**

-  #1 x 1pc  
Headboard
-  #2 x 1pc  
Footboard
-  #3 x 2pcs  
Headboard Leg L/R


**Parts List (Box 2) Side Rail Box**

-  #4 x 2pcs  
Side Rail
-  #5 x 1pc  
Center Slat Drawer
-  #6 x 3pcs  
Bed Slat w/o marking  
1951 x 45 x 18mm
-  #7 x 2pcs  
Bed Slat with marking  
1951 x 45 x 18mm
-  #8 x 8pcs  
Bed Slat Support  
320 x 30 x 30mm
-  #9 x 1pc  
Drawer Slat Support  
95 x 30 x 30mm
-  #10 x 2pcs  
Drawer Support Rail  
633 x 40 x 20mm
-  #11 x 6pcs  
Concealed Panel  
2040 x 295 x 9mm





**Parts List (Box 3) Drawer Box**

-  #12 x 2pcs  
Footboard Drawer

**Hardware List (Box 1) Headboard Box**

-  #A x 6pcs  
Bolt 1/4" x 1-2/8"
-  #B x 6pcs  
Lock Washer
-  #C x 6pcs  
Flat Washer
-  #D x 1pc  
Allen Key m4

**Hardware List (Box 2) Side Rail Box**



-  #E x 2pcs  
Bolt 1/4" x 1-3/8"
-  #F x 9pcs  
Bolt 1/4" x 2"
-  #G x 2pcs  
Lock Washer
-  #H x 2pcs  
Flat Washer
-  #I x 1pc  
Allen Key m4
-  #J x 1pc  
Allen Key m5
-  #K x 14pcs  
CSK m4 x 32mm
-  #L x 30pcs  
P.H Screw m3.5x20mm



#1



Prepare 6 bolts assembly by inserting lock washer (#B), then flat washer (#C) onto bolts (#A). Align HB legs (#3R/L) to the holes of the headboard (#1). Secure by using bolts (#A).

#A x 6pcs  
#B x 6pcs  
#C x 6pcs



#2

1) Loosen the bolts attached to headboard (#1) and footboard (#2), then hook the side rails (#4) to the loosed bolts on the headboard (#1) and footboard (#2).  
2) Tighten the bolts on the headboard (#1) and footboard (#2) to the side rail hooks (#4).






#3


Align center slat drawer (#5) to the side rails (#4), then secure by using screws (#K).

#K x 2pcs



x 2

#4



#K


#5



#4

Align support leg (#9) to the hole of the center slat drawer (#5), then adjust leveler of the support leg (#9) according to ground level.

#F x 1pc




x 1

#1

#F

#5


#9






#E x 2pcs  
 #G x 2pcs  
 #H x 2pcs  
 #K x 2pcs

Prepare 2 bolts assembly by inserting lock washer (#G), then flat washer (#H) onto bolts (#E). Align drawer support rail (#10) to the holes of the footboard (#2) and center slat (#5). Secure drawer rail (#10) to center slat (#5) by using bolts (#E), then secure drawer rail (#10) to footboard (#2) by using screws (#K).




Unscrew knobs on the inside, then secure knobs to the outside of the drawers (#12).







#F x 8pcs



Align slat support (#8) to the hole of the bed slat without marking (#6). Secure by using bolts (#F).

Align slat support (#8) to the holes of the bed slat with marking (#7). Secure by using bolts (#F).



Align slats (#6,7) to the side rails (#4).



#8

#K x 10pcs

Secure slats (#6,7) by using screws (#K).




x10

#K

#4

#6/#7

MARKING LINE



#4



#9

#L x 30pcs

Align concealed panel (#11) to the slats (#6,7). Secure by using screws (#L).

#7

#11

x30


#6

Marking Line

#L


#7

#11



#11

Please see diagram in steps 10.



ASSEMBLY COMPLETED

