


OPTION 1: RTA CUBBY ON LEFT SIDE




OPTION 2: RTA CUBBY ON RIGHT SIDE


IMPORTANT! Please keep these instructions for future reference. Please read these instructions before assembly and use of this product.

- Adult assembly is required.
- Allen wrench (included) required for assembly.
- Product features and decorations may vary from illustrations.
- Do not use power drills or drivers.
- Phillips Head Screwdriver (Not Included) required for assembly.


Part List




A. 2 Drawer Storage Unit




B. Top Panel



C. Side Panel



D. Bottom Panel




E. Back Panel


Part List

HARDWARE AND TOOL DIAGRAM


(F) 1-3/8" Allen Head Bolt X 4




(H) Cam Lock X 4



(K) Cam Rods X 4



(L) Phillips Head Screw 5/8" X 14




(M) Flat Washer X 4



(N) Spring Washer X 4



(P) Allen Wrench X 1



Furniture Care Instructions

Room Climate Control

Wood, when first cut contains more than 50 percent water. When it is prepared for furniture construction it is placed in a Kiln and the moisture content is brought down to 8 to 10 percent. Wood is porous and responds to its environment. If the room has high humidity it will absorb it and expand and if the humidity is low it will lose moisture and shrink.

It is important that the humidity levels in the room be controlled from extremes of too much humidity or too little. Furniture should not be placed close to air-conditioning outlets, fireplaces, radiators, space heaters, humidifiers or dehumidifiers. Exposure to extreme variations of temperature and humidity can damage any fine wood product.

The Ideal Environment for Fine Furniture

Fine wood furniture will have fewer problems when its environment is controlled at a temperature between 65 and 75 degrees and a relative humidity between 35 and 40 percent. Wood placed in an environment outside of those limits can and will shrink or expand and may develop some small cracks which are not material or structural defects.

Sticking Doors and Drawers

With minor changes in temperature and humidity, doors and drawers may swell and be difficult to open or close. Tolerances have been built into the units but extreme conditions may still cause sticking. This will adjust back to normal over time but until it does, consider using a dehumidifier or rub candle wax or paraffin on the sides that stick.

Avoid Direct Sunlight

Keep the furniture out of direct sunlight. Ultraviolet rays will fade colors and in some cases darken them. It can also cause crazing or hair line cracks in the finish. White finishes will yellow naturally over time and exposure to direct sunlight will hasten this natural process along with some woods darkening naturally over time; this is not considered to be a quality defect.

Proper Storage

If you need to put your furniture in storage for any period of time, do not place furniture in a damp basement or hot dry attic. Allow air movement around the furniture and do not stack anything on it.

In General

- Protect furniture surface from hot or extremely cold items.
- Use coasters under hot or cold beverages.
- Do not use synthetic fabric under accessories or lamps.
- Protect tops from pens, markers and crayons.
- Oils from potpourri and other scented items can damage the furniture finish.
- Do not drag items across the surface of the furniture.
- Allow the surface to breathe by rotating your accessories and lamps.
- Do not over polish the furniture, do it only two or three times a year. Over polishing can distort the natural finish of the product.
- Do not wax the furniture as wax build up can destroy the natural finish of the product.
- When moving furniture always lift the unit. Do not push or drag it to avoid damage to the legs.
- Keep the furniture level so doors and drawers open and close freely.
- Clean with a damp, not wet, cloth. Use only a mild soap. Do not use abrasive cleaners.

STOP



**IF YOU EXPERIENCE ANY
ISSUES WITH THIS PRODUCT**

**BEFORE YOU
RETURN THIS TO
THE RETAILER**

**PLEASE FOLLOW
PROCEDURES ON THE
BACK PAGE**

OPTION 1: RTA CUBBY ON LEFT SIDE



Assembly step 1



Step 1: Insert Cam Rods (K) into the inset nut on the left side panel of Storage Unit (A), and right side of Side Panel (C) as shown in Figure. Tighten with the Phillips Head screwdriver (Figure 1 A & 1B).

OPTION 1: RTA CUBBY ON LEFT SIDE

Assembly step 2




Step 2:



- Attach Bottom Panel (D) to the Storage Unit using 1-3/8 " Allen Head Bolts (F) with Flat Washer (M) and Spring Washer (N). Insert the 1-3/8" Allen Head Bolts (F) first through holes on Bottom Panel (D) to Storage Unit (A) and Side Panel (C), (FIGURE 2A). Tighten all bolts with Allen Wrench (P).
- Use pre-assembled dowels as a guide to align Cam Rods (K) on Side Panel (C) and Storage Unit (A) with holes on Top Panel (B). Insert Cam Locks (H) into holes in bottom of Top Panel (B). Rotate Cam Locks (H) in a clockwise direction with a Phillips Head screwdriver to lock-in the Cam Rods (FIGURE 2B).

OPTION 1: RTA CUBBY ON LEFT SIDE

Assembly step 3





Step 3: Use a Phillips Head screwdriver to attach Back Panel (E) with 5/8" Phillips Head screws (L) as shown in figure.



Move assembled storage unit under the bed carefully as shown above.

OPTION 2: RTA CUBBY ON RIGHT SIDE


Assembly step 1




Step 1: Insert Cam Rods (K) into the inset nut on the right side panel of 2 Drawer Storage Unit (A) and left side of Side Panel (C) as shown in Figure. Tighten with the Phillips Head screwdriver (Figure 1A & 1B).

OPTION 2: RTA CUBBY ON RIGHT SIDE

Assembly step 2



NOTE: TURN STORAGE UNIT ONTO ITS BACK




Step 2:


- Attach the Bottom Panel (D) to the Storage Unit using 1-3/8 " Allen Head Bolts (F) with Flat Washer (M) and Spring Washer (N). Insert the 1-3/8 " Allen Head Bolts (F) first through the holes on Bottom Panel (D) to Storage Unit (A) and Side Panel (C), (FIGURE 2A). Tighten all bolts with Allen Wrench (P).
- Use pre-assembled dowels as a guide to align Cam Rods (K) on Side Panel (C) and Storage Unit (A) with holes on Top Panel (B). Insert Cam Locks (H) into holes in bottom of Top Panel (B). Rotate Cam Locks (H) in a clockwise direction with a Phillips Head screwdriver to lock-in the Cam Rods (FIGURE 2B).

OPTION 2: RTA CUBBY ON RIGHT SIDE

Assembly step 3



Step 3: Use a Phillips Head screwdriver to attach Back Panel (E) with 5/8" Phillips Head screws (L) as shown in figure.



Move the storage to bottom of the bed carefully as figure.

Product Assistance Procedures

You have purchased a quality piece of furniture. Our International team has spent many hours designing and engineering this piece and packaging to ensure you will be satisfied with your purchase. But if for any reason you need help with your purchase please contact us at any time.

Procedures to follow should you have any questions:

Most inquiries can be answered by visiting our website. There, you can order parts, find assembly instructions, and get answers to frequently asked questions on all of our brands.

You can also email us. In order for us to provide you with the best service possible, please include the following information in your email:

1. Your Name
2. Address
3. Phone Number
4. Item Number and description of your product
5. PO#
6. Production Date

All product information will be on the product label located on the back of all dressers and other furniture, and on either the inside bottom of the headboard, crib ends, or stabilizer bar of your crib, depending on which model you have.

Someone will contact you via e-mail or phone to help you with your issues.

If you do not have internet access, you can fax your information to us.

If you do not have internet or fax access, please call us at our toll free number.

Be sure to have all of the above information ready to give to your Customer Service Specialist.

Contact

U.S.A

Bivona & Company®, LLC
125 Jackson Avenue Suite 1,
Edison, NJ 08837
Toll Free: 1-888-963-8125;
Fax: 732-527-0664
Website: www.bivonaco.com
Email: info@bivonaco.com

Manufactured for and distributed by Bivona & Company®, LLC
125 Jackson Avenue Suite 1, Edison, NJ 08837.

MADE IN VIETNAM