


ASSEMBLY INSTRUCTION FOR ACME FURNITURE

MODEL # 97167 / 97168 / 97169 / 97170

JEWELRY ARMOIRE


Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and metal hardware. Compare with parts list to be sure all part are present. If any part(s) are missing or damaged, please contact your local furniture dealer. For efficient and speedy service, please indicate the model number and code letter of part(s) needed.

*** Do not fully tighten screws until fully assembled ***


PART LIST		
NO	PICTURE	Q'TY
①		1 PC
②		1 PC
③		2 PC
④		2 PC

HAREWRD LIST					
NO	PICTURE	Q'TY	NO	PICTURE	Q'TY
A	 Ø1/8*5/8"	3 PC	E	 Ø1/8*1-1/8"	1 PC
B	 Ø5/8*1/8"	2 PC	F		1 PC
C	 Ø1/4*1/2"	8 PC			
D	 Ø1/4*1-3/4"	8 PC			


Step 1




Step 2



Step 3



Step 4



Attention:

*** Mattresses not include.

*** Some number parts listed on the instruction sheet may not be in parts bag as they may already be assembled.