


**ASSEMBLY INSTRUCTIONS**  
**COASTER FINE FURNITURE**



*Fine Furniture for every stage of life*

**703147**  
***End Table***

# ITEM:703147



## ASSEMBLY INSTRUCTIONS

### ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### Warning !!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.




**ASSEMBLY TIME**

**30 MINUTES**

## PARTS IDENTIFICATION

(A) TOP PANEL




1 PC

(D) FRONT-RIGHT ARC LEG/  
REAR-LEFT ARC LEG




2 PCS

(B) BASE



1 PC

(E) CROSS BAR



2 PCS

(C) REAR-RIGHT ARC LEG/  
FRONT-LEFT ARC LEG















2 PCS

ITEM: **703147**




HARDWARE IDENTIFICATION

1	FLAT-HEAD SCREW	M6x40mm		4pcs
2	WOOD SCREW	Ø7x58mm		2pcs
3	PLASTIC PAD WITH SCREW	Ø55x25mm		4pcs
4	CAMLOCK SCREW	L29mm		4pcs
5	CAMLOCK	Ø15mm		4pcs
6	DOWEL	Ø8x25mm		6pcs
7	SELF-TAPPING SCREW	Ø4x50mm		4pcs
8	HAMMER BOLT	Ø6x55mm		4pcs
9	HAMMER NUT	Ø10x15mm		4pcs
10	ALLEN WRENCH	M4mm		1pc
11	STICKER	Ø18mm		6pcs
12	GLUE			1pc


ITEM: **703147**

**ASSEMBLY INSTRUCTIONS**

**STEP 1**




**STEP 2**




ITEM: **703147**

**ASSEMBLY INSTRUCTIONS**

**STEP 3**




**STEP 4**




ITEM: **703147**

**ASSEMBLY INSTRUCTIONS**

**STEP 5**




**STEP 6**




ITEM: **703147**

**DIMENSION**



# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



*Fine Furniture for every stage of life*

**703148**  
**Coffee Table**



# ITEM:703148



## ASSEMBLY INSTRUCTIONS

### ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### Warning !!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.




**ASSEMBLY TIME**

**30 MINUTES**


## PARTS IDENTIFICATION

(A) TOP PANEL




1 PC

(C) CIRCULAR SUPPORT



2 PCS

(B) BASE



1 PC

(D) ARC LEG



4 PCS

ITEM: **703148**




HARDWARE IDENTIFICATION

1	SMALL FLAT-HEAD SCREW	M6x40mm		4pcs
2	BIG FLAT-HEAD SCREW	M6x60mm		2pcs
3	WOOD SCREW	Ø7×58mm		10pcs
4	PLASTIC PAD WITH SCREW	Ø55×25mm		4pcs
5	STICKER	Ø18mm		4pcs


ITEM: **703148**

**ASSEMBLY INSTRUCTIONS**

**STEP 1**




**STEP 2**




ITEM: **703148**

**ASSEMBLY INSTRUCTIONS**

**STEP 3**



**STEP 4**



ITEM: **703148**

**DIMENSION**

