



ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE



Fine Furniture for every stage of life

193822
Side Chair

ITEM:193822



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES



PARTS IDENTIFICATION

A SEAT AND BACK





1PC

B FRONT LEG



2PCS

C BACK LEG



2PCS

HARDWARE IDENTIFICATION

1 ALLEN WRENCH
(M4 X 60MM - RBW)



1PC

2 LONG BOLT
(M6 X 60MM - RBW)



8PCS

3 LOCK WASHER
(M6 X 13MM - RBW)



8PCS

4 FLAT WASHER
(M6 X 19MM - RBW)




8PCS


ITEM: **193822**

ASSEMBLY INSTRUCTIONS


STEP 1



STEP 2




STEP 3 COMPLETE



ITEM: **193822**

COASTER
FINE FURNITURE



Note : Dimension tolerance $\pm 5\%$