






# ASSEMBLY INSTRUCTIONS

5682BLK-18, 5682BRW-18, 5682GEN-18, 5682GRY-18, 5682RED-18  
18 STOOL


Important note :

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts.
- Kindly follow the assembly instructions step by step.
- Do not tighten all screws and bolts until the stool is fully assembled.


NO	COMPONENT	QTY
1	CUSHION SEAT	1
2	#2 FRONT LEG	2
3	#3 FRONT LEG	2
4	LONG STRETCHER	2
5	SHORT STRETCHER	2

NO	HARDWARE	QTY
A	BOLT Ø5/16" x 20 x 2" 	8
B	SCREW Ø4 x 40mm 	8
C	SPRING WASHER 	8
D	FLAT WASHER 	8
E	ALLEN KEY 	1


## STEP 1




## STEP 2



## STEP 3



## STEP 4



For items use on wooden floor, hard surfaces or carpets, it is recommended to Install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.