

Item #: ZR380CS

Description: ZERMATT COUNTER STOOL

Product Size: 17 1/2"X14 1/2"X24 3/4"H

Your furniture purchase is an investment. Here are a few tips to maximize the lifetime of your furniture with a minimum amount of effort. Properly caring for your furniture can help ensure that it looks great year after year.

Wood furniture Maintenance:

- Always dust, wipe, and clean with the grain of the wood.
- Dust with a soft cloth. Dust will scratch the furniture surface if not removed properly
- Use the same type of polish consistently as interchanging oil-based and wax-based polishes will cause a build-up and result in a foggy or cloudy appearance
- If a polished surface becomes foggy, rub it with a cloth dipped in a solution of one tablespoon vinegar to one quart of water. Rub softly with the grain until the surface is completely dry
- Soap and water are not advisable for wood surfaces. Water can penetrate the finish and raise the grain on wood, causing damage.
- Remember to change dusting cloths frequently as dirty cloths may scratch your furniture's surface

The Enemies of Wood:

- Moisture is wood's worst enemy. Liquid spills should be gently wiped up immediately. Coasters should be used under all beverages.
- Do not allow or vinyl materials to lie on the furniture. Chemicals in rubber may leave a stain. Put a strip of felt or leather under accessories that have rubber or vinyl.
- Heat creates a chemical change in the furniture's finish, which results in a white spot. Use protective pads under hot dishes, appliances, etc.
- Sunlight's ultraviolet rays can damage the finish of furniture. Do not place furniture directly against a heater or radiator and do not place in the path of hot streams of air from central heating. This will cause extreme localized drying of the wood.

High Gloss Resin Table Maintenance:

- Resin tabletops have approximately 1/8" of a resin coat on the top face of the table, which will resist ice, water, wine, liquor, food, cleaning fluids and warm or hot liquids; however, cups, glasses, etc. Containing hot liquids should not be left on the table without a coaster for protection
- Resin tabletops will scratch just the same as any other glossy surface and basic precaution should be taken
- For lasting shine, the resin table should be waxed with a car wax that does not contain. Maintaining this wax build-up will result in a high gloss shine.
- When wiping down the table, a soft, clean rag should be used. Do not use a heavy paper

Granite Top Maintenance:

The surface of the granite on your table has been polished or sealed to create a generally non-porous surface. The stone has many natural characteristics including: Veining, hairline cracks, and color variations - which make up the stone's beauty.

To maintain the beauty of your granite:

- Protect surfaces from scratching, staining and etching by:
- * Keeping them free of debris or sharp objects
- * Wiping up spills immediately
- * Avoiding contact with chemicals (particularly acid-baced materials)
- Clean with pH neutral products or those especially formulated for use on stone.
- It is not recommended to use a water-based solvent for dark granite as it will remove the polish from the surface. Absorbed into the stone.
- After a period of use , apply a penetrating sealer to prevent contaminants from being
- Remove stains with special absorbent poultices formulated for use on stone.
- Renew the surface on polished granite (granite with a highs gloss surface) by buffing with special stone polish, powder or cream.
- Do not use granite on granite with a matte finish, which has been honed rather than polished (penetrating sealer may be used on both polish and honed granite)

Marble Top Maintenance:

Marble may be stone, but it is porous stone and and can stain easily. Treating marble surfaces the same as wood surfaces is a great rule of thumb.

- _ It is recommended to seal the tops on a regular basis (every 6 to 12 months) A good quality stone sealer can be purchased from any tiles/ stone store or any homecare store and should be applied according to the manufacturer's recommendation.
- When sealed properly, marble tops can be used indoors and outdoors and can withstand any wether conditions except internal freezing. Snow or freezing rain will penetrate the table and cause cracks

Caring for the Fabric on Upholstered Furniture:


- -Frequent vacuuming of the entire upholstered area will prevent dust from settling into the fibers.
- Professional cleaning is always recommended for all upholstered pieces.
- Always pre- test a small area of fabric in an inconspicuous area when cleaning before proceeding.
- Do not use cleaning products containing brightening agents

VERY IMPORTAN !! DO NOT DO NOT DO NOT NEVER WRITE **PLACE** USE USE GLASS CLEANERS DIRECTLY DIRECTLY **PLACEMATS** ON FINISHED WITH SURFACES. IN SURFACE AMMONIA WILL CHEMICALLY ATTACK SURFACE RUBBER BASES **PREVENT** PREVENT **PREVENT** MARKING DISCOLORING **FADING** DO NOT USE DO NOT REGULATE FLACE HOT COMMERCIA THE NEVER **POLISHER** POTS. ETC. HUMIDITY ALLOW LIQUIDS OF ANY KIND TO LINGER ON SURFACES. ABSORPTION AND WAXES ONCONDITIONS SURFACE AT YOUR CAUSES THE WOOD TO HOME WARP AND THE FINISH TO DE-LAMINATE. **PREVENT PREVENT PREVENT** DAMAGE TO YELLOWING **SPLITTING** FINISH!


ZR380CS ASSEMBLY INSTRUCTIONS

DO NOT FULLY TIGHTEN ALL BOLT & HEX NUTS UNTIL THE ENTIRE UNIT IS COMPLETELY ASSEMBLED


Step 1: Attach the Right Leg (B) and the Left Leg (C) to the Seat Cushion (A) by using Flat Washer (3), Lock Washer (2) and Bolt (1). Secure well by Allen Key (5). Do not fully tighten. Connect the Right Leg (B) with the Left Leg (C) by the Side stretcher (F), Front stretcher (D) and Back stretcher (E).



<u>Step 2:</u> Use Wood screw (4) to attach the joints at the foot of the chair by the screwdriver. Fully tighten bolts at this time.



Step 3: Product assembly is now completed.




PART LIST

No.	Parts List		Q'ty
A		Seat	1PC
В	22	Right Leg	2PCS
С		Left Leg	2PCS
D		Front stretcher	1PC
Е		Back stretcher	1PC
F		Side stretcher	2PCS

HARDWARE PACK #: PZR380CSH

NO.	DESCRIPTION		DIMENSION	Q'TY
1	Bolt		Ø1/4" x 44mm	8pcs
2	Lock Washer		Ø1/4" × 10mm	8pcs
3	Flat Washer		Ø1/4" x 16mm	8pcs
4	Wood Screw	Emmu-	#8 x 38mm	8pcs
5	Allen Key		4*59mm	1pc

PARTS FOR ZR380CS COMPLETE HARDWARE #: PZR380CSH



PRODUCT DETAILS

TOP LEGS PRODUCT SIZE CARTON SIZE NET WEIGHT GROSS WEIGHT CU.RT. PLYWOOD/ FOAM/ PU RUBBER WOOD 17.5" X 14.5" X 24.75" H 33" X 21" X 9" 23.98 LBS 29.59 LBS 3.61/ 2PCS

MADE IN VIETNAM