

ASSEMBLY INSTRUCTIONS

24" Counter Stool


LPK100CST/LPK150CST

Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.


1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
3. Please do not over tighten screws or bolts.
4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

PART LIST FOR COUNTER STOOL				HARDWARE LIST PACKED INSIDE BOX				
No.	PART DESC	CODE	Q'TY	No.		HARDWARE DESC	CODE	Q'TY
1	Counter Stool - Seat Frame W/Cushion (Set)	PLPK100CSTSEA PLPK150CSTSEA	1	A		ALLEN BOLT (1/4" x 63mm)	PLPK100CSTHW	4
2	Counter Stool - Front / Back Legs (2pcs/1set) (Set)	PLPK100CSTLEG1	2	B		SPRING WASHER (1/4")		4
3	Counter Stool - Side Stretcher Left / Right (2pcs/1set) (Set)	PLPK100CSTSTR1	1	C		FLAT WASHER (1/4")		4
4	Counter Stool - Side Stretcher Front / Back (2pcs/1set) (Set)	PLPK100CSTSTR2	1	D		SCREW (M4 x 38mm)		8
				E		ALLEN KEY (M4)		1


Step :1




Step :3



Step :2



Step :4



Completed