



HD-MD-300-C-E/HD-MD-400-C-E

HD Scaling Auto-Switchers and Extenders

Supplemental Guide

Crestron Electronics, Inc.

The product warranty can be found at www.crestron.com/warranty.

The specific patents that cover Crestron products are listed at patents.crestron.com.

Certain Crestron products contain open source software. For specific information, please visit www.crestron.com/opensource.

Crestron, the Crestron logo, Crestron Connect It, and DigitalMedia 8G are either trademarks or registered trademarks of Crestron Electronics, Inc. in the United States and/or other countries. HDMI, the HDMI logo, and High Definition Multimedia Interface are either trademarks or registered trademarks of HDMI Licensing LLC in the United States and/or other countries. Other trademarks, registered trademarks, and trade names may be used in this document to refer to either the entities claiming the marks and names or their products. Crestron disclaims any proprietary interest in the marks and names of others. Crestron is not responsible for errors in typography or photography.

This document was written by the Technical Publications department at Crestron.
©2017 Crestron Electronics, Inc.

Contents

Introduction	1
Web Interface Overview	1
Accessing the Web Interface	2
Navigating the Web Interface	3
Status and Configuration	4
Viewing Status Information	4
Routing an Input to the HDMI Output	5
Configuring Input Settings	7
Configuring Output Settings	10
Configuring HDMI Output Settings	11
Configuring Automatic Power Settings	12
Configuring Analog Audio Settings	15
Configuring Network Settings	17
Configuring Device Settings	18
Enabling or Disabling the Front Panel	19
Displaying the Selected Input on the HDMI Output	19
Changing the Username and Password	20
Configuring RS232 Port Settings	20
Configuring IR Settings	21
Upgrading Firmware	23
Routing Push Button Controls	24
Using Routing Push Button Controls on the Receiver	24
Using Routing Push Button Controls on the Transmitter	25
Using Routing Push Buttons on the HD-MD-300-C-E Transmitter	25
Using Routing Push Buttons on the HD-MD-400-C-E Transmitter	26

HD-MD-300-C-E/HD-MD-400-C-E: HD Scaling Auto-Switchers and Extenders

Introduction

The Crestron® HD-MD-300-C-E and HD-MD-400-C-E are high-definition digital AV switchers, scalars, and extenders that are comprised of a transmitter and a receiver. The HD-MD-300-C-E transmitter includes one HDMI® input, one VGA input, and one analog audio input. The HD-MD-400-C-E transmitter includes two HDMI inputs, one VGA input, and one analog audio input. The HD-MD-300-C-E and HD-MD-400-C-E receiver includes one HDMI input, one HDMI output, and one analog audio output as well as one IR port and one COM port.

The HD-MD-300-C-E and HD-MD-400-C-E, hereinafter referred to as *HD-MD switchers*, provide a web interface, which allows simplified configuration. Advanced functionality is enabled through integration with a Crestron control system.

This guide provides information about configuration of the HD-MD switchers using the web interface. For installation information, refer to the HD-MD-300-C-E DO Guide (Doc. 7983) or the HD-MD-400-C-E DO Guide (Doc. 7836).

Web Interface Overview

The web interface of the HD-MD switchers consists of built-in web pages that allow configuration of routing, input, output, network, and device settings. In addition, information about the HD-MD switchers as well as the connected display can be viewed.

NOTE: Unless otherwise indicated in this manual, the web pages of the HD-MD switchers are the same.

Accessing the Web Interface


To access the web interface of an HD-MD switcher, do the following:

1. Find the IP address of the HD-MD switcher by pressing the **SETUP** button on the receiver and note the IP address on the connected display. The IP address is displayed for 10 seconds.

NOTE: Configuration of an HD-MD switcher is hosted by the receiver; however, pressing the **SETUP** button on the transmitter also displays the IP address.

2. Open a web browser.
3. Go to the IP address of the HD-MD switcher. The Login page opens.

Login Page



The screenshot shows the login page of the Crestron web interface. It has a light blue background with a darker blue vertical bar on the left side. The Crestron logo is in the top left. A white box with a blue border is centered on the page, titled 'Login'. Inside this box, there are two text input fields: 'Username' and 'Password'. Below these fields is a 'Submit' button.

4. Enter the username and password. The default username is *admin*, and the default password is *admin*.

NOTE: The username and password are case sensitive.

NOTE: For enhanced security, it is recommended that the default username and password be changed. For information about changing the username and password, refer to "Changing the Username and Password" on page 20.

5. Click **Submit**. The Status page opens.

For information about navigating the web interface, refer to "Navigating the Web Interface" that follows.

Navigating the Web Interface

The web interface of the HD-MD switchers provides a navigation bar and built-in web pages of the HD-MD switchers.

Web Interface (Sample HD-MD-400-C-E Status Page Shown)

The screenshot shows the Crestron web interface. On the left is a vertical navigation bar with the following items: STATUS, ROUTING, INPUTS, OUTPUT, NETWORK, and DEVICE. The main content area is titled 'STATUS' and contains three sections:

- General**: Model: HD-RX-201-C-E, Serial Number: L14509301, Firmware Version: 2.0.1.2238
- Upstream Device**: Model: HD-TX-301-C-E, Serial Number: G15901664, Firmware Version: 2.0.1.2238
- Network**: Hostname: HDRX201-0003CE, IP Address: 10.254.67.101, Subnet Mask: 255.255.255.0, Default Gateway: 10.254.67.1, MAC Address: f8:22:85:00:03:ce

The navigation bar provides access to the web pages as follows:

- Clicking **STATUS** accesses the Status page, which provides general information about the HD-MD switcher as well as network-related information. For more information, refer to "Viewing Status Information" on the following page.
- Clicking **ROUTING** accesses the Routing page, which allows an input to be selected and routed to the HDMI output on the receiver. For more information, refer to "Routing an Input to the HDMI Output" on page 5.
- Clicking **INPUTS** accesses the Input page, which allows the desired EDID to be sent to the inputs. For more information, refer to "Configuring Input Settings" on page 7.
- Clicking **OUTPUT** accesses the HDMI Output page, which allows the output resolution to be set. In addition, the output can be enabled or disabled. For more information, refer to "Configuring Output Settings" on page 10.
- Clicking **NETWORK** accesses the Network page, which allows network settings such as hostname and DHCP (Dynamic Host Configuration Protocol) mode to be set. For more information, refer to "Configuring Network Settings" on page 17.
- Clicking **DEVICE** accesses the Device page, which allows changes to username and password settings and also controls various device functions. For more information, refer to "Configuring Device Settings" on page 18.

NOTE: After 10 minutes of inactivity, the web interface times out and returns to the Login page.

Status and Configuration

The web interface of the HD-MD switchers displays status information and allows configuration of the following:

- Routing settings
- Input settings
- Output settings
- Network settings
- Device settings


Viewing Status Information

General information, such as model name, serial number, and firmware version of an HD-MD switcher, can be viewed. The current network settings, such as hostname and IP address, can also be viewed.

To view status information, do the following: In the navigation bar, click **STATUS**. The Status page opens.

NOTE: The Status page opens after logging in to an HD-MD switcher.

Status Page (Sample HD-MD-400-C-E Status Page Shown)



The screenshot shows the Crestron web interface with the STATUS page selected in the navigation menu. The page is divided into three sections: General, Upstream Device, and Network. Each section contains fields for Model, Serial Number, and Firmware Version. The Network section also includes fields for Hostname, IP Address, Subnet Mask, Default Gateway, and MAC Address.

Section	Field	Value
General	Model	HD-RX-201-C-E
	Serial Number	L14509301
	Firmware Version	2.0.1.2238
Upstream Device	Model	HD-TX-301-C-E
	Serial Number	G15901664
	Firmware Version	2.0.1.2238
Network	Hostname	HDRX201-0003CE
	IP Address	10.254.67.101
	Subnet Mask	255.255.255.0
	Default Gateway	10.254.67.1
	MAC Address	f8:22:85:00:03:ce

The Status page displays the following information about an HD-MD switcher:

- General information, which consists of the following:
 - Model, which is **HD-RX-201-C-E**

NOTE: **HD-RX-201-C-E** is the name assigned to the receiver of the HD-MD switcher.

- Serial Number
- Firmware Version
- Upstream device information, which consists of the following:

NOTE: The **Upstream Device** section appears on the Status page only when the TO RX port on the transmitter is connected to the FROM TX port on the receiver.

- Model, which is **HD-TX-201-C-2G-E** or **HD-TX-301-C-E**

NOTE: **HD-TX-201-C-2G-E** is the name assigned to the HD-MD-300-C-E transmitter. **HD-TX-301-C-E** is the name assigned to the HD-MD-400-C-E transmitter.

- Serial Number
- Firmware Version
- Network-related information, which consists of the following:

- Hostname

NOTE: The default hostname is **HDRX201-xxxxxx**, where **xxxxxx** represents the last six characters (excluding punctuation) of the MAC address of the HD-MD switcher.

- IP Address
- Subnet Mask
- Default Gateway
- MAC Address


Routing an Input to the HDMI Output

The HDMI input on the receiver (local input) or any input on the transmitter (remote input) can be automatically or manually routed to the HDMI output on the receiver. The default input and output names can be changed if desired.


To route the desired input to the HDMI output on the receiver, do the following:

1. In the navigation bar, click **ROUTING**. The Routing page opens.

Routing Page of HD-MD-300-C-E



Routing Page of HD-MD-400-C-E



As shown above, the Routing page of the HD-MD switchers contain an **Output** section in the upper-right corner of the page, an option to enable or disable automatic routing (**Auto Route**), a **Local Inputs** section, and a **Remote Transmitter (HD-TX-201-C-2G-E or HD-TX-301-C-E)** section.

NOTE: The **Remote Transmitter (HD-TX-201-C-2G-E)** section for the HD-MD-300-C-E and the **Remote Transmitter (HD-TX-301-C-E)** section for the HD-MD-400-C-E appear on the Routing page only when the TO RX port on the transmitter is connected to the FROM TX port on the receiver.

The default name of the HDMI output on the receiver is **OUTPUT**. The default name of the local HDMI input on the receiver is **INPUT1**. The default names of the remote inputs on the transmitter are **INPUT2**, **INPUT3**, and **INPUT4** (HD-MD-400-C-E only).

2. Enable or disable automatic routing of the local and remote inputs by clicking the appropriate **Auto Route** radio button:
 - To enable automatic routing, click the **TRUE** radio button (default setting).
 - To disable automatic routing, click the **FALSE** radio button.
3. In the text entry boxes of the **Output**, **Local Inputs**, and **Remote Transmitter (HD-TX-201-C-2G-E or HD-TX-301-C-E)** sections, rename the output and inputs if desired, and then click **Save Name**.

NOTE: The **Output** section displays the resolution and frame rate being transmitted to the output.

4. To manually route a local or remote input to the output, select the corresponding input radio button. The input is routed to the output.

To manually disconnect the route of a local or remote input, click the **<clear Route>** radio button in the **Local Inputs** section of the page.

Configuring Input Settings

The web interface allows the desired EDID to be selected and sent to the inputs. Three built-in EDID files are available for selection, and a custom EDID file can also be selected. The EDID can be selected on a global basis and sent to all inputs, or it can be selected on an individual basis for each input. In addition, inputs can be renamed. HDCP support can also be enabled or disabled for each input on an individual basis. The routing priority level of inputs can also be set. For the HD-MD-400-C-E only, TT-100 support can also be configured.

To configure inputs, do the following:

1. In the navigation bar, click **INPUTS**. The Inputs page opens.

Inputs Page of HD-MD-300-C-E

The screenshot shows the Crestron web interface for configuring input settings. On the left is a navigation menu with options: STATUS, ROUTING, INPUTS (selected), OUTPUT, NETWORK, and DEVICE. The main content area is titled "Global EDID" and includes a dropdown menu for "Send EDID to All inputs" set to "1 DM Default EDID", with "Apply to All" and "Delete..." buttons. Below this is a "Load CEDID file" section with a "Choose EDID File" input and a "Browse..." button, followed by a "Load..." button. The "Local Inputs" section contains a table with columns for "Sync Name", "EDID", "HDCP Support", and "Priority".

Sync Name	EDID	HDCP Support	Priority	Save	Revert
1 INPUT1	1 DM Default EDID	Enabled	Priority 1	Save	Revert

Below the table is a "Remote Transmitter (HD-TX-201-C-2G-E)" section with a similar table:

Sync Name	EDID	HDCP Support	Priority	Save	Revert
2 INPUT2	1 DM Default EDID	Enabled	Priority 1	Save	Revert

Below that is another table for "Remote Transmitter (HD-TX-301-C-E)":

Sync Name	EDID	Audio Only	Priority	Save	Revert
3 INPUT3	16 DM Default VGA EDID	Disabled	Priority 1	Save	Revert

At the bottom of the input sections is a "Save All" button. The "Priority Routing Support" section at the bottom shows "Priority Routing" set to "Enabled".

Inputs Page of HD-MD-400-C-E

The screenshot shows the Crestron web interface for the Inputs page. On the left is a navigation menu with tabs for STATUS, ROUTING, INPUTS, OUTPUT, NETWORK, and DEVICE. The main content area is titled 'Global EDID' and includes a dropdown menu for 'Send EDID to All inputs' currently set to '1 DM Default EDID', with 'Apply to All' and 'Delete...' buttons. Below this is a 'Load CEDID file' section with a 'Choose EDID File' input field and a 'Browse...' button. The 'Local Inputs' section features a table with columns for Sync Name, EDID, HDCP Support, and Priority. The 'Remote Transmitter (HD-TX-301-C-E)' section has a table with columns for Sync Name, EDID, HDCP Support, Audio Only, and Priority. The 'Priority Routing Support' section has a 'Priority Routing' dropdown set to 'Enabled'. The 'TT-100 Support' section has a 'TT-100 Mode' dropdown set to 'Standard'.

2. (Optional) In the **Global EDID** section of the page, load a custom EDID file by doing the following:
 - a. Click **Browse** located to the right of the **Load CEDID file** field. Windows Explorer opens.
 - b. Navigate to the desired EDID file (*.cedid), select the file, and then click **Open**.
The selected EDID file appears in the **Load CEDID file** field.
 - c. Click **Load**. A prompt appears asking for confirmation that the EDID file be uploaded to the input device.
 - d. Click **OK**. The following occur:
 - In the **Global EDID** section of the page, the custom EDID filename is added to the **Send EDID to All inputs** drop-down list.
 - In the **Local Inputs** and **Remote Transmitter (HD-TX-201-C-2G-E or HD-TX-301-C-E)** sections of the page, the custom EDID filename is added to the **EDID** drop-down lists.

NOTE: Only custom EDID files can be deleted. Built-in EDID files cannot be deleted. To delete a custom EDID file, click **Delete** in the **Global EDID** section of the page. The custom EDID file is deleted from the **Send EDID to All** inputs drop-down list and also from each individual EDID drop-down list in the **Local Inputs** and **Remote Transmitter (HD-TX-201-C-2G-E or HD-TX-301-C-E)** sections of the page.

NOTE: When a custom EDID file is deleted, the EDID reverts to the default EDID for any input that was loaded with the custom EDID. The default EDID for an HDMI input is **DM Default EDID**. The default EDID for the VGA input is **DM Default VGA EDID**.

3. Configure the inputs as follows:
 - a. (Optional) In the **Global EDID** section of the page, globally apply the same EDID to all inputs simultaneously by doing the following:
 - i. In the **Send EDID to All inputs** drop-down list, select the desired built-in EDID file or a custom EDID file. The built-in EDID files are as follows:
 - 1 DM Default EDID
 - 16 DM Default VGA EDID
 - Output

NOTE: Selecting **Output** copies the EDID from the output to all of the inputs.

- ii. Click **Apply to All**. The selected EDID is automatically sent to all inputs and appears in the **EDID** drop-down list for all inputs in the **Local Inputs** and **Remote Transmitter (HD-TX-201-C-2G-E or HD-TX-301-C-E)** sections of the page.
 - b. In the **Local Inputs** and **Remote Transmitter (HD-TX-201-C-2G-E or HD-TX-301-C-E)** sections of the page, configure each input as desired:

NOTE: For each input, the Sync icon denotes whether a source is detected at the input. If a source is detected, the icon is green. If no source is detected, the icon is gray.

- i. In the **Name** text box, rename the input if desired.
 - ii. If an EDID other than the Global EDID is to be assigned, select the desired EDID in the **EDID** drop-down list.
 - iii. (Applicable only to inputs 1–2 of the HD-MD-300-C-E and inputs 1–3 of the HD-MD-400-C-E) In the **HDCP Support** drop-down list, select **Enabled** or **Disabled**. The default setting is **Enabled**.
 - iv. (Applicable only to input 3 of the HD-MD-300-C-E and input 4 of the HD-MD-400-C-E) In the **Audio Only** drop-down list, select **Enabled** or **Disabled**. When **Audio Only** is enabled, analog audio can be transmitted from the VGA input without video (a blue frame is displayed). If **Audio Only** is disabled, an active VGA video source must be connected to the VGA input. The default setting is **Disabled**.

NOTE: When **Audio Only** is enabled and when **Auto Route** is set to **TRUE** on the Routing page, automatic switching from the VGA input to another input occurs when a new source is detected at another input. Automatic switching from the VGA input to another input will not occur if an active VGA video source is disconnected from the VGA input.

- v. (Applicable only when **Auto Route** is set to **TRUE** on the Routing page) In the **Priority** drop-down list, select the priority level for routing of the input.

NOTE: In order for a priority level to be selected, the **Priority Routing** radio button in the **Priority Routing Support** section of the Inputs page must be set to **Enabled**.

Priority levels for automatic routing of an input range from **Priority 1** (highest priority) to **Priority 3** (lowest priority for the HD-MD-300-C-E) or **Priority 4** (lowest priority for the HD-MD-400-C-E). Automatic routing of an input occurs according to the routing priority level and the detection of a source at the input. Routing of an input remains until the input is disconnected. If the input that is being routed is disconnected, automatic routing switches to another input based on the routing priority level and the detection of a source at the input. If **Priority 1** is set for all inputs, the last connected input is automatically routed.

- vi. Do one of the following:
 - Click **Save** to save the **Name**, **EDID**, **HDCP Support**, **Audio Only**, and **Priority** entries for each corresponding input.
 - Click **Revert** to revert to the previous settings without saving the current entries.
 - Click **Save All** to save all unsaved entries.
- c. (HD-MD-400-C-E only) In the **TT-100 Support** section of the page, select the TT-100 mode to determine how the HD-MD-400-C-E is to interpret button presses on the connected Crestron Connect It™ cable caddy (TT-100 Series):
 - **Quick Selection:** (Default setting) The HD-MD-400-C-E switches among the active inputs each time a button on a cable caddy is pressed while the button LED is green. The selected active input is displayed on the output.

A button LED is green when an active input is routed and is blue when no inputs are connected to the HD-MD-400-C-E.
 - **Standard:** Operates according to the SIMPL program (refer to the SIMPL Windows help file for information)

Configuring Output Settings

Configuration of output settings includes the enabling or disabling of the HDMI output, the renaming of the output, setting the output resolution, and the enabling of HDCP. In addition, automatic power settings and analog audio settings can be configured. Information about the connected display and the output signal can also be viewed.

Configure output settings on the Output page of the web interface. To access the Output page, click **OUTPUT** in the navigation bar.

Output Page

The screenshot shows the Crestron web interface for the Output Page. On the left is a navigation menu with tabs for STATUS, ROUTING, INPUTS, OUTPUT (selected), NETWORK, and DEVICE. The main content area is divided into four sections:

- Output Settings:** Includes radio buttons for Enable and Disable. A text field for Name contains "OUTPUT" with a "Save Name" button. A dropdown for Resolution is set to "Auto (Recommended)". A dropdown for HDCP Enabled is set to "Automatic".
- Automatic Power Settings:** Includes radio buttons for Enable and Disable. It has two sub-sections: "Power Off" with a Timeout dropdown set to "5 seconds" and a "Set" button; and "Power On (Sync Detected)" with a "Send command" dropdown set to "None".
- Analog Audio Settings:** Features a Volume slider set to "0 dB" and a Delay slider set to "0 ms".
- Connected Display:** Shows Sink Detected: YES, Manufacturer: CEI, Name: Crestron, and Serial Number: 0.
- Output Signal:** Shows Transmitting: (green dot), Resolution: 1080p60, and HDCP: Inactive.

Configuring HDMI Output Settings

Configure HDMI output settings in the **Output Settings** section of the Output page.

Output Page - Output Settings

This screenshot is identical to the one above, but the "Output Settings" section is highlighted with a red rectangular box to draw attention to it.

To configure HDMI output settings, do the following:

1. Enable or disable the HDMI output by clicking the **Enable** or **Disable** radio button, respectively. By default, the **Enable** radio button is selected, allowing the output display to turn on. If the **Disable** radio button is selected, the output display turns off.
2. In the **Name** text entry box, rename the output if desired. The default name is **OUTPUT**. To save the new name, click **Save Name**.

- In the **Resolution** drop-down list, select the desired output resolution. A list of the available selections follows.

NOTE: In the following list, *RB* denotes *Reduced Blanking*.

Auto (Recommended)	1360x768@60
640x480@60	1366x768@60
480i	1366x768@60 RB
480p	1400x1050@60
576i	1400x1050@60 RB
576p	1440x900@60
720p@50	1440x900@60 RB
720p@60	1600x900@60 RB
800x600@60	1600x1200@60
840x480@60	1680x1050@60
1024x768@60	1680x1050@60 RB
1280x768@60	1080i50
1280x768@60 RB	1080i60
1280x800@60	1080p50
1280x800@60 RB	1080p60
1280x960@60	1900x1200@60 RB
1280x1024@60	1080p30


The default setting is **Auto (Recommended)**, which specifies the preferred resolution of the connected display.

- In the **HDCP Enabled** drop-down list, select either of the following:
 - Automatic:** (Default setting) Specifies that the output be encrypted if the input requires HDCP protection
 - Always Enabled:** Specifies that the output always be encrypted regardless of the input requirements

Configuring Automatic Power Settings

Configure automatic power-off and power-on settings in the **Automatic Power Settings** section of the Output page.

Output Page - Automatic Power Settings



By default, automatic power-off and power-on settings are disabled (the **Disable** radio button is selected). To enable automatic power settings, click the **Enable** radio button. For configuration information, refer to "Configuring Power-Off Settings" and "Configuring Power-On Settings" that follow.

Configuring Power-Off Settings

If **Automatic Power Settings** is set to **Enable**, configure automatic power-off settings by doing the following in the **Power Off** section:

1. In the **Timeout** drop-down list, select the amount of time in seconds that no signal is active before the HDMI output automatically turns off. Available values are the following: **5 seconds**, **10 seconds**, **15 seconds**, **30 seconds**, **60 seconds**, **90 seconds**, and **Custom...(sec)**. The default setting is **5 seconds**.

If **Custom...(sec)** is selected, enter the desired number of seconds in the **Timeout** text box. Valid values range from **5** to **9999** seconds. To save the setting, click **Set**.

2. Specify whether the HDMI output is to be turned off according to the timeout value specified in step 1. Select the **Yes** radio button to turn off the output or the **No** radio button to allow the output to remain turned on.
3. Select one of the **Send command** radio buttons to choose the interface to send a power-off command: **None** (default setting), **CEC**, **RS232**, or **IR**.

- If **None** is selected, no command is sent. Click **Save** to save the power-off setting.
- If **CEC** (Consumer Electronics Control) is selected, continue with step 4.
- If **RS232** is selected, skip step 4 and proceed to step 5.
- If **IR** is selected, skip steps 4 and 5 and proceed to step 6.

4. (Applicable only when **Send command** is set to **CEC**) In the **CEC** drop-down list, select one of the following to turn off the output:

- **Power Off: RCP** (Remote Control Passthrough) **and SS** (System Standby)
- **Power Off: RCP Only**
- **Power Off: SS Only**
- **Custom**

If **RCP and SS**, **RCP Only**, or **SS Only** is selected, skip steps 5 and 6 and proceed to step 7. If **Custom** is selected, continue with step 5.

5. (Applicable only when **Send command** is set to **CEC Custom** or to **RS232**) Do the following:

- a. Select the **Hex** or **Ascii** radio button to specify the format of the command. The default setting is **Hex**.
- b. In the **Command** text box, enter the command in hexadecimal or ASCII format.
- c. In the **Terminator** drop-down list, select one of the following terminators to append to the command: **None** (specifies no terminator), **CR** (carriage return), **LF** (line feed), or **CR LF** (carriage return followed by a line feed). The default setting is **CR LF**.
- d. Skip step 6 and proceed to step 7.

6. (Applicable only when **Send command** is set to **IR**) Do the following:

NOTE: In order for IR operation to be functional, an IR file (*.ir) must be loaded to the HD-MD switcher. For information about loading an IR file, refer to "Configuring IR Settings" on page 21.

- a. In the IR drop-down list, select the IR signal that is to be transmitted to turn off the output.
 - b. Continue with step 7.
7. (Applicable only when **Send command** is set to **CEC**, **RS232**, or **IR**) Do one of the following:
 - Click **Save** to save the power-off settings.
 - Click **Test** to test the command. If the command is successful, click **Save** to save the power-off settings.

Configuring Power-On Settings

If **Automatic Power Settings** is set to **Enable**, configure power-on settings by doing the following in the **Power On (Sync Detected)** section:

1. Select one of the **Send command** radio buttons to choose the interface to send a power-on command: **None** (default setting), **CEC**, **RS232**, or **IR**.
 - If **None** is selected, no command is sent. Click **Save** to save the power-on setting.
 - If **CEC** (Consumer Electronics Control) is selected, continue with step 2.
 - If **RS232** is selected, skip step 2 and proceed to step 3.
 - If **IR** is selected, skip steps 2 and 3 and proceed to step 4.
2. (Applicable only when **Send command** is set to **CEC**) In the **CEC** drop-down list, select one of the following to turn on the output:
 - **Power On: RCP** (Remote Control Passthrough) **and IVO** (Image View On)
 - **Power On: RCP**
 - **Power On: Image View on**
 - **Custom**

If **RCP and IVO**, **RCP**, or **Image View on** is selected, skip steps 3 and 4 and proceed to step 5. If **Custom** is selected, continue with step 3.

3. (Applicable only when **Send command** is set to **CEC Custom** or to **RS232**) Do the following:
 - a. Select the **Hex** or **Ascii** radio button to specify the format of the command. The default setting is **Hex**.
 - b. In the **Command** text box, enter the command in hexadecimal or ASCII format.

- c. In the **Terminator** drop-down list, select one of the following terminators to append to the command: **None** (specifies no terminator), **CR** (carriage return), **LF** (line feed), or **CR LF** (carriage return followed by a line feed). The default setting is **CR LF**.
 - d. Skip step 4 and proceed to step 5.
4. (Applicable only when **Send command** is set to **IR**) Do the following:


NOTE: In order for IR operation to be functional, an IR file (*.ir) must be loaded to the HD-MD switcher. For information about loading an IR file, refer to "Configuring IR Settings" on page 21.

- a. In the IR drop-down list, select the IR signal that is to be transmitted to turn on the output.
 - b. Continue with step 5.
5. (Applicable only when **Send command** is set to **CEC**, **RS232**, or **IR**) Do one of the following:
- Click **Save** to save the power-on settings.
 - Click **Test** to test the command. If the command is successful, click **Save** to save the power-on settings.

Configuring Analog Audio Settings

Configure analog audio settings in the **Analog Audio Settings** section of the Output page.

Output Page - Analog Audio Settings



To configure analog audio settings, do the following:

1. Mute or unmute audio by clicking the **Volume** button, which is represented by a speaker icon. By default, audio is unmuted and is set to **0 dB**. When audio is muted, the **Volume** button displays a red circle with a slash overlapping the speaker icon (🔇).
2. (Applicable only when audio is unmuted) Adjust the volume as desired by dragging the **Volume** slider to the left or to the right. The volume decreases when the slider is dragged to the left and increases when the slider is dragged to the right. Available values range from **-80 dB** to **20 dB**.


3. Set the audio delay so that the audio is in sync with the video. To do so, do either of the following:

- Drag the **Delay** slider to the left or to the right. The **Delay** text box displays the value set by the **Delay** slider.
- Enter the desired value in the **Delay** text box. The **Delay** slider adjusts to the value entered in the **Delay** text box.

Valid values range from **0 ms** to **150 ms**. The default setting is **0 ms**.

The Output page also displays information about the connected display and the output signal in the **Connected Display** and **Output Signal** sections of the page, respectively.

Output Page - Connected Display and Output Signal Information



The following information is displayed in the **Connected Display** section of the page:

- **Sink Detected:** Specifies whether the HDMI signal is detected by the connected display (**Yes** or **No**)
- **Manufacturer:** Specifies the name of the manufacturer of the connected display
- **Name:** Specifies the model name of the connected display
- **Serial Number:** Specifies the serial number of the connected display

The following information is displayed in the **Output Signal** section of the page:


- **Transmitting:** Specifies whether the HDMI output is transmitting an HDMI signal to the connected display:
 - A green icon indicates that the HDMI output is transmitting an HDMI signal.
 - A gray icon indicates that the HDMI output is not transmitting an HDMI signal.
- **Resolution:** Specifies the current resolution of the output
- **HDCP:** Specifies whether HDCP is active, inactive, or undefined

Configuring Network Settings

To configure network settings, do the following:

1. In the navigation bar, click **Network**. The Network page opens.

Network Page



2. Configure network settings as required:

- In the **Hostname** text box, overwrite the existing hostname with a name that identifies the HD-MD switcher on the network. The hostname is restricted to the letters a to z (not case sensitive), the digits 0 to 9, and the hyphen.
The default hostname is **HDRX201-xxxxxx**, where **xxxxxx** consists of the last six characters (excluding punctuation) of the MAC address of the HD-MD switcher.
- Specify whether the IP address of the HD-MD switcher is to be assigned by a DHCP server. To set the IP address, click either of the following radio buttons:
 - **Obtain an IP address automatically:** (Default setting) Allows the IP address of the HD-MD switcher to be automatically assigned by a DHCP server on the local area network (LAN) for a predetermined period of time.

NOTE: If a DHCP server does not exist on the network and 45 seconds have elapsed since the HD-MD switcher was powered on, the IP address defaults to a link-local address. Refer to RFC 3927 for information about link-local addressing.

- **Use the following IP address:** Allows a static IP address and related network settings to be assigned:
 - **IP address:** Enter a unique IP address for the HD-MD switcher.
 - **Subnet Mask:** Enter the subnet mask that is set on the network.
 - **Default Gateway:** Enter the IP address that is to be used as the network's gateway.
3. Do either of the following:
 - To save the current entries, click **Save**. The device automatically reboots.
 - To revert to the previous settings without saving the current entries, click **Revert**.

Configuring Device Settings

Configuration and management of device settings consist of the following:

- Enabling or disabling the front panel
- Displaying the selected input on the HDMI output
- Changing the username and password
- Configuring RS232 port settings
- Configuring IR settings
- Saving or loading a configuration file
- Upgrading firmware

Configure device settings on the Device page of the web interface. To access the Device page, click **DEVICE** in the navigation bar.

Device Page

The screenshot displays the Crestron web interface for device configuration. On the left is a vertical navigation bar with the following menu items: STATUS, ROUTING, INPUTS, OUTPUT, NETWORK, and DEVICE (which is highlighted). The main content area is titled 'Front Panel' and contains several sections:


- Front Panel:** Includes 'Front Panel Lock' (radio buttons for Enabled and Disabled) and 'Front Panel LEDs' (radio buttons for Enabled and Disabled).
- On Screen Display:** Includes 'Input Notification' (radio buttons for Enabled and Disabled).
- Username and Password:** Includes fields for Username (admin), Password (masked with asterisks), and Confirm Password (masked with asterisks). Buttons for 'Save' and 'Revert' are present.
- RS232 Port Settings:** Includes dropdown menus for Baud (9600), Data Bits (8), Parity (NONE), and Stop Bits (1). It also includes dropdowns for Hardware Flow Control (NONE) and Software Flow Control (NONE).
- IR Settings:** Includes a 'Filename' field, a 'Load IR file (.ir):' section with a 'Choose IR File' input and 'Browse...' button, and 'Load...' and 'Delete' buttons.
- Save/Load Configuration:** Includes a 'Load Configuration file:' section with a 'Choose Configuration File' input and 'Browse...' button, and 'Load' and 'Save' buttons.
- Firmware:** Displays 'Model: HD-RX-201-C-E', 'Serial Number: L16282717', and 'Firmware Version: 2.0.1.2232'. It includes an 'Upload firmware file:' section with a 'Choose Firmware File' input and 'Browse...' button, and a 'Load...' button.

Enabling or Disabling the Front Panel

By default, the front panel of the transmitter and receiver is unlocked, allowing the push buttons to function. When the front panel is locked, pressing any of the push buttons—with the exception of the **SETUP** push button—has no effect. In addition, the LEDs on the front panel are enabled by default. When the front panel LEDs are disabled, the LEDs—with the exception of the SETUP LED—do not light. Although front panel push buttons and LEDs may be disabled, the device continues to function.

Configure the front panel in the **Front Panel** section of the Device page.

Device Page - Front Panel



To configure the front panel, do the following as required:


- Configure **Front Panel Lock** to unlock or lock the front panel push buttons:
 - To disable locking of the push buttons and allow them to function, click the **Disabled** radio button (default setting).
 - To enable locking of the push buttons excluding the **SETUP** push button, click the **Enabled** radio button.
- Configure **Front Panel LEDs** to enable or disable the LEDs:
 - To enable the LEDs to light as appropriate, click the **Enabled** radio button (default setting).
 - To disable the LEDs excluding the SETUP LED, click the **Enabled** radio button.

Displaying the Selected Input on the HDMI Output

By default, the HDMI output is configured to display the name of the selected input when inputs are switched. The input name is the name assigned in the web interface or SIMPL Windows. The input name is displayed for 10 seconds in the upper-right corner of the display.

Configure input notification in the **On Screen Display** section of the Device page.

Device Page - On Screen Display



To configure input notification, do either of the following:

- To enable input notification on the HDMI output when inputs are switched, click the **Enabled** radio button (default setting).
- To disable input notification on the HDMI output when inputs are switched, click the **Disabled** radio button.

Changing the Username and Password

Change the username and password in the **Username and Password** section of the Device page.

Device Page - Username and Password



The screenshot shows the 'Username and Password' configuration page. On the left is a navigation menu with 'INPUTS', 'OUTPUT', 'NETWORK', and 'DEVICE' (selected). The main content area has a title 'Username and Password' with an information icon. Below the title are three text input fields: 'Username' (containing 'admin'), 'Password' (with masked characters), and 'Confirm Password' (with masked characters). At the bottom of the form are 'Save' and 'Revert' buttons. Below the form, a link for 'RS232 Port Settings' is visible.

To change the username and password, do the following:


NOTE: The username and password are case sensitive.

1. In the **Username** text box, enter the desired username.
2. In the **Password** text box, enter the desired password.
3. In the **Confirm Password** text box, reenter the desired password to confirm the password.
4. Do either of the following:
 - To save the current entries, click the **Save** button.
 - To revert to the previous settings without saving the current entries, click the **Revert** button.

Configuring RS232 Port Settings

Configure RS232 port settings in the **RS232 Port Settings** section of the Device page.

Device Page - RS232 Port Settings



The screenshot shows the 'RS232 Port Settings' configuration page. On the left is a navigation menu with 'DEVICE' (selected). The main content area has a title 'RS232 Port Settings' with an information icon. Below the title are four dropdown menus: 'Baud' (9600), 'Data Bits' (8), 'Parity' (NONE), and 'Stop Bits' (1). Below these are two more dropdown menus: 'Hardware Flow Control' (NONE) and 'Software Flow Control' (NONE). At the top right of the form are 'Save' and 'Revert' buttons. Below the form, a link for 'Firmware' is visible.

To configure RS232 port settings, do the following:

1. In the **Baud** drop-down list, select the number of bits to be transmitted per second. Available values are as follows:

300	9600
600	14400
1200	19200
2400	28800
3600	38400
4800	57600
7200	115200

The default setting is **9600** bits per second (bps).

2. In the **Data Bits** drop-down list, select the number of data bits that are to be transmitted as a series. Available values are **7** and **8**. The default setting is **8**.
3. In the **Parity** drop-down list, select the parity. Available values are **NONE**, **Odd**, **Even**, or **Mark**. The default setting is **NONE**.
4. In the **Stop Bits** drop-down list, select the number of stop bits. Available values are **1** and **2**. The default setting is **1**.
5. In the **Hardware Flow Control** drop-down list, select the hardware flow control. Available values are **RTS/CTS** and **NONE**. The default setting is **NONE**.
6. In the **Software Flow Control** drop-down list, select the software flow control. Available values are **NONE** and **XON/XOFF**. The default setting is **NONE**.

Configuring IR Settings

An IR file (*.ir) can be loaded to an HD-MD switcher. The IR file defines all IR signals available on the device.

NOTE: After the Crestron Database is installed on a PC, IR files are installed in the following location on the PC:

C:\Program Files (x86)\Crestron\Cresdb\cresirdb.zip

Before loading an IR file, extract the *.ir files from the cresirdb.zip file.

Load an IR file using the **IR Settings** section of the Device page.

Device Page - IR Settings



To load an IR file, do the following:

1. Click **Browse** located to the right of the **Load IR file (.ir)** field. Windows Explorer opens.
2. Locate and select the desired IR file (*.ir), and then click **Open**. The **Load IR file (.ir)** field displays the path to the selected IR file.

NOTE: If a file other than an *.ir file is selected, a message appears indicating that the selected file is an invalid file type. Select a valid IR file.

3. Click **Load**. A prompt appears asking for confirmation that the IR file be loaded.
4. Click **OK** to load the IR file. The IR filename is displayed and the IR signals are listed below the filename as shown in the example below.

Device Page - Sample IR Settings



To delete the IR settings, do the following:


1. In the **IR Settings** section of the Device page, click **Delete**. A prompt appears asking for confirmation that the IR settings be deleted.
2. Click **OK** to delete the IR settings. The IR settings are removed from the **IR Settings** section of the page.

Saving or Loading a Configuration File

A configuration file (*.xml) can be generated using the settings currently configured on an HD-MD switcher. The file can then be saved to the local hard drive of a PC. A configuration file can also be loaded to an HD-MD switcher.

Save or load a configuration file in the **Save/Load Configuration** section of the Device page.

Device Page - Save/Load Configuration



To save or load a configuration file, refer to "Saving a Configuration File" or "Loading a Configuration File" on the following page.

Saving a Configuration File

In the **Save/Load Configuration** section, do the following to save a configuration file:

1. Click **Save**.
An HD-RX-201-C-E.xml file is generated containing the settings currently configured on the HD-MD switcher. In addition, an **XML Edit** dialog box opens.
2. Click **Save** to save the HD-RX-201-C-E.xml file. The file is downloaded to the **Downloads** folder of the PC.

Loading a Configuration File

In the **Save/Load Configuration** section, do the following to load a configuration file:

1. Click **Browse** located to the right of the **Load Configuration file** field. Windows Explorer opens.
2. Locate and select the desired configuration file (*.xml), and then click **Open**. The **Load Configuration file** field displays the path to the selected configuration file.
3. Click **Load** to load the configuration file. A prompt appears asking for confirmation that the selected configuration file be loaded.
4. Click **Yes**. The **Restoring** message appears.

When the configuration file is loaded to the HD-MD switcher, a message appears indicating that the XML restore process is finished. The web interface then returns to the Login page.

Upgrading Firmware

Upgrade firmware in the **Firmware** section of the Device page.

Device Page - Firmware



The **Firmware** section displays the following information about the receiver:

- Model, which is **HD-RX-201-C-E**
- Serial Number
- Firmware Version

NOTE: The firmware file is an *.bin file. Before upgrading firmware, extract the *.bin file from the *.zip file.

To upgrade firmware, do the following:

1. Click **Browse** located to the right of the **Upload firmware file** field. Windows Explorer opens.
2. Locate and select the desired firmware file (*.bin), and then click **Open**. The **Upload firmware file** field displays the path to the selected firmware file.
3. Click **Load**. A prompt appears asking for confirmation that the firmware be upgraded.
4. Click **OK** to upgrade the firmware. When the firmware upgrade process is complete, the Login page of the web interface opens.

NOTE: If the web interface is inaccessible after a firmware upgrade, refresh the web browser using **CTRL + F5**.

Routing Push Button Controls

The receiver and transmitter of the HD-MD switchers provide push buttons that can be used to route an input to the HDMI output on the receiver.


NOTE: If the front panel is disabled, pressing the routing push buttons has no effect and the corresponding LEDs do not light. For more information, refer to "Enabling or Disabling the Front Panel" on page 19.

NOTE: As discussed in the "Routing an Input to the HDMI Output" section on page 5, the Routing page of the web interface can also be used to route an input to the HDMI output.

Using Routing Push Button Controls on the Receiver

The receiver of the HD-MD switchers provides one **AUTO** push button, two **INPUT** push buttons, and corresponding LEDs as shown in the following illustration.

Routing Push Buttons and LEDs on the Receiver



To route signals for each of the inputs on the receiver, use the routing push buttons as follows:

- To enable or disable automatic routing of the inputs, press the **AUTO** push button. Pressing the button toggles automatic routing on and off. Automatic routing is enabled by default.
- To route the HDMI signal corresponding to the HDMI input on the receiver, press the **INPUT 1** push button.
- To route the signal corresponding to the FROM TX input on the receiver, press the **INPUT 2** push button.

NOTE: The **INPUT 2** push button on the receiver must be pressed in order for any of the inputs on the transmitter to be routed to the output.

For each INPUT push button on the receiver, the corresponding LED functions as follows:

- **AUTO LED:** When automatic routing is enabled, the AUTO LED lights green. When automatic routing is disabled, the AUTO LED turns off.
- **INPUT LED:** For each input, the INPUT LED indicates whether the input is routed and a source is detected:
 - Green indicates that the input is routed to an output.
 - Amber indicates that a source is detected but is not routed.
 - Off indicates that no source is detected and no signal is routed.


Using Routing Push Button Controls on the Transmitter

The following sections provide information about the routing push buttons and LEDs that are specific to the HD-MD-300-C-E transmitter and the HD-MD-400-C-E transmitter.

Using Routing Push Buttons on the HD-MD-300-C-E Transmitter

The HD-MD-300-C-E transmitter provides one **AUTO** push button and LED, one **INPUT SEL** push button, one HDMI IN LED, and one VGA IN LED. The routing push buttons and LEDs are shown in the following illustration.

Routing Push Buttons and LEDs on the HD-MD-300-C-E Transmitter



To route signals for each of the inputs on the HD-MD-300-C-E transmitter, use the routing push buttons as follows:

NOTE: The **INPUT 2** push button on the receiver must be pressed in order for any of the inputs on the transmitter to be routed to the output.

- To enable or disable automatic routing of the inputs, press the **AUTO** push button. Pressing the button toggles automatic routing on and off. Automatic routing is enabled by default.
- To switch from the default setting of automatic routing to any of the inputs on both the transmitter and receiver, press the **INPUT SEL** push button in succession to cycle through the HDMI and VGA inputs on both the transmitter and receiver until the desired input is selected.


For each input on the HD-MD-300-C-E transmitter, the corresponding LED functions as follows:

- **AUTO LED:** When automatic routing is enabled, the AUTO LED lights green. When automatic routing is disabled, the AUTO LED turns off.
- **INPUT LED:** For each input, the corresponding LED indicates whether the input is routed and a source is detected:
 - Green indicates that the input is routed to an output.
 - Amber indicates that a source is detected but is not routed.
 - Off indicates that no source is detected and no signal is routed.

Using Routing Push Buttons on the HD-MD-400-C-E Transmitter

The HD-MD-400-C-E transmitter provides one **AUTO** push button, three **INPUT** push buttons, and corresponding LEDs. The routing push buttons and LEDs on the HD-MD-400-C-E transmitter are shown in the following illustration.

Routing Push Buttons and LEDs on the HD-MD-400-C-E Transmitter



To route signals for each of the inputs on the HD-MD-400-C-E transmitter, use the routing push buttons as follows:

NOTE: The **INPUT 2** push button on the receiver must be pressed in order for any of the inputs on the transmitter to be routed to the output.

- To enable or disable automatic routing of the inputs, press the **AUTO** push button. Pressing the button toggles automatic routing on and off. Automatic routing is enabled by default.
- To route the HDMI signal corresponding to the HDMI 2 input on the transmitter, press the **INPUT 2** push button.
- To route the HDMI signal corresponding to the HDMI 3 input on the transmitter, press the **INPUT 3** push button.
- To route the RGB (VGA) or component video input signal with an analog audio signal corresponding to the VGA 4 and AUDIO inputs on the transmitter, press the **INPUT 4** push button.

For each **INPUT** push button on the HD-MD-400-C-E transmitter, the corresponding LED functions as follows:

- **AUTO LED:** When automatic routing is enabled, the AUTO LED lights green. When automatic routing is disabled, the AUTO LED turns off.
- **INPUT LED:** For each input, the INPUT LED indicates whether the input is routed and a source is detected:
 - Green indicates that the input is routed to an output.
 - Amber indicates that a source is detected but is not routed.
 - Off indicates that no source is detected and no signal is routed.

This page is intentionally left blank.

Crestron Electronics, Inc.
15 Volvo Drive Rockleigh, NJ 07647
Tel: 888.CRESTRON
Fax: 201.767.7576
www.crestron.com



Supplemental Guide – DOC. 7797C
(2045740)
06.17
Specifications subject to
change without notice.