

Congratulations on your purchase of a GEMINI recliner!

To get the most enjoyment from your recliner, and extend its life, **please follow these important instructions:**



To recline, pull the handle back to start the recline operation as you lean back in the chair, then release the handle. (It only requires 3 lbs. of pressure on the handle to release the reclining mechanism and begin reclining.)



To return to upright, lean forward and push the legrest down using your legs. Once you are completely upright, push the handle forward to close the chair completely.

DO NOT begin by pulling the handle forward to close the chair.

IMPORTANT:

This manual recliner is **Lever-activated**, not **Lever-operated**. This means the side handle is only to be used to start the process of reclining and finish the process of closing the recliner.

**** DO NOT** continue pulling the handle as you recline.

**** DO NOT** pull the handle forward to close the recliner until after you are fully upright and have pushed down on the legrest.

Overuse of the handle in this unnecessary manner may result in breakage.



Parker House[®]
FURNITURE