


# LIEBHERR

## Installation Instructions

For Wine Cooler



MW 18.. / MW 24..  
7085 882-00

Table of Contents	Page
Please Read and Follow these Instructions.....	2
Note to the Installer.....	2
Important Safety Information .....	3
R600a Refrigerant .....	4
Disposal of Old Appliance .....	4
Disposal of Packaging Material .....	4
Electrical Safety .....	5
Blocking for Safety.....	5
Appliance Dimensions.....	6
Door Swing Clearance (top view) .....	6
Cabinet Opening Dimensions .....	7
Panel Dimensions.....	8
Unpacking .....	9
Standard Accessories.....	11
Mounting the anti tipping device in cabinets deeper than 24" - Figure 1- 2.....	12
Mounting the anti tipping device on wooden floors - Figure 3.....	12
Mounting the anti tipping device on concrete floors - Figure 4 - 5.....	13
Appliance Installation.....	14
Please note in case of removing appliance from the recess.....	21
Important Note for Changing over Door Hinges or Limiting the Hinges to a 90° Opening Angle .....	21

### **IMPORTANT**

*All types and models are subject to continuous improvement. The manufacturer reserves the right to make modifications to the shape, equipment, and technology.*

## **Please Read and Follow these Instructions**

These instructions contain Danger, Warning, and Caution notes.

This information is important for safe and efficient installation and operation.

Always read and comply with all Danger, Warning, and Caution notes!



### **DANGER!**

**Danger indicates a hazard which will cause serious injury or death if precautions are not followed.**



### **WARNING!**

**Warning indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.**



### **CAUTION!**

**Caution indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.**

### **IMPORTANT**

*This indicates information that is especially relevant to a problem-free installation and operation.*

## **Note to the Installer**

It is very important to follow the instructions in the manual to ensure proper installation and operation of the unit.

Before installing the unit, be sure to thoroughly read and understand all of the information in this manual.



### **WARNING!**

**Electrocution hazard.**

**Do not connect to the electrical outlet before the installation is completed.**

## Important Safety Information

- **WARNING:** Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- **WARNING:** Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- **WARNING:** Do not damage the refrigerant circuit.
- **WARNING:** The power cord must not be damaged while installing the appliance.
- **WARNING:** Multi-sockets or distributor strips and other electronic devices (such as halogen transformers) must not be positioned and operated at the rear of appliances.
- **WARNING:** Danger of injury through electric shock! There are live parts under the cover. Only have the interior LED light replaced or repaired by customer service staff or trained personnel.
- **WARNING:** Risk of injury from the LED lamp. The light intensity of the LED light complies with laser class RG 2. If the cover is defective, do not look directly at the light through optical lenses from close distance. This may damage your eyes.
- **WARNING:** This appliance must be secured as described in the Use and Care Manual (Installation Instructions) to rule out any potential risks due to its instability.
- **WARNING:** Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- Any repairs and work on the appliance should only be performed by the customer service department. Unauthorized work may be dangerous to the user. The power source cable should only be changed or replaced by the customer service department. Component parts and power cords shall be replaced with like components performed by factory authorized service personnel only.
- Do not stand on the toe kick, drawers or doors or use them to support anything else.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge unless they have been given initial supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- To prevent injury and damage to property, the appliance should only be installed by two people.
- Check the appliance for signs of damage after unpacking. Contact the supplier if it is damaged. Do not connect the appliance to the mains power supply.
- Avoid prolonged skin contact with cold surfaces (e.g., chilled/frozen products). If necessary, take safety action (e.g., gloves).
- Do not consume food which has been stored for too long; it could cause food poisoning.

- Any repairs and work on the appliance should only be performed by the customer service department or other trained personnel. The same applies to changing the power cord.
- Only perform repair and other work on the appliance when the plug has visibly been disconnected.
- Only install, connect, and dispose of the appliance as described in this Use and Care Manual.
- In the event of a fault, pull out the plug or switch off the fuse.
- When disconnecting the appliance from the power source, pull it out by the plug, never pull on the cable.
- If you have a lockable appliance, do not keep the key near the appliance or within reach of children.
- The appliance is designed for use in enclosed rooms. Do not operate the appliance outdoors or in areas where there is moisture or splashing water.
- Do not use the interior LED light to light the room. The interior LED light is only designed to illuminate the interior of the appliance.
- Do not allow naked flames or ignition sources to enter the appliance.
- Alcoholic drinks or other vessels containing alcohol should be sealed tightly for storage.

## R600a Refrigerant



### WARNING!

The refrigerant R600a contained within the appliance is environmentally friendly, but flammable. Leaking refrigerant can ignite.

## Disposal of Old Appliance



### DANGER!

#### Risk of child entrapment.

Child entrapment and suffocation are not problems of the past.

Junked or abandoned refrigerators are still dangerous – even if they will sit for “just a few days.”

If you are getting rid of your old refrigerator, please follow these instructions to help prevent accidents.

#### Before you discard old appliances:

- **Take off the doors.**
- **Leave the shelves in place so that children may not easily climb inside.**
- **Cut off the power cord from the discarded appliance. Discard separately from the appliance.**
- **Be sure to follow your local requirements for disposal of appliances.**

**Contact the trash collection agency in your area for additional information.**

## Disposal of Packaging Material



### WARNING!

**Keep packaging materials away from children. Polythene sheets and bags can cause suffocation!**

If possible, please recycle packaging material at a recycling facility.

## Electrical Safety

Connect this appliance to a 15 amp or 20 amp, 110-120 VAC circuit which is grounded and protected by a circuit breaker or fuse.

We recommend using a dedicated circuit for this appliance to prevent circuit overload and the chance of interruption to the appliance.

This appliance is equipped with a three-prong (grounding) polarized plug for your protection against possible shock hazards.

Where a two-prong wall receptacle is encountered, contact a qualified electrician and have it replaced with a properly grounded three-prong receptacle in accordance with all local codes and ordinances.



### **WARNING!**

**Electrocution hazard.**


**Electrical grounding required.**

- Do not remove the round grounding prong from the plug. →



- Do not use extension cords or ungrounded (two prong) adapters.

- Do not use a power cord that is frayed or damaged.



- Do not use a power strip. →

Failure to follow these instructions may result in fire, electric shock or death.

## Blocking for Safety




### **WARNING!**

To avoid a hazard due to instability of the appliance, it must be fixed in accordance with the instructions.


# PLANNING INFORMATION

## Appliance Dimensions



Stated minimum height dimensions include when the levelled feet are fully inserted.  
Width will increase by 1/4" (6.5 mm) when mounting strips are installed.

## Door Swing Clearance (top view)



### Inset installation style

A = 8 1/4" (210 mm)  
B = 1/2" (12.5 mm)  
C = 19 7/8" (505 mm)

### Frameless installation style

A = 8 1/2" (216 mm)  
B = 1/2" (12.5 mm)  
C = 20 3/8" (517 mm)

### Inset installation style

A = 10 3/4" (273 mm)  
B = 1/2" (12.5 mm)  
C = 25 7/8" (658 mm)


### Frameless installation style

A = 11" (279 mm)  
B = 1/2" (12.5 mm)  
C = 26 3/8" (670 mm)




Dimension A and B: Add panel thickness and handle to calculate distance to wall.

## Cabinet Opening Dimensions

Continuous toe kick



Individual toe kick



### A

Cabinet depth frameless installation style = 25" (635 mm)

Cabinet depth inset installation style = 25" (635 mm) plus panel thickness

### B

This is the point where the power cord exits from the appliance rear. 3/4" (19 mm) from the left and 5" (127 mm) from the floor.

Free length of the power cord is 98" (2.5 m).

### IMPORTANT

*The power plug must be easily accessible so that the appliance can be disconnected from the mains quickly in an emergency. It must not be behind the back of the appliance.*

### C


The appliance has a recess in this area for cable and waterline laying.

1" (25 mm) in depth and 5 1/2" (140 mm) in height over the whole width of the appliance.

### D

This surface is visible when the appliance door is open. Designed finish is required.

## Panel Dimensions



### 18" recess

#### Inset installation style

H = 79 7/8" (2029 mm)

W = 17 3/4" (451 mm)

H = 58 7/8" (1495 mm)

W = 11" (280 mm)

#### Frameless installation style


H = 80" (2032 mm) plus overlapping of the panel on the top

W = 18" (457 mm) plus overlapping of the panel on both sides

Minimum panel thickness = 5/8" (16 mm)

Maximum panel thickness = 1" (25 mm)

Maximum panel weight = 55 lbs (25 kg)



### 24" recess

#### Inset installation style

H = 79 7/8" (2029 mm)

W = 23 3/4" (603 mm)

H = 58 7/8" (1495 mm)

W = 17" (432 mm)

#### Frameless installation style

H = 80" (2032 mm) plus overlapping of the panel on the top

W = 24" (610 mm) plus overlapping of the panel on both sides


Minimum panel thickness = 5/8" (16 mm)

Maximum panel thickness = 1" (25 mm)

Maximum panel weight = 66 lbs (30 kg)




## Unpacking




1. Cut the straps and remove them.
2. Press in the lug, tear or cut the carton on the edge and remove it.
3. Remove all styrofoam packing material from the sides and top.

MW 18..

MW 24..



4. Remove the box with mounting parts.
5. Remove the ventilation grille.




6. Secure the appliance door with tape to prevent it from being opened accidentally.



**DANGER!**

**Risk of death or serious injury due to appliance tipping.**

**Do not remove the transit supports before the appliance is in the recess.**



7. Remove the rear transportation safety components and anti-tipping device.


Remove the packed cover strips and support strips from the appliance rear.



**WARNING!**

**Risk of injury and damage.**

**Four people are required to safely remove the appliance from the bottom pallet.**



8. One person tilts the appliance back carefully and holds it in place.

9. Two people grasp the appliance from the bottom and lift. One on each side.


10. One person removes the pallet.

Place the appliance carefully on the floor.


# UNPACKING

## Alternative possibility:


Cut off the marked area from the pallet.




or



Tilt the appliance slightly sideways.




Slide a two-wheeled cart between the appliance and packaging.  
Restrain the appliance to the cart with straps.  
Tilt the appliance onto the cart.




Place the appliance carefully on the floor.

## Standard Accessories



Retaining screws for installation





### SmartDeviceBox

Includes component for smartphone connectivity



**DO NOT DISCARD!**

Forward to appliance user!




Screw length measuring tool


Divider for ventilation duct in the toe kick area




Depth adjustment aid 4 pcs.





Door stop



Bottle holder  
12 pcs. MW 18..  
7 pcs. MW 24..



Appliance cover strips for the gap between appliance and recess



# BLOCKING FOR SAFETY

## Mounting the anti tipping device in cabinets deeper than 24" -

*Figure 1- 2*


To ensure the compressor mounting plate reaches the anti tipping bracket in cabinets deeper than 24", a wooden spacer must be mounted between the appliance back and the wall. The anti tipping bracket will be fastened to the floor downwards and to the spacer backwards.



**WARNING!**


**Be sure the wooden spacer is fastened securely to the floor.**

### Measuring for mounting the wooden spacer on inset kitchen cabinets - *Figure 1*



*Figure 1*

### Measuring for mounting the wooden spacer on frameless kitchen cabinets - *Figure 2*



*Figure 2*

### **IMPORTANT**

*If the floor slopes down sideways, the anti-tipping bracket must be fitted horizontally. Lay down spacers in the appropriate positions.*

## Mounting the anti tipping device on wooden floors - *Figure 3*


1. Mark the center line of the appliance on the back wall. Align the anti tipping bracket center to this line.



**WARNING!**

**Be sure that there is no plumbing or electrical wiring located in this area which screws or drills could damage.**

2. Fasten bracket to the wooden floor using 5 screws (1/4" x 2-1/8"). Drill pilot holes if necessary.
3. Fasten bracket with 3 screws (1/4" x 2-1/8") into the wall plate.



*Figure 3*

## Mounting the anti tipping device on concrete floors - Figure 4 - 5

Secure the appliance in place so it does not tip forward when the fully stocked door is opened. The anti tipping bracket is provided with the appliance.

1. Mark the center line of the appliance on the back wall. Align the anti tipping bracket center to this line.



**WARNING!**

**Be sure that there is no plumbing or electrical wiring located in this area which screws or drills could damage.**

2. Drill a 3/8" diameter hole in any position as shown in **Figure 4** using a carbide drill bit.

The depth of the holes must exceed the overall length of the anchors provided.

Clean the holes after drilling.


3. Attach washer and screw on hex nut to the end of each anchor.

Drive in all 3 anchors.


Align the bracket center to the center line on the back wall again.

Fasten the anchors by turning the hex nut.

4. Fasten bracket with 3 screws (1/4" x 2-1/8") into the wall plate (**Figure 5**).



**Figure 4**




**Figure 5**


# BLOCKING FOR SAFETY

## Appliance Installation



Move the appliance towards the final position and leave enough space to work behind.



**IMPORTANT**  
Complete the installation  
before switching on the  
device.




Fit the door stops.




Apply the appliance cover strips to the left and right front edge of the appliance housing, align in height with the top profile and screw into place. The strip is transparent so the designed mounting holes on the appliance housing are visible. We recommend that you mark and pre-drill the hole positions in the strip.

**IMPORTANT**  
Use the correct flat head screws, otherwise the edges of the cabinet will be damaged when sliding the appliance into the recess.

Mounting the depth adjustment aid into the cover strips






Slide the appliance into the recess. Move the power cord and appliance at the same time to avoid damage.

Align the appliance in depth.

X = Recess front to appliance housing front (not cover strip)



**Inset 7/8"** (22 mm) panel  
X = 2 5/8" (66 mm)

**Inset 3/4"** (19 mm) panel  
X = 2 1/2" (63 mm)

**Inset 5/8"** (16 mm) panel  
X = 2 3/8" (60 mm)


**Frameless**

X = 1 3/4" (44 mm)

or


with the depth adjustment aid:

The surface of the depth adjustment aid must be flush with the surface of the recess. (Example shows 3/4" (19 mm))



## IMPORTANT

*The depth of the door cannot be adjusted later!*




Remove the transit supports using the Torx 25 key.



## DANGER!

**Risk of death or serious injury due to appliance tipping.**

**Do not open the appliance door before the height adjustment is finished and the anti-tipping bracket supports the appliance.**



Turn clockwise to raise the appliance.

Raise the appliance evenly by turning the screws successively until the appliance back touches the anti-tipping bracket (lift approx. 1/4" / 6.5 mm).

Maximum height adjustment of the appliance = 3/4" (19mm)

## IMPORTANT


*When turning the screws with a power driver please consider absolutely.*

Maximum rotation speed = 400 rpm  
Maximum torque = 8.8 lbs/in (1 Nm)

*Failure to follow this instruction will result in damage to the height adjustment unit.*




# INSTALLATION




Mount the ventilation grille with the grille segments tilted down.

Remove the depth adjustment aid before fastening the appliance in the recess.



Fasten the appliance in the recess through the appliance cover strips using eight screws 4 x 14 for each side. We recommend that you mark and pre-drill the hole positions in the strip.

Close the front part of the appliance cover strips.




## Hint:

Use the removed transportation safety component to help with closing.

Measure the distance.


## Inset installation style

From the bottom of the recess to the center of the attachment bracket boreholes




## Frameless installation style

From the top of the recess to the center of the attachment bracket boreholes




Mark the spacing on the door panel.






Remove the attachment bracket from the door. Nuts are required again later.




Fit the attachment bracket on the panel.



## IMPORTANT

*Door handles should be mounted now because the side support strips will cover the mounting holes.*




Only use countersunk screws for handle mounting.


The holes should be countersunk.

The screw heads should be flush with the panel.

Affix the sealing strip to the bottom inside of the panel.



Fit the divider for the ventilation duct using two screws 4 x 19. Fit cover.




# INSTALLATION

## IMPORTANT


If the door has to be limited to a 90° opening angle, it must be done before the panel is mounted onto the appliance door. See chapter "Important Note for Changing over Door Hinges or Limiting the Hinges to a 90° Opening Angle" on page 21.

Open the appliance door.

Place the door panel on the top adjusting bolts and align in the centre.




Close the door and check the position of the panel.





## IMPORTANT

After a certain time and loading, it may be necessary to readjust the door again.




Loosen the hex nuts and turn the adjusting bolts with the Torx 15 key provided.




Align the panel in its depth at the bottom.

Loosen the screws, align the panel and tighten the screws. Use the Torx 20 key provided.




Fasten the panel through the bottom attachment bracket with two screws 4 x 14.




## IMPORTANT


*For installation, only pull out the magnetic seal at one of the marked screw positions (there are 9 on each side 200 mm apart). Never remove the magnetic seal in full.*




# INSTALLATION



Adjust the brackets to the thickness of the toe kick panel.




Remove the backing foil and affix the toe kick panel.



Check that there is no gap between the appliance air divider and the door air divider.

## **IMPORTANT**


*There will be a gap if the ventilation grille is fitted incorrectly.*



## Please note in case of removing appliance from the recess

If the appliance has to be removed from the recess again, please make sure you take account of the following.

1. Unload the appliance.
2. Disconnect the appliance from the power source.
3. Remove the mounted front panel from the appliance door.
4. Lower the appliance using the height adjustment unit.



**DANGER!**

**Risk of death or serious injury due to appliance tipping.**

**Do not remove the appliance without the mounted transit supports.**

## Important Note for Changing over Door Hinges or Limiting the Hinges to a 90° Opening Angle

Changing the door hinges or limiting the hinges to a 90° opening angle should only be carried out by a trained expert.

The door hinges are fitted with strong closing springs. If the hinge accidentally snaps shut, this can lead to serious injury.

The door itself is very heavy. Do not try to dismount the door yourself.

Contact the Liebherr service for more information. See contact details on the back of this manual.

## **For Service in the U.S.**

### **Liebherr Service Center**

Toll Free: **1-866-LIEBHER or 1-866-543-2437**

Email: [Service-appliances.us@liebherr.com](mailto:Service-appliances.us@liebherr.com)

### **PlusOne Solutions, Inc.**

3501 Quadrangle Blvd, Suite 120

Orlando, FL 32817

## **For Service in Canada**

### **Liebherr Service Center**

Toll Free: **1-888-LIEBHER or 1-888-543-2437**

[www.euro-parts.ca](http://www.euro-parts.ca)

### **EURO-PARTS CANADA**

39822 Belgrave Road

Belgrave, Ontario, N0G 1E0

Phone: (519) 357-3320

Fax: (519) 357-1326



[www.liebherr-appliances.com](http://www.liebherr-appliances.com)