

7870A




A




1PC

1




A


2




- 1** To raise the footrest, grasp both armrests and push forward while leaning back in the recliner.




- 2** To fully recline, pull the strap loop and lean backward.




- 3** To return the recliner to an upright position, pull the strap loop and sit up.



- 4** To stow the footrest, push downward with your lower legs while seated.




- Raise footrest from full upright position only.



- Do not raise footrest from this position.



- Stow footrest with back in full upright position.




- Do not attempt to stow footrest from this position.

How to adjust the headrest

P4



To adjust the headrest, grip the backside of the headrest and pull forward from both sides as shown



DO NOT pull from the side edges, as the material may tear



To adjust the headrest backward, push on both sides or use a forearm to evenly move the headrest

Caution:

Do not push in the center of the headrest, as this may cause the cushion to collapse

