SHARP | Simply Better Living ALEXA COMMAND GUIDE

Smart Convection Microwave Drawer™ Oven

SMD2499FS

Pair with your Amazon Alexa App and enjoy hands-free cooking with Alexa.

Menu Item	Command	Quantity Range
Open	Alexa, open the oven.	-
+ 30 Seconds	Alexa, add 30 seconds to the oven.	100% Power
Add Time	Alexa, add X minutes to the oven. Alexa, add Y seconds to the oven.	X = 01:00 - 60:00 Y = 00:01 - 00:59
Pause Time	Alexa, pause the oven.	-
Resume Time	Alexa, resume the oven.	_
Stop Time	Alexa, stop the oven.	-
Time Cook	Alexa, microwave/cook for X minutes and Y seconds. Alexa, reheat for X minutes and Y seconds.	X = 01:00 - 60:00 Y = 00:01 - 00:59
Time Cook (Time & Power Level)	Alexa, microwave/cook for X minutes at level Y .	X = 01:00 - 60:00 Y = 1 - 10
Preheat	Alexa, preheat the oven to X degrees.	X = 90°F / 150°F / 275°-450°F by increments of 5°F
Convection Bake	Alexa, convection bake for X minutes/ hours at Y degrees.	X = 1 min - 2 hrs Y = 90°F / 150°F / 275°-450°F by increments of 5°F
Convection Roast	Alexa, convection roast for X minutes/ hours at Y degrees.	X = 1 min - 2 hrs. Y = 375°F - 450°F by increments of 5°F

Menu Item	Command	Quantity Range
Convection Grill	Alexa, convection grill for X minutes.	X = 1 - 30 min
Convection Warm	Alexa, warm for X minutes/hours at Y degrees.	X = 1 min - 2 hrs Y = 90°F / 150°F / 200°F
Time Defrost	Alexa, defrost for X minutes. Alexa, defrost for Y seconds.	X = 01:00 - 60:00 Y = 00:01 - 00:59
Popcorn	Alexa, microwave/cook popcorn. Alexa, microwave/cook X popcorn.	X = Regular / Mini
Reheat	Alexa, reheat leftovers. Alexa, reheat dinner plate.	-
Fish	Alexa, microwave/cook fish.	-
Fresh Vegetables	Alexa, microwave/cook fresh vegetables.	Quick Fresh / Longer Fresh Vegetables
Frozen Entrée	Alexa, microwave/cook frozen entrée.	-
Frozen Vegetables	Alexa, microwave/cook frozen vegetables.	-
Ground Meat	Alexa, microwave/cook ground meat.	-
Potatoes	Alexa, microwave/cook potatoes. Alexa, microwave/cook baked potatoes. Alexa, microwave/cook sweet potatoes.	Baked / Sweet Potatoes
Rice	Alexa, microwave/cook rice. Alexa, microwave/cook brown rice. Alexa, microwave/cook white rice.	Brown / White Rice
Seafood	Alexa, microwave/cook seafood.	-

Menu Item	Command	Quantity Range
Steamer Bags	Alexa, microwave/cook steamer bags.	-
Bone-In Poultry (Defrost)	Alexa, defrost bone-in poultry.	X = 0.5 - 3.0 lbs.
Boneless Poultry (Defrost)	Alexa, defrost boneless poultry.	X = 0.5 - 2.0 lbs.
Casserole (Defrost)	Alexa, defrost X cups of casserole.	X = 1 / 2 / 3 / 4 / 5 / 6 cups
Chops (Defrost)	Alexa, defrost X pounds of chops.	X = 0.5 - 3.0 lbs.
Ground Meat (Defrost)	Alexa, defrost X pounds of ground meat.	X = 0.5 - 2.0 lbs.
Roast (Defrost)	Alexa, defrost roast. Alexa, defrost X pounds of roast.	X = 0.5 - 4.0 lbs.
Steaks (Defrost)	Alexa, defrost X pounds of steaks.	X = 0.5 - 3.0 lbs.
Soup (Defrost)	Alexa, defrost X cups of soup.	X = 1 / 2 / 3 / 4 / 5 / 6 cups
Beverage (Reheat)	Alexa, reheat beverage. Alexa, reheat X cups of beverage.	X = 0.5 / 1 / 1.5 / 2 cups
Hot Cereal	Alexa, microwave/cook hot cereal. Alexa, microwave/cook X cups of hot cereal.	X = 1 / 2 / 3 / 4 / 5 / 6 servings
Hot Water	Alexa, microwave/cook hot water. Alexa, microwave/cook X cups of hot water.	X = 1 / 2 / 3 / 4 / 5 / 6 cups
Butter (Melt)	Alexa, melt X tablespoons of butter.	X = 2 - 8 tbsp.

Menu Item	Command	Quantity Range
Chocolate (Melt)	Alexa, melt X oz. of chocolate.	X = 1 - 8 oz.
Cream Cheese (Soften)	Alexa, soften cream cheese. Alexa, soften X oz. of cream cheese.	X = 2 - 8 oz.
Ice Cream (Soften)	Alexa, soften ice cream. Alexa, soften X cups of ice cream.	X = 2 - 6 cups
Dessert Topping (Warm)	Alexa, warm dessert topping. Alexa, warm X cups of dessert topping.	X = 0.25 - 0.5 cups
Syrup (Warm)	Alexa, warm syrup. Alexa, warm X cups of syrup.	X = 0.25 - 0.5 cups
Bacon (3 - 8 slices)	Alexa, cook bacon. Alexa, bake bacon. Alexa, convection bake bacon.	-
Beef Burger (2 - 6 patties) (1/2" thick, 6 oz. each)	Alexa, cook beef burger. Alexa, grill beef burger.	-
Beef Roast	Alexa, cook beef roast. Alexa, cook X pounds of beef roast. Alexa, roast beef roast. Alexa, convection roast reef roast.	X = 2.0 - 4.0 lbs.
Biscuits (6 - 12 canned)	Alexa, cook biscuits. Alexa, bake biscuits. Alexa, convection bake biscuits.	-
Boneless Chicken Breast (1.0 - 3.5 lbs (1 - 3 large breast pieces)	Alexa, cook boneless chicken breast in the oven. Alexa, grill boneless chicken breast in the oven.	-
Breaded Shrimp (6 - 18 pieces)	Alexa, cook breaded shrimp. Alexa, roast breaded shrimp. Alexa, convection roast breaded shrimp.	-

Menu Item	Command	Quantity Range
Brownies (One 8x8" Pan)	Alexa, cook brownies. Alexa, bake brownies. Alexa, convection bake brownies.	-
Chicken Drummies (1.0 - 2.5 lbs) (3 - 6 large drumsticks)	Alexa, cook drummies in the oven. Alexa, grill drummies in the oven.	-
Chicken Tenders (3 - 8 pieces)	Alexa, cook chicken tenders in the oven. Alexa, roast chicken tenders. Alexa, convection roast chicken tenders.	-
Cookies (6 - 12 prepackaged)	Alexa, cook cookies. Alexa, bake cookies. Alexa, convection bake cookies.	-
Crescent Rolls (4 - 8 canned)	Alexa, cook crescent rolls. Alexa, bake crescent rolls. Alexa, convection bake crescent rolls.	-
Dinner Rolls (10 - 20 frozen)	Alexa, cook dinner rolls. Alexa, bake dinner rolls. Alexa, convection bake dinner rolls.	-
Fish Fillets (2 - 4 fillets) (6 - 10 oz each)	Alexa, cook fish fillet. Alexa, roast fish fillet. Alexa, convection roast fish fillet.	-
Flank Steak (1.5 - 2.0 lbs)	Alexa, cook flank steak in the oven. Alexa, grill flank steak.	-
French Fries (10 - 24 oz)	Alexa, cook french fries. Alexa, roast french fries. Alexa, convection roast french fries.	-

Menu Item	Command	Quantity Range
Fresh Pizza on Pizza Stone (One 12")	Alexa, cook fresh pizza on pizza stone in the oven. Alexa, roast fresh pizza on pizza stone in the oven. Alexa, convection roast fresh pizza on pizza stone in the oven.	-
Frozen Classic Pizza (One 12")	Alexa, cook frozen classic pizza in the oven. Alexa, roast frozen classic pizza in the oven. Alexa, convection roast frozen classic pizza in the oven.	-
Frozen Rising Pizza (One 12")	Alexa, cook frozen rising pizza in the oven. Alexa, roast frozen rising pizza in the oven. Alexa, convection roast frozen rising pizza in the oven.	-
Frozen Rising Pizza (One 12")	Alexa, cook frozen rising pizza in the oven. Alexa, roast frozen rising pizza in the oven. Alexa, convection roast frozen rising pizza in the oven.	-
Frozen Thin Crust Pizza (One 12")	Alexa, cook frozen thin crust pizza in the oven. Alexa, roast frozen thin crust pizza in the oven. Alexa, convection roast frozen thin crust pizza in the oven.	_
Layered Cake (One or two 8" pans)	Alexa, cook layered cake. Alexa, bake layered cake. Alexa, convection bake layered cake.	-
Mozzarella Sticks (4 - 12 sticks)	Alexa, cook mozzarella sticks. Alexa, roast mozzarella sticks. Alexa, convection roast mozzarella sticks.	-
Pork Chop (2 - 5 pieces) (1/2" thick, 6 - 9 oz each)	Alexa, cook pork chop. Alexa, grill pork chop.	-

Smart Convection Microwave Drawer™ Oven

Menu Item	Command	Quantity Range
Pork Tenderloin (0.75 - 1.5 lbs)	Alexa, cook pork tenderloin. Alexa, roast pork tenderloin. Alexa, convection roast pork tenderloin.	-
Preheat	Alexa, preheat.	-
Tater Tots (10 oz - 24 oz)	Alexa, cook tater tots. Alexa, roast tater tots. Alexa, convection tater tots.	-
Toast	Alexa, toast in the oven	Default setting is medium.
Turkey Breast	Alexa, roast turkey breast in the oven. Alexa, roast X pounds of turkey breast. Alexa, cook turkey breast in the oven. Alexa, cook X pounds of turkey breast.	X = 1.0 - 3.5 lb
Turkey Burger (2 - 6 patties) (1/2" thick, 6 oz each)	Alexa, cook turkey burger. Alexa, grill turkey burger.	_
Veggie Burger (2 - 6 frozen patties) (3 - 4 oz each)	Alexa, cook veggie burger. Alexa, grill veggie burger.	
Whole Chicken	Alexa, roast whole chicken in the oven. Alexa, roast X pounds of whole chicken. Alexa, cook whole chicken in the oven. Alexa, cook X pounds of whole chicken.	X = 2.5 - 7.5 lb