

MAYTAG® Microwave Hood Combination

Model MMV5219 Quick Reference Guide

POPCORN (sensor)

Senses 3.0-3.5 oz (85-99 g) size bags:

Place bag on turntable. Listen for popping to slow to 1 pop every 1 or 2 seconds, then stop the cycle.

MENU PROGRAMS: Touch the menu control repeatedly to scroll through program options. Follow display prompts to select submenu items and/or amounts, and then start the program.

VEGGIE

- 1 Fresh Vegetable** – Senses 1-4 cups (250 mL-1 L):
Place in microwave-safe container. Add 2-4 tbs (30-60 mL) water. Cover with plastic wrap, and vent. Stir and let stand 2-3 minutes after cooking.
- 2 Frozen Vegetable** – Senses 1-4 cups (250 mL-1 L):
Remove from package. Place in microwave-safe container. Add 2-4 tbs (30-60 mL) water. Cover with plastic wrap, and vent. Stir and let stand 2-3 minutes after cooking.
- 3 Canned Vegetable** – 1, 2, 3 or 4 cups (250, 500, 750 mL or 1 L):
Place in microwave-safe container. Cover with plastic wrap, and vent. Stir and let stand 2-3 minutes after cooking.

REHEAT

- 1 Beverage** – 1 or 2 cups, 8 oz (250 mL) each:
Do not cover. The diameter of the cup's opening will affect how the liquid heats. Beverages in cups with smaller openings may heat faster.
- 2 Casserole** – 1, 2, 3 or 4 cups (250, 500, 750 mL or 1 L):
Place in microwave-safe container and cover with plastic wrap. Stir and let stand 2-3 minutes after reheating.
- 3 Soup** – Senses 1-4 cups (250 mL-1 L):
Place in microwave-safe container and cover with plastic wrap. Stir and let stand 2-3 minutes after reheating.
- 4 Dinner Plate** – Senses 1 plate, about 8-16 oz (227-454 g):
Place food on microwave-safe plate, cover with plastic wrap, and vent.
- 5 Pizza** – 1, 2 or 3 slices, 4 oz (113 g) each:
Place on paper towel lined paper plate.
- 6 Sauce** – Senses 1-4 cups (250 mL-1 L):
Place in microwave-safe container and cover with plastic wrap. Stir and let stand 2-3 minutes after reheating.
- 7 Baked Goods** – 1, 2, 3, 4, 5 or 6 pieces, 2 oz (57 g) each:
Place on paper towel. Two small rolls may be counted as 1 piece.

DEFROST

- 1 Meat** – 0.2 to 6.6 lbs (90 g to 3 kg):
Remove wrap and place in microwave-safe dish. Do not cover.
- 2 Poultry** – 0.2 to 6.6 lbs (90 g to 3 kg):
Remove wrap and place breast side up in microwave-safe dish. Do not cover.
- 3 Fish** – 0.2 to 4.4 lbs (90 g to 2 kg):
Remove wrap and place in microwave-safe dish. Do not cover.
- 4 Quick Defrost (auto)** – 1.0 lb (454 g) only:
Remove wrap and place in microwave-safe dish. Do not cover. Turn over food at signal.

SOFTEN/MELT

- 1 Soften Butter** – 0.5, 1.0, 1.5 or 2.0 sticks:
Unwrap and place in microwave-safe dish.
- 2 Melt Butter** – 0.5, 1.0, 1.5 or 2.0 sticks:
Unwrap and place in microwave-safe dish.
- 3 Soften Ice Cream** – 16, 32 or 64 oz (473, 946 or 1893 mL):
Place ice cream container on turntable.
- 4 Soften Cream Cheese** – 3 or 8 oz (85 or 227 g):
Unwrap and place in microwave-safe dish.

BAKED POTATO (sensor)

Senses 1-4 potatoes, 10-13 oz (283-369 g) each, similar in size:

Pierce each potato several times with a fork. Place on paper towel, around turntable edges, at least 1" (2.5 cm) apart. Place single potato to the side of the turntable. Let stand 5 minutes after cooking.

- 5 Soften Frozen Juice** – 12 or 16 oz (340 or 454 g):
Remove lid from container.

- 6 Melt Chocolate** – 4, 6, 8 or 12 oz (113, 170, 227 or 340 g):
Place in microwave-safe dish.

- 7 Melt Cheese** – 8 or 16 oz (227 or 454 g):
Place in microwave-safe dish. Stir at signal.

- 8 Melt Marshmallows** – 5 or 10 oz (142 or 283 g):
Place in microwave-safe dish.

AUTO COOK

- 1 Frozen Entrée** – 10 or 20 oz (283 or 567 g) (sensor), or 40 oz (1134 g) (non-sensor):
Remove from package. Loosen cover on 3 sides. If entrée is not in microwave-safe container, place on plate, cover with plastic wrap, and vent.
- 2 Bacon** – 1, 2, 3, 4, 5 or 6 slices, average thickness:
Follow directions on package.
- 3 French Toast** – 1 or 2 pieces:
Follow directions on package.
- 4 Cereal** – 1, 2, 3 or 4 servings:
Follow directions on package. Use microwave-safe bowl with high sides.
- 5 Rice** – Senses 0.5-2.0 cups (125-500 mL) dry, white long grain:
Follow measurements on package for ingredient amounts. Use microwave-safe dish with loose-fitting lid. Let stand 5 minutes after cooking, or until liquid is absorbed. Stir.

KIDS MENU

- 1 Canned Pasta** – 1-4 servings:
Follow directions on package.
- 2 Frozen Pizza** – 1 pizza, about 6 oz (170 g):
Follow directions on package.
- 3 Frozen Meal** – 8, 9 or 10 oz (227, 255 or 283 g):
Follow directions on package.
- 4 Oatmeal** – 1 or 2 servings:
Follow directions on package. Use microwave-safe bowl with high sides.
- 5 Chicken Nuggets** – 1 or 2 servings (about 5-6 pieces each):
Place in single layer on paper towel-lined microwave-safe plate.
- 6 Hot Dog** – 1-4 hot dogs (pieces):
Pierce with fork. Place on microwave-safe plate.

SNACK MENU

- 1 Nachos** – 1 serving:
Place tortilla chips in single layer on microwave-safe plate, then sprinkle with cheese.
- 2 Chicken Wings** (precooked, refrigerated) – 5-8 oz (142-227 g) (about 5-8 wings):
Place wings on microwave-safe plate in spoke formation. Cover with wax paper.
- 3 Potato Skins** (prebaked) – 1 or 2 potatoes:
Quarter each potato, and scoop out the centers of the wedges, leaving about 1/4" (6 mm) skin. Place wedges on microwave-safe plate, then sprinkle with toppings.
- 4 Frozen Sandwich** – 1 or 2 sandwiches (pieces):
Follow directions on package.

