



GTB-HD4K2K-444-BLK

User Manual Release A6



Important Safety Instructions

GENERAL SAFETY INFORMATION

- 1. Read these instructions.
- 2. Keep these instructions.
- 3. Heed all warnings.
- Follow all instructions.
- 5. Do not use this product near water.
- 6. Clean only with a dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- 8. Do not install or place this product near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- 9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- 11. Only use attachments/accessories specified by the manufacturer.
- 12. To reduce the risk of electric shock and/or damage to this product, never handle or touch this unit or power cord if your hands are wet or damp. Do not expose this product to rain or moisture.
- 13. Unplug this apparatus during lightning storms or when unused for long periods of time.
- 14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- 15. Batteries that may be included with this product and/or accessories should never be exposed to open flame or excessive heat. Always dispose of used batteries according to the instructions.

Warranty Information

Gefen warrants the equipment it manufactures to be free from defects in material and workmanship.

If equipment fails because of such defects and Gefen is notified within two (2) years from the date of shipment, Gefen will, at its option, repair or replace the equipment, provided that the equipment has not been subjected to mechanical, electrical, or other abuse or modifications. Equipment that fails under conditions other than those covered will be repaired at the current price of parts and labor in effect at the time of repair. Such repairs are warranted for ninety (90) days from the day of reshipment to the Buyer.

This warranty is in lieu of all other warranties expressed or implied, including without limitation, any implied warranty or merchantability or fitness for any particular purpose, all of which are expressly disclaimed.

- 1. Proof of sale may be required in order to claim warranty.
- 2. Customers outside the US are responsible for shipping charges to and from Gefen.
- Copper cables are limited to a 30 day warranty and cables must be in their original condition.

The information in this manual has been carefully checked and is believed to be accurate. However, Gefen assumes no responsibility for any inaccuracies that may be contained in this manual. In no event will Gefen be liable for direct, indirect, special, incidental, or consequential damages resulting from any defect or omission in this manual, even if advised of the possibility of such damages. The technical information contained herein regarding the features and specifications is subject to change without notice.

For the latest warranty coverage information, refer to the Warranty and Return Policy under the Support section of the Gefen Web site at www.gefen.com.

PRODUCT REGISTRATION

Please register your product online by visiting the Register Product page under the Support section of the Gefen Web site.

Contacting Gefen Technical Support

Gefen, LLC c/o Customer Service 20600 Nordhoff St. Chatsworth, CA 91311

Telephone: (818) 772-9100

(800) 545-6900

Fax: (818) 772-9120

Email: support@gefentoolbox.com

Visit us on the Web: www.gefentoolbox.com

Technical Support Hours: 8:00 AM to 5:00 PM Monday - Friday, Pacific Time

4K Ultra HD 4x4 Matrix for HDMI is a trademark of Gefen, LLC.

Important Notice

Gefen, LLC reserves the right to make changes in the hardware, packaging, and any accompanying documentation without prior written notice.

HDMI, the HDMI logo, and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing in the United States and other countries.

© 2015 Gefen, LLC. All Rights Reserved.
All trademarks are the property of their respective owners.

Operating Notes

- EDID contains the A/V capabilities of a display device in regards to video resolutions and audio formats supported. This information is used by the source device to determine the format of the A/V signal on the outputs. The GefenToolBox 4K Ultra HD 4x4 Matrix for HDMI incorporates advanced EDID management to ensure compatibility with all sources and display devices.
- The GefenToolBox 4K Ultra HD 4x4 Matrix for HDMI can detect the presence of Deep Color (12-bit signal) automatically and will disable Deep Color EDID features across all other outputs if any connected device or display is not capable of processing Deep Color. This automatic behavior ensures compatibility among all output devices in a mixed-device environment. This feature cannot be disabled.
- When powering the GefenToolBox 4K Ultra HD 4x4 Matrix for HDMI or if the EDID mode is changed, the matrix will undergo a momentary initialization sequence. This is normal operation and may take a few seconds.
- The best way to operate and configure this unit is to use the built-in Web interface, which can be accessed by entering the IP address of the matrix into the address bar of any Web browser. See the section RS-232 and IP Configuration for more information about this feature.

Licensing

This product uses software that is subject to open source licenses, including one or more of the General Public License Version 2 and Version 2.1, Lesser General Public License Version 2.1 and Version 3, BSD, and BSD-style licenses. Distribution and use of this product is subject to the license terms and limitations of liability provided in those licenses. Specific license terms and Copyright Notifications are provided in the source code. For three years from date of activation of this product, any party may request, and we will supply, for software covered by an applicable license (e.g. GPL or LGPL), a complete machine-readable copy of the corresponding open source code on a medium customarily used for software interchange. The following software and libraries are included with this product and subject to their respective open source licenses:

- IwIP
- jQuery

IwIP is licenced under the BSD licence:

Copyright (c) 2001-2004 Swedish Institute of Computer Science. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- 3. The name of the author may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Features and Packing List

Features

- Routes four Ultra Hi-Def sources to four Ultra HD displays
- Supports resolutions up to Ultra HD 4K x 2K (3840 x 2160 @ 30Hz) and 1080p Full HD
- Supports 12-bit Deep Color
- 3DTV pass-through
- Lip Sync pass-through
- Push button controls for Routing, FST Modes, Audio, and EDID management
- FST Technology speeds up HDCP authentication process
- Advanced EDID Management for rapid integration of sources and displays
- Supports LPCM 7.1, Dolby® TrueHD, and DTS-HD Master Audio™
- Supports the use of DVI sources and DVI displays with HDMI-to-DVI adapters (not included)
- RS-232 Serial interface for remote control using a computer or automation control system
- IP control via Telnet, UDP, and the built-in web server interface
- IR remote control
- Field-upgradeable firmware via Mini-USB and IP ports
- Locking Power Supply
- Surface-mountable

















Packing List

The 4K Ultra HD 4x4 Matrix for HDMI ships with the items listed below. If any of these items are not present in your box when you first open it, immediately contact your dealer or Gefen.

- 1 x 4K Ultra HD 4x4 Matrix for HDMI
- 1 x DB-9 Cable
- 1 x IR Remote
- 1 x 5V DC Power Supply
- 1 x AC Power Cord
- 1 x Quick-Start Guide

Table of Contents

01 Getting Sto	ırted
----------------	-------

	Panel Layout	2
	IR Remote Control Unit	5
	Front	5
	Back	6
	Installing the Battery	7
	Setting the IR Channel	7
	Installation	8
	Connecting the 4K Ultra HD 4x4 Matrix for HDMI	
	Sample Wiring Diagram	
02	Operating the 4K Ultra HD 4x4 Matrix for HDMI	
	Routing Basics	12
	Determining the Current Routing State	12
	Routing Inputs to Outputs	13
	Using the IR Remote Control Unit	
	Using the IR Extender	
	Switching Modes	
	What is Fast Switching Technology?	
	Fast Mode vs Slow Mode	
	Selecting the FST Mode	
	Audio Modes	
	Selecting the Audio Mode	
	EDID Modes	
	Available Modes	
	Selecting the EDID Mode	
03	Advanced Operation	
	RS-232 and IP Configuration	22
	RS-232 Interface	22
	RS-232 Settings	22
	IP / UDP Configuration	23
	Commands	24
	Configuration	24
	IP / Telnet Configuration	43
	FST	55
	Masking	58
	Routing / Naming / +5V / Presets	
	Status	
	Web Interface	71
	Using the built-in Web Server	
	Main ► Routing	
	Main ► I/O Status	
	Main ▶ Display Info	
	-r - y -	

04

Table of Contents

I/O Setup ► Preset Names	/8
I/O Setup ► I/O Names	79
I/O Setup ▶ HPD Control	80
I/O Setup ▶ FST	
I/O Setup ▶ HDCP	82
Manage EDID ► Assign	83
Manage EDID ► Bank Names	86
Manage EDID ► Upload/Download	87
Configuration ► Change IP Settings	89
Configuration ► Telnet Login Settings	90
Configuration ► UDP Connection Settings	91
Configuration ► Web Login Settings	92
Configuration ► System Configuration	93
Appendix	
Wall Mounting Instructions	98
Firmware Upgrade Procedure	99
Upgrading using the Web interface	99
Upgrading using USB	100
Specifications	101



01 Getting Started

Panel Layout	2
IR Remote Control Unit	5
Front	5
Back	6
Installing the Battery	7
Setting the IR Channel	7
Installation	8
Connecting the 4K Ultra HD 4x4 Matrix for HDMI	8
Sample Wiring Diagram	8

Panel Layout




ID	Name	Description
1	In (1 - 4)	Connect an HDMI cable from an Ultra Hi-Def source to any of these HDMI ports.
2	Out (1 - 4)	Connect an Ultra HD display to each of these ports using an HDMI cables.
3	FST (Fast / Slow)	Use this recessed button to switch between Fast and Slow FST (Fast Switching Technology) modes. See Fast Mode vs Slow Mode for more information on using FST mode. The LED indicators will display the current mode.
4	Audio (2ch / Multi-ch)	Use this recessed button to switch between 2CH and Multichannel audio on the output. The LED indicators will display the current mode. See Selecting the Audio Mode for more information on using this feature.
5	EDID (Int / Ext / Custom)	Use this recessed button to switch between internal (Int), external (Ext), and custom EDID modes. The LED indicators will display the current mode. See Selecting the EDID Mode for more information.
6	Out 1 - Out 4 (selection)	Press these buttons to change the routing state of the desired output. See Routing Inputs to Outputs for more information. The LED indicators will display the current routing state.
7	Power	This LED indicator will glow bright blue when the included 5V DC power supply is connected from the matrix to an available electrical outlet.
8	RS-232	Connect an RS-232 cable from this port to an RS-232 device. See RS-232 and IP Configuration for more information.
9	IR Ext	Connect an IR Extender (Gefen part no. EXT-RMT-EXTIRN) to this port.

(continued on next page)

ID	Name	Description
10	USB	Used for upgrading the firmware. See Firmware Upgrade Procedure for more information.
11	IR	This IR sensor receives signals from the included IR remote control unit.
12	IP Control	Connect an Ethernet cable between this jack and a LAN to use IP control. See RS-232 and IP Configuration for more information.
13	5V DC	Connect the included 5V DC power supply to this locking power receptacle.

IR Remote Control Unit

Front



ID	Name	Description
1	Activity indicator	This LED flashes bright orange when a key is pressed on the remote.
2	Input Selection (1 - 16)	Press these button to switch to the desired input (source). Buttons 1 - 4 are used to select the input for Out 1 , buttons 5 - 8 are used to select the input for Out 2 , and so on.



NOTE: If the Activity indicator flashes quickly while holding down any one of the buttons, then replace the battery as soon as possible. See Installing the Battery.

Back (shown with cover removed)



ID	Name	Description
1	DIP switch bank	Use these DIP switches to set the IR channel of the remote. See Setting the IR Channel for more information.
2	Primary battery slot (shown without battery)	Holds the battery for operating the remote. Use only 3V CR2032-type batteries. Make sure that the positive (+) side of the battery is facing up.
3	Alternate battery slot	Allows for the installation of secondary (backup) battery.

Installing the Battery

The IR remote control unit ships with two batteries. Only one battery is required for operation. The second battery is a spare.




WARNING: Use only 3V CR2032-type batteries. Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

- Remove the back cover the IR Remote Control unit.
- Insert the included battery into the primary battery slot. The positive (+) side of the battery should be facing up.
- 3. Replace the back cover.

Setting the IR Channel

In order for the included IR remote control to communicate with the 4x4 Matrix for HDMI 4K x 2K, the IR remote control must be set to the same channel as the matrix. Use the #set_ir command to set the IR channel of the matrix.






Installation

Connecting the 4K Ultra HD 4x4 Matrix for HDMI

- Connect up to four Ultra Hi-Def sources to the input ports (In 1 In 4) ports on the matrix.
- Connect up to four Ultra HD displays using the output ports (Out 1 Out 4) on the matrix.
- OPTIONAL: Connect an RS-232 cable from the RS-232 port on the matrix to the RS-232 connector on the serial controller (e.g. Gefen PACS, etc).
- 4. OPTIONAL: Connect an Ethernet cable from the IP Control port on the matrix to a Local Area Network (LAN).
- 5. OPTIONAL: Connect an IR extender to the IR Ext port on the matrix.
- Connect the included 5V DC locking power supply to the 5V DC power receptacle on the matrix. Do not overtighten the locking power connector.
- 7. Connect the power supply to an available electrical outlet.

Sample Wiring Diagram





02 Operating the 4x4 Matrix for HDMI

Routing Basics	12
Determining the Current Routing State	12
Routing Inputs to Outputs	13
Using the IR Remote Control Unit	14
Using the IR Extender	15
Switching Modes	16
What is Fast Switching Technology?	16
Fast Mode vs Slow Mode	16
Selecting the FST Mode	16
Audio Modes	17
Selecting the Audio Mode	17
EDID Modes	18
Available Modes	18
Selecting the EDID Mode	18

Routing Basics

Determining the Current Routing State

On the bottom-left portion of the matrix, there are four rows of four LED indicators. The top row of LED indicators displays the routing state of **Out 1**. The next row displays the routing state of **Out 2**, and so on. A row of numbers (1 - 4) is printed above the four rows of LED indicators. Each LED indicator represents an input (**In 1** - **In 4**) on the matrix. The LED indicator for the currently selected input will glow solid green.



Routing Basics


Routing Inputs to Outputs

To the left of each row of LED indicators, there are two push-buttons labeled **Out 1** and **Out 2**. To change the routing state of an output, press and release the button of the desired output to advance to the next input.

In the example below, the source connected to In 1 is currently routed to Out 2.



To change the routing state and route In 2 to Out 2, press and release the Out 2 button.



To route the another source to **Out 2**, consecutively press and release the **Out 2** button until the desired input is selected.

Once In 4 is selected for any of the outputs, pressing the **Out** button again will return to In 1.


Using the IR Remote Control Unit

The IR remote control unit provides discrete routing between each input and output. There are a total of 16 buttons on the IR remote. The buttons are color-coded in groups of four. Each set of buttons controls the routing for each output. Buttons 1 - 4 select which input (In 1 - In 4) is routed to Out 1, buttons 5 - 8 select which input (In 1 - In 4) is routed to Out 2, and so on. Let's look at an example.

Currently, In 2 is routed to Out 1. In this example, we will route In 4 to Out 1.



- 1. Point the IR remote at the IR sensor on the top panel of the matrix.
- Since we want to control the routing state of **Out 1**, we need to use the *first* set of four buttons on the IR remote control. Press button 4 on the IR remote control.
- The LED indicator on the IR remote will flash bright yellow, indicating that a button on the IR remote was pressed.




 The LED indicator for In 4 will glow bright green, indicating that the input has been routed to Out 1 (shown above).

Routing Basics

Using the IR Extender

There may be situations where the IR sensor is blocked by a cabinet or other mounting device. In this case, an IR extender (Gefen part no. EXT-RMT-EXTIRN) can be connected to the IR port on the matrix. The sensor on the IR extender behaves exactly like the sensor on the top panel of the matrix. Always point the IR remote control unit at the IR sensor.



Switching Modes



What is Fast Switching Technology?

Fast Switching Technology (FST) is a Gefen software implementation for HDMI products. FST was created to improve the lengthy HDMI authentication process, based on the HDMI and HDCP specifications.

FST provides quicker audio/video source switching and greatly improves the overall audio/video system behavior and performance when more than one HDTV display is used in the system setup.

FST allows connecting / disconnecting or turning ON / OFF of HDTV displays without having these activities affect other Hi-Def sources routed to any other HDTV display in the same system.


Fast Mode vs Slow Mode

Use *fast* switching mode to improve performance when connecting / disconnecting Hi-Def sources, and powering ON / OFF HDTV displays.

Use *slow* mode when the source does not support multiple devices. When set to *slow* switching mode, the 4K Ultra HD 4x4 Matrix for HDMI will follow the standard authentication process, based on the HDMI and HDCP specifications.

Selecting the FST Mode

- Use a paper clip or other pointed object to press and release the recessed FST button, to toggle between Fast and Slow modes.
- The LED indicator will display the current FST mode.



Audio Modes

The 4K Ultra HD 4x4 Matrix for HDMI provides the capability to switch between 2-channel and multichannel audio output.



NOTE: In order for the audio channel mode to be selected, the **EDID** switch must be set to the **Int** position. If the EDID switch is set to the **Ext** position, then the **Audio** switch will have no effect on the audio output signal. See EDID Modes for more information on using the EDID.

Selecting the Audio Mode

Use this audio mode when all displays (and/or other sink devices) support *only* 2-channel LPCM audio.

- Use a paper clip or other pointed object to press and release the recessed Audio button, to toggle between 2-channel and multichannel audio modes.
- 2. The LED indicator will display the current audio mode.



Supported audio formats

Audio Format	Audio Format
LPCM 2CH	LPCM 8-channel
Dolby® Digital	Dolby® Digital Plus
Dolby® TrueHD	DTS®
DTS-HD Master Audio™	MLP (PPCM)



NOTE: When the Audio Mode is set the 2CH, the internal EDID will restrict the audio output to 2-channel LPCM, regardless of the audio input format.

EDID Modes

The 4K Ultra HD 4x4 Matrix for HDMI features EDID Management. Before the source can send video and/or audio to the display (sink), the source reads the EDID (Extended Display Identification Data) from the display (sink) devices connected to the matrix. The EDID contains information about what type of audio/video data that the source can send to each display device. The matrix can use either the downstream EDID (from the display/sink), the built-in internal EDID, or a custom EDID setting.

Available Modes

Internal EDID

Use this EDID mode if problems are encountered when using the external EDID. The built-in internal EDID provides the source device with a "generic" EDID which can be used by all display (sink) devices. The use of the internal EDID also provides control of the audio output format.

External EDID

When set to **Ext** mode, EDID data will be fetched from each display (or other sink device) that is connected to the outputs of the matrix. Once this information is gathered, the matrix "builds" an EDID based on the highest video and audio formats that are supported by <u>all</u> sink devices. This EDID is then transmitted to each source device

Custom EDID

When set to Custom mode, the matrix will use a customized EDID configuration selected by the user. For example, each input can be individually set to different EDID modes to suit the needs of each input.

Selecting the EDID Mode

- Use a paper clip or other pointed object to press and release the recessed EDID button, to toggle between internal, external, and custom EDID modes.
- 2. The LED indicator will display the current EDID mode.



See Table 2.1, on the next page, for specifications on the internal EDID.

EDID Modes

Table 2.1 - Internal EDID Specification

Video Data Block	Audio Data Block	Color Profile
640 x 480p 59/60 4:3 720 x 480p 59/60 4:3 720 x 480p 59/60 16:9 1280 x 720p 59/60 16:9 1920 x 1080i 59/60 16:9 1440 x 480i 59/60 4:3 1920 x 1080p 59/60 16:9 720 x 576p 50 4:3 720 x 576p 50 16:9 1280 x 720p 50 16:9 1920 x 1080i 50 16:9 1440 x 576i 50 4:3 1920 x 1080p 50 16:9 1920 x 1080p 50 16:9	LPCM 2-channel LPCM 8-channel Dolby® Digital DTS® Dolby® Digital Plus Dolby® TrueHD DTS-HD Master Audio™ MLP (PPCM)	YCbCr 4:4:4 YCbCr 4:2:2




4x4 Matrix for HDMI


03 Advanced Operation

RS-232 and IP Configuration	2
RS-232 Interface	22
RS-232 Settings	22
IP / UDP Configuration	23
Commands	24
Configuration	24
IP / Telnet Configuration	43
FST	5
Masking	58
Routing / Naming / +5V / Presets	60
Status	67
Web Interface	7
Using the built-in Web Server	7
Main ► Routing	72
Main ► I/O Status	7
Main ► Display Info	77
I/O Setup ▶ Preset Names	78
I/O Setup ► I/O Names	79
I/O Setup ► HPD Control	80
I/O Setup ► FST	
I/O Setup ► HDCP	82
Manage EDID ► Assign	83
Manage EDID ► Bank Names	86
Manage EDID ► Upload/Download	87
Configuration ► Change IP Settings	89
Configuration ► Telnet Login Settings	
Configuration ► UDP Connection Settings	9
Configuration ► Web Login Settings	92
Configuration ► System Configuration	93

RS-232 and IP Configuration

RS-232 Interface





Only TXD, RXD, and GND pins are used.

RS-232 Settings

Description	Setting
Baud rate	19200
Data bits	8
Parity	None
Stop bits	1
Hardware flow control	None



IMPORTANT: When sending Telnet or RS-232 commands, a carriage return (0d) and a line feed (0a) must be included at the end of the command.

IP / UDP Configuration

The 4K Ultra HD 4x4 Matrix for HDMI supports IP-based control using Telnet, UDP, or the built-in Web-based GUI. To set up IP control, the network settings for the 4K Ultra HD 4x4 Matrix for HDMI must be configured via RS-232. The default network settings for the matrix are as follows:

Description	IP Address / Port	Description	IP Address / Port
IP Address	192.168.1.72	UDP Port	23
Subnet	255.255.255.0	Local UDP Port	50007
Gateway	192.168.1.254	Remote UDP IP	192.168.1.255
HTTP Port	80	Remote UDP Port	50008

- Connect an RS-232 cable from the PC to the 4K Ultra HD 4x4 Matrix for HDMI.
 Also make sure that an Ethernet cable is connected between the matrix and the network.
- Launch a terminal emulation program (e.g. HyperTerminal) and use the RS-232 settings listed on the previous page.



NOTE: Depending upon the network, all related IP, Telnet, and UDP settings will need to be assigned. Consult your network administrator to obtain the proper settings.

- 3. Set the IP address for the matrix using the #sipadd command.
- 4. Set the subnet mask using the #snetmask command.
- 5. Set the gateway (router) IP address using the #sgateway command.
- 6. Set the Telnet listening port using the #set telnet port command.
- 7. Set the HTTP listening port using the #set http port command.
- Set the UDP remote IP address for the matrix using the #set_udp_remote_ip command.
- 9. Set the UDP listening port for the matrix using the #set udp port command.
- Set the UDP remote port for the matrix using the #set_udp_remote_port command
- Reboot the matrix to apply all changes, then type the IP address that was specified in step 3, in a Web browser to access the Web GUI. Use the same IP address to Telnet to the matrix.

Commands

Configuration

Command	Description
#echo	Enables / disables RS-232 feedback
#fadefault	Resets the routing and masking to factory-default settings
#hdcp	Enables / disables HDCP detection
#hdp_pulse	Cycles with HPD line on the specified output
#lock_edid	Locks the local EDID when the matrix is power-cycled
#power	Toggles the power on the matrix
#reboot	Reboots the matrix
#set_edid	Sets the specified EDID to an input or bank
#set_ir	Sets the IR channel for the matrix
#set_udp_port	Sets the local UDP listening port
#set_udp_remote_ip	Sets the remote UDP IP address
#set_udp_remote_port	Sets the remote UDP listening port
#show_hdcp	Displays the HDCP status of the specified input
#show_ir	Displays the current IR channel of the matrix
#show_out_colordpt	Displays the maximum color depth supported by the display (sink) device based on the EDID
#show_out_res	Displays the maximum video resolution supported by the display (sink) device, based on the EDID
#show_udp_port	Displays the current local UDP listening port
#show_udp_remote_ip	Displays the current remote UDP IP address
#show_udp_remote_port	Displays the current remote UDP listening port
#use_udp_enable	Enables / disables UDP access
n	Displays the routing status of the output
s	Routes the specified input to the output

Commands

#echo

The #echo command enables / disables (toggles) the RS-232 feedback.

Syntax:

#echo param1

Parameters:

param1

Value

[0 ... 1]

Value	Description	
0	Disable feedback	
1	Enable feedback	

Example:

#echo 1

LOCAL ECHO IS ON

Commands

#fadefault

The #fadefault command resets the matrix to factory-default settings. Outputs are unmasked and all IP and UDP settings are reset to default settings.

Syntax:

#fadefault

Parameters:

None

Example:

#fadefault

MATRIX WAS RESET TO FACTORY DEFAULTS.
RESET MATRIX ROUTING
RESET USER DEFINE NAME
RESET IP CONFIGURATIONS
RESET WEBGUI CONFIGURATIONS

MATRIX WILL REBOOT SHORTLY *REBOOT UNIT IN 3 SECONDS

GTB-HD4K2K-444 v0.7U

#hdcp

The #hdcp command enables / disables HDCP detection on the selected input.



NOTE: Some computers will enable HDCP if an HDCP-compliant display is detected. Set *param2* = 1 to force the computer to ignore detection of an HDCP-compliant display. Setting *param2* = 0 does *not* decrypt HDCP content.

Syntax:

#hdcp param1 param2

Parameters:

param1 param2 Input Value [1 ... 4] [0 ... 1]

Value	Description
0	Disable
1	Enable

Example:

#hdcp 2 0

HDCP ON INPUT 2 IS DISABLED

#hdcp 2 1

HDCP ON INPUT 2 IS ENABLED

#hdp pulse

The #hpd_pulse command cycles the HPD line on the specified input. Issuing this command is identical to physically disconnecting and reconnecting the cable between the source and the matrix. If param1 = 0, then all inputs will receive the HPD pulse.

Syntax:

#hpd pulse param1

Parameters:

param1 Input [1 ... 4]

Examples:

#hpd_pulse 1
HPD PULSE HAS BEEN SENT TO INPUT 1

#hpd_pulse 0

HPD PULSE HAS BEEN SENT TO ALL INPUTS

#lock edid

The $\#lock_edid$ command secures the Local EDID by disabling the automatic loading of the downstream EDID when the matrix is powered.

Syntax:

#lock edid param1

Parameters:

param1

Value

[0 ... 1]

Value	Description	
0	Disable	
1	Enable	

Examples:

#lock_edid 0
MATRIX EDID IS UNLOCKED

#lock_edid 1
MATRIX EDID IS LOCKED

#power

The #power command toggles power on the matrix.

Syntax:

#power param1

Parameters:

param1

Value

[0 ... 1]

Value	Description
0	Off
1	On

Examples:

#power 0

MATRIX IS OFF

#power 1

MATRIX IS ON

GTB-HD4K2K-444 v0.7U

Commands

#reboot

The #reboot command reboots the matrix. Executing this command is the equivalent of disconnecting and reconnecting the AC power cord, on the back of the matrix. The matrix must be rebooted after changing any of the IP settings.

Syntax:								
#reboot	t							
<u>Paramet</u> None	<u>ers</u> :							
Example	:							
#reboot	t							
MATRIX	WILL	REBOOT	SHORTLY	*REBOOT	UNIT	IN	3	SECONDS

#set edid

The #set edid command sets the specified EDID type to an input or bank.

Syntax:

#set edid param1 param2 param3 param4

Parameters:

param1

Source

[STRING]

Source	Description
default	Uses default (Internal) EDID
dynamic	Uses dynamic EDID
bank	Uses EDID bank
output	Uses EDID on Output (sink)

param2

Source

[8 ... 8]

Source	Description
0	Default EDID / Dynamic
1 8	EDID bank
1 2	Output

param3

Target

[STRING]

Target	Description
input	Specifies an input
bank	Specifies an EDID bank

param4

Target

[1 ... 8]

Value	Description
1 4	Input
1 8	EDID bank

(continued on next page)

Notes:

If param1 = default or param1 = dynamic, then set param2 = 0.

Examples:

```
#set_edid default 0 input 4
COPY DEFAULT EDID TO INPUT 4

#set_edid output 2 input 3
COPY OUTPUT 2 EDID TO INPUT 3

#set_edid dynamic 0 input 2
COPY DYNAMIC EDID TO INPUT 2

#set_edid bank 3 input 4
COPY BANK 3 EDID TO INPUT 4
```

#set ir

The $\#set_ir$ command sets the IR channel for the matrix. The default IR channel setting is 0. The IR channel for the switch can also be set under the **Configuration** tab within the Web interface. See Configuration > System Configuration for more information.

Syntax:

#set ir param1

Parameters:

param1

Channel

[0 ... 3]

Channel	Description
0	Set IR channel 0
1	Set IR channel 1
2	Set IR channel 2
3	Set IR channel 3

Example:

#set ir 1

IR CHANNEL IS SET TO CHANNEL 1

#set udp port

The #set_udp_port command sets the local UDP server listening port. The default port setting is 21. The matrix must be rebooted after executing this command. Use the #show_udp_port command to display the current local UDP listening port.

Syntax:

#set udp port param1

Parameters:

param1 Port [0 ... 65535]

Example:

#set_udp_port 56

UDP COMMUNICATION PORT 56 IS SET. PLEASE REBOOT THE UNIT.

#set udp remote ip

The #set_udp_remote_ip command sets the remote UDP IP address. The IP address must be specified using dot-decimal notation. The default UDP remote IP address is 192.168.1.255. The matrix must be rebooted after executing this command.

Syntax:

#set udp remote ip param1

Parameters:

param1

UDP address

Example:

```
#set_udp_remote_ip 192.168.1.227
```

REMOTE UDP IP ADDRESS 192.168.1.227 IS SET.

#set_udp_remote_port

The #set_udp_remote_port command sets the remote UDP listening port. The default remote UDP listening port is 50008. The matrix must be rebooted after executing this command.

Syntax:

#set udp remote port param1

Parameters:

param1 Port [0 ... 65535]

Example:

#set udp remote port 50008

REMOTE UDP COMMUNICATION PORT 50008 IS SET.

#show hdcp

The #show hdcp command displays the HDCP status on the specified input.

Syntax:

#show hdcp param1

Parameters:

param1 Input [1 ... 4]

Example:

#show hdcp 1

HDCP ON INPUT 1 IS ENABLED

#show ir

The #show ir command displays the IR channel of the matrix.

Syntax:

#show ir

Parameters:

None

Example:

#show_ir

CURRENT IR CHANNEL IS: 1

#show out colordpt

The #show_out_colordpt command displays the highest color depth supported by the specified display based on the EDID. If no display is attached to the specified output, then the command will return THERE IS NO INFORMATION FROM OUTPUT [X].

Syntax:

#show out colordpt param1

Parameters:

param1 Output [1 ... 4]

Example:

```
#show_out_colordpt 1
OUTPUT 1 HIGHEST COLOR DEPTH IS 8 BITS
```

#show_out_res

The #show_out_res command displays the highest resolution supported by the specified display based on the EDID. If no display is attached to the specified output, then the command will return THERE IS NO INFORMATION FROM OUTPUT [X].

Syntax:

#show out res

Parameters:

param1 Output [1 ... 4]

Example:

```
#show_out_res 1
```

OUTPUT 1 HIGHEST RESOLUTION IS 1600x900

#show udp port

The #show_udp_port command displays the current local UDP listening port. Use the #set_udp_port command to set the local UDP listening port.

Syntax:

#show udp port

Parameters:

None

Example:

```
#show_udp_port

UDP COMMUNICATION PORT IS 56
```

#show_udp_remote_ip

The <code>#show_udp_remote_ip</code> command displays the remote UDP IP address. Use the <code>#set_udp_remote_ip</code> command to set the remote UDP IP address.

Syntax:

```
#set udp remote ip param1
```

Parameters:

None

Example:

```
#set_udp_remote_ip 192.168.1.227
REMOTE UDP IP ADDRESS IS : 192.168.1.227
```

#show udp remote port

The #show_udp_remote_port command displays the remote UDP listening port. Use the #set_udp_remote_port to set the remote UDP listening port.

Syntax:

#show udp remote port param1

Parameters:

None

Example:

```
#show_udp_remote_port
REMOTE UDP COMMUNICATION PORT IS 50008
```

#use_udp_enable

The #use udp enable command enables or disables UDP access mode.

Syntax:

#use udp enable param1

Parameters:

param1 Value [0 ... 1]

Value	Description
0	Disable UDP
1	Enable UDP

Example:

#use udp enable 1

UDP ACCESS IS ENABLED

n

The n command displays the routing status of the output. Do not precede the n command with the "#" symbol. param1 must be set to 1. If param1 = 0, then the routing state for all outputs is returned.

Syntax:

n param1

Parameters:

param1 Output [0 ... 4]

Examples:

To see how this command works, we have already routed Input 3 to Output 1. Now, we'll use the $\bf n$ command to query the routing state of Output 1:

n 4 D3

The feedback is abbreviated as: "D3". This indicates that Input 3 is routed to Output 4.

The following command returns the routing state for all outputs:

n 0

A2B4C1D3

The feedback is abbreviated as: "A2B2C1D3". This indicates that Input 2 is routed to Output 1, Input 4 is routed to Output 2, Input 1 is routed to Output 3, and Input 3 is routed to Output 4.

Advanced Operation

Commands

s

The ${\rm s}$ command routes the specified input to all outputs. Do not precede this command with the "#" symbol.

Syntax:

s param1

Parameters:

param1 Input [1 ... 4]

Example:

s 2

INPUT 2 IS ROUTED TO ALL OUTPUTS

IP / Telnet Configuration

Command	Description
#display_telnet_welcome	Enable / disable the Telnet welcome message
#ipconfig	Displays the current IP configuration
#resetip	Resets the IP configuration to factory-default settings
#set_http_port	Sets the Web server listening port
#set_telnet_pass	Sets the Telnet password
#set_telnet_port	Sets the Telnet listening port for the matrix
#set_webui_ad_pass	Sets the Administrator password for the Web GUI
#set_webui_op_pass	Sets the Operator password for the Web GUI
#sgateway	Sets the IP address of the (router) gateway
#show_gateway	Displays the current gateway address of the matrix
#show_http_port	Displays the current HTTP listening port of the matrix
#show_ip	Displays the current IP address of the matrix
#show_mac_addr	Displays the MAC address of the matrix
#show_netmask	Displays the current net mask of the matrix
#show_telnet_port	Displays the Telnet listening port
#show_telnet_username	Displays the user name of the current Telnet session
#show_ver_data	Displays the current software and hardware version
#sipadd	Sets the IP address of the matrix
#snetmask	Sets the Net mask of the matrix
#use_telnet_pass	Force password during Telnet sessions

#display telnet welcome

The #display_telnet_welcome command enables / disables the Telnet welcome message during a Telnet session.

Syntax:

#display telnet welcome param1

Parameters:

param1

Value

[0 ... 1]

Value	Description	
0	Disable welcome message	
1	Enable welcome message	

Example:

#display_telnet_welcome 1

TELNET WELCOME SCREEN IS ENABLED

When enabled and a Telnet session has been started, the following will appear:

Welcome to GTB-HD4K2K-444 TELNET

telnet->

#ipconfig

The #ipconfig command displays the current TCP settings.

Syntax:

#ipconfig

Parameters:

None

Example:

#ipconfig

IP Configuration is :
IP: 192.168.2.190
NETMASK: 255.255.255.0
GATEWAY: 192.168.1.254

#resetip

The #resetip command resets the IP configuration to factory-default settings. The matrix must be rebooted after executing this command.

Syntax:

#resetip

Parameters:

None

Syntax:

#resetip

IP CONFIGURATION WAS RESET TO FACTORY DEFAULTS

IP: 192.168.1.72

Netmask: 255.255.255.0 Gateway: 192.168.1.1

#set http port

The $\#set_http_port$ command specifies the Web server listening port. The matrix must be rebooted after executing this command. The default port setting is 80. Use the $\#show_http_port$ command to display the current HTTP listening port.

Syntax:

#set http port param1

Parameters:

param1 Port [1 ... 1024]

Example:

#set http port 82

HTTP COMMUNICATION PORT 82 IS SET. PLEASE REBOOT THE UNIT.

#set_telnet_pass

The #set_telnet_pass command sets the Telnet password. The password is case-sensitive and cannot exceed 8 characters in length. The default password is Admin.

Syntax:

#set telnet pass param1

Parameters:

param1 Password

Example:

#set telnet pass 3ver3st

TELNET INTERFACE PASSWORD IS SET

#set telnet port

The #set_telnet_port command sets the Telnet listening port. The matrix must be rebooted after executing this command. The default port setting is 23. Use the #show_telnet_port command to display the current Telnet listening port.

Syntax:

#set telnet port param1

Parameters:

param1 Port [1 ... 1024]

Example:

#set_telnet_port 24

TELNET COMMUNCATION PORT 24 IS SET. PLEASE REBOOT THE UNIT.

#set_webui_ad_pass

The #set_webui_ad_pass command sets the Administrator password for the Web GUI. The password is case-sensitive and cannot exceed 7 characters in length. The default password is Admin.

Syntax:

#set_webui_ad_pass param1

Parameters:

param1 Password

Example:

#set webui ad pass bossman

WEB UI ADMINISTRATOR PASSWORD IS SET

#set webui op pass

The #set_webui_ad_pass command sets the Operator password for the Web GUI. The default password is Admin.

Syntax:

#set webui op pass param1

Parameters:

param1 Password

Example:

#set_webui_op_pass minion

WEB UI OPERATOR PASSWORD IS SET

#sgateway

The #sgateway command sets the gateway address. The gateway must be typed using dot-decimal notation. The matrix must be rebooted after executing this command. The default gateway is 192.168.1.1.

Syntax:

#sgateway param1

Parameters:

param1 Gateway

Example:

#sgateway 192.168.1.5

GATEWAY ADDRESS 192.168.1.5 IS SET. PLEASE REBOOT THE UNIT.

#show gateway

The #show_gateway command displays the current gateway address of the matrix. Use the #sgateway command to set the gateway address.

Syntax:

#show gateway

Parameters:

None

Example:

```
#show_gateway
GATEWAY ADDRESS IS: 192.168.1.5
```

#show_http_port

The #show_http_port command displays the current HTTP listening port of the matrix. Use the #set http port command to set the HTTP listening port.

Syntax:

#show http port

Parameters:

None

Example:

```
#show_http_port
HTTP COMMUNICATION PORT IS: 82
```

#show ip

The <code>#show_ip</code> command displays the current IP address of the matrix. Use the <code>#sipadd</code> command to set the IP address.

Syntax:

#show ip

Parameters:

None

Example:

#show ip

IP ADDRESS IS: 192.168.1.239

#show_mac_addr

The #show mac addr command displays the MAC address of the matrix.

Syntax:

#show mac addr

Parameters:

None

Example:

```
#show mac addr
```

MAC ADDRESS IS: 00-1c-91-03-00-02

#show netmask

The #show_netmask command displays the current net mask of the matrix. Use the #snetmask command to set the net mask.

Syntax:

#show netmask

Parameters:

None

Example:

#show netmask

NETMASK ADDRESS IS: 255.255.255.0

#show_telnet_port

The <code>#show_telnet_port</code> command displays the current Telnet port of the matrix. Use the <code>#set_telnet_port</code> command to set the Telnet listening port.

Syntax:

#set telnet port param1

Parameters:

param1 Port [1 ... 65535]

Example:

#set telnet port 24

TELNET COMMUNCATION PORT 24 IS SET. PLEASE REBOOT THE UNIT.

#show telnet username

The #show_telnet_username command displays the user name of the current Telnet session.

Syntax:

#show_telnet_username

Parameters:

None

Example:

```
#show_telnet_username
USER NAME FOR TELNET IS : Admin
```

#show_ver_data

The #show ver data command displays the current software and hardware version.

Syntax:

#show ver data

Parameters:

None

Example:

```
#show ver data
```

SOFTWARE AND HARDWARE VERSION: v0.7U PCB-1979*B

#sipadd

The #sipadd command sets the IP address of the matrix. The IP address must be entered using dot-decimal notation. The matrix must be rebooted after executing this command. The default IP address is 192.168.1.72. Use the #show_ip or #ipconfig command to display the current IP address of the matrix.

Syntax:

#sipadd param1

Parameters:

param1

IP address

Example:

#sipadd 192.168.2.190

IP ADDRESS 192.168.2.190 IS SET.

#snetmask

The #snetmask command sets the subnet mask. The net mask must be entered using dot-decimal notation. The matrix must be rebooted after executing this command. The default net mask is 255.255.255.0. Use the #show_netmask or #ipconfig command to display the current net mask of the matrix.

Syntax:

#snetmask param1

Parameters:

param1 Net mask

Example:

#snetmask 255.255.0.0

NETMASK ADDRESS 255.255.0.0 IS SET. PLEASE REBOOT THE UNIT.

#use telnet pass

The $\#use_telnet_pass$ command forces the password credentials for each Telnet session. The default setting is 0 (disabled). Use the $\#set_telnet_pass$ command to set the Telnet password.

Syntax:

#use telnet pass param1

Parameters:

param1

Value

[0 ... 1]

Value	Description
0	Disable password
1	Enable password

Example:

#use telnet pass 1

TELNET INTERFACE PASSWORD IS ENABLED

FST

Command	Description	
#fst_fast	Sets the specified inputs to Fast switching mode	
#fst_slow	Sets the specified inputs to Slow switching mode	
#show_fst	Displays the current switching mode for the specified input	

#fst fast

The #fst_fast command sets the specified inputs to *fast* switching mode. By default, all inputs are set to *fast* switching mode. If *param1* = 0, then all inputs are set to *fast* switching mode.

Syntax:

```
#fst fast param1 [...param4]
```

Parameters:

param1 Input [0 ... 4]

Examples:

```
#fst_fast 1
INPUT 1 IS SET TO FAST MODE

#fst_fast 0
ALL INPUTS ARE SET TO FAST MODE
```

#fst slow

The #fst_slow command sets the specified inputs to slow switching mode. By default, all inputs are set to fast switching mode. If param1 = 0, then all inputs are set to slow switching mode.

Syntax:

#fst slow param1

Parameters:

param1 Input [0 ... 4]

Examples:

#fst slow 2

INPUT 2 IS SET TO SLOW MODE

#fst slow 0

ALL INPUTS ARE SET TO SLOW MODE

#show fst

The #show_fst command displays the switching mode for the specified input. If param1 = 0, then the switching mode for all inputs are displayed.

Syntax:

#show fst param1

Parameters:

param1 Input [0 ... 4]

Examples:

#show fst 2

INPUT 2 FST STATUS IS SLOW

#show_fst 0

INPUT 1 FST STATUS IS SLOW INPUT 2 FST STATUS IS FAST INPUT 3 FST STATUS IS SLOW INPUT 4 FST STATUS IS SLOW

Masking

Command	Description	
#mask	Masks the video on the specified output(s)	
#show_mask	Displays the current masking status of each output	
#unmask	Unmasks the specified outputs	

#mask

The #mask command masks the video on the specified output(s). Use the #unmask command to disable output masking. If param1 = 0, then all outputs are masked.

Syntax:

#mask param1

Parameters:

param1 Output [0 ... 4]

Example:

#mask 1

OUTPUT 1 IS MASKED

#unmask

The #unmask command unmasks the specified output(s). Use the #mask command to mask the specified output(s). If param1 = 0, then all outputs are unmasked.

Syntax:

#unmask param1

Parameters:

param1 Output [0 ... 4]

Example:

#unmask 2

OUTPUT 2 IS UNMASKED

#show_mask

The #show mask command displays the mask status of the specified output.

Syntax:

#show mask param1

Parameters:

param1 Output [1 ... 4]

Example:

#show mask 1

OUTPUT 1 (OUTPUT1) IS UNMASKED

Routing / Naming / +5V / Presets

Command	Description	
#lock_matrix	Locks / unlocks the matrix	
#recall_preset	Loads the specified routing state	
#save_preset	Saves the current routing state to a preset	
#set_bank_name	Assigns a name to the specified EDID bank	
#set_input_name	Assigns a name to the specified input	
#set_output_name	Assigns a name to the specified output	
#set_preset_name	Assigns a name to the specified preset	
#set_preset_name	Displays the name for the specified EDID bank	
#show_input_name	Displays the name of the specified input	
#show_output_name	Displays the name of the output	
#show_preset_name	Displays the name of the specified preset	
#show_r	Displays the routing status of the output	
r	Routes the specified input to the output	

#lock_matrix

The #lock_matrix command locks / unlocks the matrix. When the matrix is locked, all functions are disabled including the front panel, RS-232, and Telnet.

Syntax:

#lock matrix param1

Parameters:

param1 Value [0 ... 1]

Value	Description
0	Unlock
1	Lock

Example:

#lock_matrix 1
MATRIX IS LOCKED

#recall preset

The #recall preset command loads the routing preset.

Syntax:

#recall preset param1

Parameters:

param1 Preset [1 ... 8]

Example:

#recall preset 2

RECALLED THE ROUTING STATE SAVED TO PRESET 2

#save_preset

The #save preset command saves the current routing state to a specified preset.

Syntax:

#save preset param1

Parameters:

param1 Preset [1 ... 8]

Example:

#save preset 3

CURRENT ROUTING STATE IS SAVED TO PRESET 3

#set bank name

The #set bank name command names the specified bank.

Syntax:

#set bank name param1 param2

Parameters:

param1	Bank	[1 8]
param2	Name	

Example:

```
#set_bank_name 5 Dell_24
Dell 24 NAME IS ASSIGNED TO BANK 5
```

#set_input_name

The #set input name command assigns a name to the specified input on the matrix.

Syntax:

#set input name param1 param2

Parameters:

param1	Input	[1 4]
param2	Name	

Example:

```
#set_input_name 3 Blu-ray
Blu-ray NAME IS ASSIGNED TO INPUT 3
```

#set output name

The <code>#set_output_name</code> command assigns a name to the output on the matrix. The name of the output is limited to 15 characters. Names longer than 15 characters will be truncated. To name an output, use the <code>#set_output_name</code> command.

Syntax:

#set output name param1 param2

Parameters:

param1 Output [1 ... 4]
param2 Name

Example:

#set_output_name 3 Sony_XBR
Sony XBR NAME IS ASSIGNED TO OUTPUT 2

#set_preset_name

The #set_preset_name command assigns a name to the specified preset. The name of the preset is limited to 10 characters. Names longer than 10 characters will be truncated. To display the name of a preset, use the #show preset name command.

Syntax:

#set preset name param1 param2

Parameters:

param1 Preset [1 ... 8] param2 Name

Example:

```
#set_preset_name 4 BR_to_Out2
BR to Out2 NAME IS ASSIGNED TO PRESET 4
```

#show bank name

The $\# show_bank_name$ command displays the name for the specified EDID bank. To name an EDID bank, use the $\# set_bank_name$ command.

Syntax:

#show bank name param1

Parameters:

param1 Bank [1 ... 8]

Example:

```
#show_bank_name 5
```

THE NAME FOR BANK 5 IS: Dell24

#show_input_name

The #show_input_name command displays the name of the specified input. To name an input, use the #set_input_name command.

Syntax:

#show input name param1

Parameters:

param1 Input [1 ... 4]

Example:

```
#show input name 3
```

THE NAME FOR INPUT 3 IS : Blu-ray

#show output name

The $\# \text{show_output_name}$ command displays the name of the output. To name an output, use the # set output name command.

Syntax:

#show output name param1

Parameters:

param1 Output [1 ... 4]

Example:

```
#show_output_name 2
THE NAME FOR OUTPUT 2 IS : Sony XBR
```

#show_preset_name

The <code>#show_preset_name</code> command displays the name for the specified preset. To assign a name to a preset, use the <code>#set_preset_name</code> command.

Syntax:

#show preset name param1

Parameters:

param1 Preset [1 ... 8]

Example:

```
#show_preset_name 4
THE NAME FOR PRESET 4 IS : BR to Out2
```

#show r

The #show_r command displays the current routing status of the output. The name of the output and input are displayed.

Syntax:

#show r param1

Parameters:

param1 Output [1 ... 4]

Example:

#show r 2

OUTPUT 2 (Sony XBR) IS ROUTED TO INPUT 3 (Blu-ray)

r

The r command routes the specified input to the output. Do not precede this command with the "#" symbol. Also see the s command. If param2 = 0, then the specified input (param1) will be routed to all outputs. param3 is optional but can be used to specify another output on the command line.

Syntax:

```
r param1 param2 [param3]
```

Parameters:

param1	Input	[1 4]
param2	Output	[0 4]
param3	Output	[1 4]

Example:

r 3 1 2

INPUT 3 IS ROUTED TO OUTPUT(S) 1 , 2

Status

Command	Description
#help	Displays a list of available RS-232 / Telnet commands
#show_fw	Displays the current version of firmware
#show_hpd	Displays the HPD status of the specified input
#show_rsense	Displays the RSENSE status of the output
m	Displays the current routing status of the matrix

#help

The #help command displays the list of available RS-232 / Telnet commands. Help on a specific command can be displayed when using param1.

Syntax:

#help param1

Parameters:

param1

Command name (optional)

Example:

#help #sipadd

#SIPADD PARAM 1 SET THE IP ADDRESS

PARAM 1 = XXX.XXX.XXX.XXX

WHERE XXX: 0 - 255

#show fw

The #show fw command displays the current version of matrix firmware.

Syntax:

#show fw

Parameters:

None

Example:

#show_fw

FIRMWARE VERSION = GTB-HD4K2K-444 v0.7U

#show hpd

The #show_hpd command displays the HPD status of the specified output. The name of the output is included.

Syntax:

#show hpd param1

Parameters:

param1 Output [1 ... 4]

Example:

#show hpd 2

HPD OF OUTPUT 2 (Sony XBR) IS HIGH

#show rsense

The #show rsense command displays the RSENSE status of the specified output.

Syntax:

#show rsense param1

Parameters:

param1 Output [1 ... 4]

Example:

#show rsense 2

RSENSE OF OUTPUT 2 (Sony_XBR) IS HIGH

m

The m command displays the current routing status of the matrix. Masking and locking status of the matrix is also provided. Do not precede the m command with the "#" symbol.

Syntax:

m

Parameters:

None

Example:

m


Out: 1 2 3 4 In: 1 3 1 3

OUTPUT 1 IS UNMASKED OUTPUT 2 IS UNMASKED OUTPUT 3 IS UNMASKED OUTPUT 4 IS UNMASKED MATRIX IS UNLOCKED

Web Interface

Using the built-in Web Server

Access the built-in Web interface by entering the IP address of the matrix that was specified in step 3 under IP / UDP Configuration. Once connected to the matrix, the login screen will be displayed.



Username

Select the username from the drop-down list.

Options:

Operator, Administrator

Administrator login provides unrestricted access to all features and settings. Operator login limits access to matrix routing, display information, and routing preset features.

Password


Enter the password for the associated username. The password can also be set using RS-232 or Telnet. See the <code>#set_webui_op_pass</code> and the <code>#set_webui_ad_pass</code> commands. The password is masked when it is entered


The Web GUI is divided into four main pages: **Main**, **I/O Setup**, **Manage EDID**, and **Configuration**. Each main page is represented by a tab at the top-most portion of the screen. The **Main**, **I/O Setup**, and **Manage EDID** pages have their own set of sub-tabs. Click on the desired tab / sub-tab to open the desired page.



NOTE: In order to view all four tabs at the top of the screen, the user must be logged in as "Administrator". If logged-in as "Operator", only the **Main** tab will be visible.

Main > Routing





Name (Outputs)

The name of the output.

This name can be changed using the #set_output_name command or through the I/O Setup > I/O Names page of the Web interface.

Outputs (Outputs)

Check to select the currently active output.

Input # (Inputs)

Click the radio button next to the desired input to be routed.

Name (Inputs)

Displays the current name of the input.


This name can be changed using the #set_input_name command or through the I/O Setup > I/O Names page of the Web interface.


Route

Click the Route button to route the selected input to the select output(s).


Lock Matrix

Locks / unlocks the matrix. Once the matrix is locked, settings cannot be changed using the front-panel buttons or through the Web GUI. When the matrix is locked, the button text will read "Unlock Matrix" and a red bar will appear across the top portion of the screen with the text "Matrix is LOCKED". Click the "Unlock Matrix" button to unlock the matrix.





Main > I/O Status



Output

Displays the state of each output for each of the following: Name, RSENSE, Mask, HPD (Hot-Plug Detect), HDCP, and Video Mode.

Name

Displays the name of the output. The name of the output can be changed using the #set_output_name command or through the I/O Setup > I/O Names page of the Web interface.

RSENSE

Displays the current Rsense state.

Mask

Displays the masking state of each output.

HPD


Displays the Hot-Plug Detect (HPD) state of each output.

HDCP

Indicates if HDCP-detection is enabled or disabled on each output.

Video Mode


Displays the current output video mode.



Input


Displays the state of each input for each of the following: Input name, Color Depth, Color Space, HDCP, 3D, Active Signal, Vertical Resolution, Horizontal Resolution, Progressive / Interlaced, Refresh Rate, and Video Mode.

Main > Display Info



Choose EDID


Select the EDID from the drop-down list. The selected EDID will be copied from the Output or selected EDID Bank to the desired input(s) and used by the source.



Feature / Audio Formats

Displays the capabilities of the display (or sink device), based on the EDID.

I/O Setup > Preset Names



Save Changes Cancel			
8	PRESET8		
7	PRESET7		
6	PRESET6		
5	PRESET5		
4	PRESET4		
3	PRESET3		
2	PRESET2		
1	PRESET1		

Preset #

The number of each preset.

Name

Type the desired name of each preset in these fields.


Save Changes

Saves the current changes to the name of the preset(s).

Cancel

Restores the previous name or each preset, if a change was made.

I/O Setup > I/O Names



Edit Output & Input Names				
Output	Name	Input #	Name	
1	OUTPUT1	1	INPUT1	
2	OUTPUT2	2	INPUT2	
3	OUTPUT3	3	INPUT3	
4	OUTPUT4	4	INPUT4	
		Save Chan	ges Cancel	

Output

The number of the output.

Name (Output)

Type the desired name of each output in these fields.

Input

The number of each input.

Name (Input #)

Type the desired name of each the input in these fields.


Save Changes

Saves the current changes to the name of the output and/or input(s).

Cancel

Restores the previous name or each output and/or input(s), if a change was made.

I/O Setup > HPD Control



Input

The number of the input.


Name

The name of the input. The name of each input can be changed using the #set_input_name command or through the I/O Setup > I/O Names page of the Web interface.

Pulse

Click the Pulse button to cycle the HPD line on the desired input. This is the equivalent of physically disconnecting and reconnecting the HDMI cable between the source device and the matrix.

I/O Setup > FST



FST

Displays the switching state of each input.

Input

The name of the input.


Name

The name of the input. The name of each input can be changed using the <code>#set_input_name</code> command or through the I/O Setup > I/O Names page of the Web interface.

I/O Setup > HDCP



NOTE: Some computers will enable HDCP if an HDCP-compliant display is detected. Check the box under the Disable column to force the computer to ignore detection of an HDCP-compliant display. The Disable feature does <u>not</u> decrypt HDCP content.



Disable

Check the box under the Disable column to force the computer to ignore HDCP-detection.

Input

The number of the input.

Name

The name of the input. The name of each input can be changed using the #set_input_name command or through the I/O Setup > I/O Names page of the Web interface.

Check All

Places a check mark in all boxes under the Disable column

Clear All

Clears all check marks from the Disable column.

Set

Click this button to save changes for all input(s).

Cancel


Cancels the current operation and ignores changes for each input, if a change was made.

Manage EDID > Assign

Lock EDID


Secures the Local EDID and disables automatic EDID loading during power-up.


If the **Lock EDID** button is clicked (enabled), the "EDID locked on power cycle" message will be displayed in red. The local EDID information will now be locked once the matrix is rebooted. Click the **Unlock EDID** button to disable the Lock EDID feature.



Copy EDID From

Select the EDID from the drop-down list. The EDID will be copied from the Output or selected EDID bank to the destination





Copy To

Place a check mark in the desired check box to select or deselect the desired input(s). These check-boxes can only be used when the EDID Mode is set to Custom - User.

EDID Modes

Select the EDID mode from the drop-down list.

Options		
Internal - 1080p 2 ch audio		
Internal - 1080p Multi ch		
External - Output1		
Custom - Last Output		
Custom - User		

When the EDID is set to Custom mode, the matrix will use a customized EDID configuration selected by the user. For example, each input can be individually set to different EDID modes to suit the needs of each input.

Inputs				
lodes	Input #	Name	EDID Source	EDID Name
)p 2 ch audio ▼	1	INPUT1	Int EDID(2CH)	HDMI-DA
)p 2 ch audio ▼	2	INPUT2	Int EDID(2CH)	HDMI-DA
)p 2 ch audio ▼	3	INPUT3	Int EDID(2CH)	HDMI-DA
)p 2 ch audio ▼	4	INPUT4	Int EDID(2CH)	HDMI-DA

Input

The number of the input.

Name

The name of the input. The name of the input can be changed using the #set_input_name command or through the I/O Setup > I/O Names page of the Web interface.

EDID Source

The current EDID source being used.


EDID Name

The name of the EDID.

Clear All

Clears all check marks from the Copy To column.

Manage EDID > Bank Names



Bank

Indicates the EDID bank number.

Name

Type the desired name of the EDID bank in this field.

Save Changes

Saves the current name change to the EDID bank(s).

Cancel

Restores the previous names for each EDID bank, if changes were made.

Manage EDID > Upload/Download

Browse...

Click this button to select the EDID file to be uploaded.


Select Bank Location


Click this drop-down list to select the bank to where the EDID will be uploaded.



Upload


Click this button to upload the EDID to the specified bank.





Select EDID File to Download


Click this box to select the EDID that is to be saved to a file. The EDID file will be saved in binary (.bin) format.



Download

Click this button to download the selected EDID to a file.

Configuration > Change IP Settings



Change IP Settings

Assigns the IP address, subnet, gateway, HTTP listening port, Telnet port, and UDP port. The MAC address cannot be changed.

Save Settings

Saves the current settings for the Change IP Settings. After clicking this button, the Web interface will display a dialog indicating that the matrix must be rebooted for changes to take effect.

Set Defaults

Click this button to restore the factory-default IP settings. After clicking this button, the Web interface will display a dialog indicating that the matrix must be rebooted for changes to take effect.

Configuration > Telnet Login Settings



Old Password

Type the current (old) password in this field.

New Password

Type the new password in this field.

Force Password on Connect

Click this check box to have the matrix prompt for a password each time a Telnet session is started. This box *must* be checked in order to change the Telnet Login credentials.


Show Login Message on Connect

Click this check box to have the matrix display the Telnet welcome message each time a Telnet session is started. The welcome message appears as: "Welcome to GTB-HD4K2K-444 TELNET".

Save Settings

Saves the current changes to the Telnet Login Settings.

Configuration > UDP Connection Settings



Remote UDP IP Address

Type the remote UDP IP address in this text box.

Remote UDP Port

Enter the remote UDP port in this text box.

Enable UDP Access

Check this box to enable UDP access. If this box is unchecked, the UDP access will be unavailable.

Configuration > Web Login Settings



Username

Click this drop-down list to select the user name. The credentials for the selected user name can now be changed.

Old Password

Type the current (old) password in this field.

New Password

Type the new password in this field.

Confirm Password

Re-type the new password in this field.

Save Settings

Saves the current changes to the Web Login Settings.


Configuration > System Configuration



Download

Click this button to download the current matrix configuration to a file.

(continued on next page)




Restore

Uploads the selected configuration file to the matrix.

Update

Updates the matrix with the selected firmware file.



IR Channel -

Click this drop-down list to set the desired IR channel for the matrix. Note that the matrix and the included IR remote control must be set to the same channel in order to work properly. The IR channel for the matrix can also be set using the \sharp set ir command.



Save

Click this button to save any changes made to the IR channel setting.

Reset

Click this button to set the matrix to factory-default settings. The IP settings are preserved.

Reboot

Click this button to reboot the matrix.



04 Appendix

Wall Mounting Instructions	98
Firmware Upgrade Procedure	
Upgrading using the Web interface	99
Upgrading using USB	100
Specifications	101

Wall Mounting Instructions

The 4K Ultra HD 4x4 Matrix for HDMI should be mounted vertically in a wall or cabinet with wood/drywall screws as shown in the diagram above. There should be an inch or two of clearance between the edges of the unit and any walls or vertical surfaces to allow for enough clearance for insertion and retraction of cables at the HDMI connectors.

For installation on a drywall surface, use a #6 drywall screw. It is recommended when installing on a drywall surface that studs be used to secure the matrix should undue stress be applied when connecting and disconnecting HDMI cables.



Firmware Upgrade Procedure

Upgrading using the Web interface



IMPORTANT: DO NOT power-off or disconnect the AC power cord from the matrix, at any time, during the firmware upgrade process.

- 1. Download the firmware update from the Support section of the Gefen Web site.
- 2 Extract the firmware file from the 7IP file
- Power-ON the 4K Ultra HD 4x4 Matrix for HDMI.
- Connect an Ethernet cable between the matrix and the computer running the Web interface.

It is unnecessary to disconnect any cables or extenders from the 4K Ultra HD 4x4 Matrix for HDMI during the update process.

- Click the Configuration tab in the Web interface and click the Browse... button under the System Configuration section.
- 6. Select the firmware file and click the **Update** button.
- The matrix will display a prompt to verify that the current firmware will be overwritten. Click the **OK** button on the dialog box to begin uploading the firmware file.
- 8. The matrix will begin the upgrade process. This process will take several minutes. The upgrade process may be monitored using the RS-232 interface.
- After the matrix has been updated, the unit will automatically initiate a countdown to reboot.
- 10. After the matrix reboots, the firmware upgrade process will be complete.

Upgrading using USB



IMPORTANT: *DO NOT* power-off or disconnect the AC power cord from the matrix, at any time, during the firmware upgrade process.

- 1. Download the firmware update from the Support section of the Gefen Web site.
- 2 Power-ON the 4K Ultra HD 4x4 Matrix for HDMI
- Connect a USB cable between the computer and the 4K Ultra HD 4x4 Matrix for HDMI.

It is unnecessary to disconnect any cables or extenders from the 4K Ultra HD 4x4 Matrix for HDMI during the update process.

- Once the computer is able to connect to the 4K Ultra HD 4x4 Matrix for HDMI, a removable-disk icon will be displayed under My Computer.
- 5. Extract the firmware file from the .ZIP file and drag the .bin file to the Removable Disk.
- 6. Disconnect the USB cable from the computer.
- After the matrix has been updated, the unit will automatically initiate a countdown to reboot.
- 8. After the matrix reboots, the firmware upgrade process will be complete.

Specifications

Supported Formats	
Resolutions (max.)	Ultra HD 4K x 2K (3840 x 2160 @ 30 Hz) 1080p Full HD
Audio	LPCM 7.1 Dolby® TrueHD DTS-HD Master Audio™

Electrical		
Maximum Pixel Clock	•	300 MHz
Routing Selectors	•	4 x Tact-type, push-button
FST Selector	•	1 x Tact-type, recessed push-button
Audio Selector	•	1 x Tact-type, recessed push-button
EDID Selector	•	1 x Tact-type, recessed push-button
Power Indicator	•	1 x LED, blue
FST Indicators		2 x LED, green
Audio Indicators	•	2 x LED, green
EDID Indicators		3 x LED, green
Routing Indicators		16 x LED, green

Connectors	
Video Input	4 x HDMI Type A 19-pin, female, locking
Video Output	4 x HDMI Type A 19-pin, female, locking
USB	Mini-B
RS-232	1 x DB-9, female
Ethernet	• 1 x RJ-45
IR Extender	1 x 3.5mm mini-stereo
Power	Locking-type

Operational		
Power Input	•	5V DC
Power Consumption	•	13W (max.)
Operating Temperature	•	+32 to 104 °F (0 to +40 °C)

(continued on next page)

Physical		
Dimensions (W x H x D)	•	6.9" x 11.9" x 1.0" (175mm x 302mm x 26mm)
Unit Weight	•	1.4 lbs (0.6 kg)

Stretch it, Switch it, Split it.

Gefen's got it. ®

20600 Nordhoff St., Chatsworth CA 91311 1-800-545-6900 818-772-9100 fax: 818-772-9120 www.gefen.com support@gefen.com











