

ASSEMBLY INSTRUCTION FOR

BAR TABLE

DA-18010-6-BTT / DA-18010-6-BTB








Caution : Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.









1.We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage the product or injury to persons during assembly.


2.Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.

3.Please do not over tighten screws or bolts.


4.Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

PARTS LIST			
NO.	PART DESC	CODE	Q' TY
A	 Bar Table Top	PDA-18010-6-BTT	1
B	 Bar Table Base	DA-18010-6-BTB	1
C	 Ice Tray	PDA-18010-6-BTBICTRY	1
D	 Plastic Tray	PDA-18010-6-BTBPTTRY	1
E	 Side Foot Rest	PDA-18010-6-BTTSFR1	2
F	 Front Foot Rest	PDA-18010-6-BTTSFR2	1
G	 Bottle Opener	PDA-18010-BTTBOP	1


HARDWARE LIST				
NO.	HARDWARE DESC		CODE	Q' TY
1		Allen Bolt (Ø1/4" *1-1/2")	PD-18010 -BTTHW	7
2		Allen Bolt (Ø1/4" *3/4")		12
3		Allen Bolt (Ø1/4" *9/16")		2
4		Spring Washer (Ø1/4") * Ø10		21
5		Flat Washer (Ø1/4") * Ø16		21
6		D-nut(Ø1/4") * 13mm		14
7		Allen Wrench (M4)		2
 SCREW-DRIVER (NOT PROVIDED)				

 Only tighten all bolts when all bolts aligned with bolt inserts

STEP 1 : Attach the top.



STEP 2 : Attach the side foot rest at both the sides.




ASSEMBLY INSTRUCTION FOR


BAR TABLE

DA-18010-6-BTT / DA-18010-6-BTB

STEP 3 : Attach the front foot rest .




STEP 4 :




STEP 5

The light is operated by touching the metal button located on the left of the Bar Table.



STEP 6



Complete