

SC 7 ASSEMBLY INSTRUCTIONS


PARTS INCLUDED:

- | | | |
|--------------------------|----------------------------|------------------------|
| (3) Left Angles | (3) 4-1/2" Threaded Glides | (3) LE-4 Leg Extenders |
| (3) Right Angles | (3) 2-1/2" Threaded Glides | with threaded inserts |
| (3) Clamps w/thumbscrews | (6) #8 Wood Screws | |


TO ASSEMBLE:

1. Measure the distance from the wood cleat to the floor.
2. Use the appropriate combination of glides and leg extenders to achieve the desired height. See combinations below:
3. Overlap one right angle over a left angle and extend them to the appropriate width. The holes at the end of each piece should be on the outside and on the top.
4. Center one clamp over the 2 angles, and extend the angles to the proper width so they rest on the cleats of the wood rails.
5. Secure each end of the rails to the wood cleats with the wood screws, and unscrew the threaded glide until it reaches the floor. Repeat with the other 2 sets of rails.


2-1/2" Glide Only
6"-8" Height Range



4-1/2" Glide Only
8"-10" Height Range




4-1/2" Glide with (1) LE-4
10"-14" Height Range



****Additional leg extenders are available to increase the height of the bed****

REVISED 12/3/2009



SC 7 ASSEMBLY INSTRUCTIONS


PARTS INCLUDED:

- | | | |
|--------------------------|----------------------------|------------------------|
| (3) Left Angles | (3) 4-1/2" Threaded Glides | (3) LE-4 Leg Extenders |
| (3) Right Angles | (3) 2-1/2" Threaded Glides | with threaded inserts |
| (3) Clamps w/thumbscrews | (6) #8 Wood Screws | |


TO ASSEMBLE:

1. Measure the distance from the wood cleat to the floor.
2. Use the appropriate combination of glides and leg extenders to achieve the desired height. See combinations below:
3. Overlap one right angle over a left angle and extend them to the appropriate width. The holes at the end of each piece should be on the outside and on the top.
4. Center one clamp over the 2 angles, and extend the angles to the proper width so they rest on the cleats of the wood rails.
5. Secure each end of the rails to the wood cleats with the wood screws, and unscrew the threaded glide until it reaches the floor. Repeat with the other 2 sets of rails.


2-1/2" Glide Only
6"-8" Height Range



4-1/2" Glide Only
8"-10" Height Range



4-1/2" Glide with (1) LE-4
10"-14" Height Range



****Additional leg extenders are available to increase the height of the bed****

REVISED 12/3/2009

