














HEKMAN®

A HOWARD MILLER COMPANY

16104 ROUND PEDESTAL LAMP TABLE


HARDWARE LIST								
A	B	C	D	E	F	G	H	
ALLEN BOLT M6x30 mm (4 Pcs)	ALLEN BOLT M8x35 mm (3 Pcs)	FLAT W. M6 (4 Pcs)	LOCK W. M6 (4 Pcs)	FLAT W. M8 (3 Pcs)	LOCK W. M8 (3 Pcs)	ALLEN KEY L4 (FOR BOLT M6) 1 PC.	ALLEN KEY L5 (FOR BOLT M8) 1 PC.	
								

PART INSIDE			
1	2	3	4
TOP ASSEMBLY (1 Pc)	MOUNTING PLATE (1 Pc)	COLUMN (1 Pc)	BASE (1 Pc)
			

Assembly Instruction


STEP 1.

ATTACH THE BASE (4) TO THE COLUMN (3).



STEP 2.

ASSEMBLE THE MOUNTING PLATE (2) TO THE COLUMN (3) WITH ALLEN BOLT (B), LOCK WASHER (F), FLAT WASHER (E) USE ALLEN KEY (H) AND TIGHTEN THE BOLTS.



STEP 3.

LAY TOP ASSEMBLY OF THE ROUND PEDESTAL LAMP TABLE UPSIDE DOWN ON SOFT, CLEAN AND FLAT SURFACE.

ALIGN MOUNTING PLATE ASSEMBLY (2) TO HOLES IN THE TOP ASSEMBLY (1) AND CONNECT USING FLAT WASHER (C), LOCK WASHER (D), ALLEN BOLT (A) AND ALLEN KEY (G) PROVIDED.

